

VISAGE: IMPROVING THE BALLISTIC VULNERABILITY MODELING AND ANALYSIS PROCESS

THESIS

Brett F. Grimes

Computer Engineer, 88 CG/SCSA, USAF

AFIT/GCS/ENG/95M-01

19950503 100

Approved for public release; distribution unlimited.

REPORT DOCUMENTATION PAGE

Form Approved
OMB No. 0704-0188

Public reporting burden for this collection of information is estimated to average. I hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing the collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden, to: Washington Headquarters Services, Directorate for information Operations and Reports, 1215 Jefferson Charles and Comments and Reports, 1216 August 2004. Alignon VA. 22702-4802, and to the Office of Management and Budget, Paperwork Reduction Project (0704-0188), Washington, OC 20503.

Davis Highway, Suite 1204, Arlington, VA 22202-4302	l, and to the Office of Management and b	udget, Paperwork Reduction Project (07	(4-0185), washington, be 20003.	
Davis Highway, Suite 1204, Arlington, VA 22202-4302, and to the Office of Management and Budget, Paperwork Reduction Project (07/04-0188), Washington, DC 20303. 1. AGENCY USE ONLY (Leave blank) 2. REPORT DATE 3. REPORT TYPE AND DATES COVERED				
4. TITLE AND SUBTITLE		5. 1	FUNDING NUMBERS	
VISAGE: IMPROVING THE	ERALLISTIC VIII NE	RABILITY		
		KADILITT		
MODELING AND ANALYS	SIS PROCESS			
6. AUTHOR(S)				
Brett F. Grimes, Computer E	ngineer, 88 CG/SCSA,	USAF		
7. PERFORMING ORGANIZATION NAME	(S) AND ADDRESS(ES)	8.	PERFORMING ORGANIZATION	
7. PERFORINING ORGANIZATION HAME	(13) Mito Hoomzoofzoy		REPORT NUMBER	
		22.4502		
Air Force Institute of Techno	ology, WPAFB, OH 454	33-6583		
		F	AFIT/GCS/ENG/95M-01	
9. SPONSORING/MONITORING AGENC	Y NAME(S) AND ADDRESS(ES)	10.	SPONSORING / MONITORING AGENCY REPORT NUMBER	
Hugh Griffis	Marty Lentz			
ASC/XRESV	WL/FIVS			
WPAFB, OH 45433	WPAFB, OH 454	33		
255-2353 ×2353	255-6302			
11. SUPPLEMENTARY NOTES				
12a. DISTRIBUTION / AVAILABILITY STA	TEMENT	120	D. DISTRIBUTION CODE	
Approved for public release;	distribution unlimited;			
13. ABSTRACT (Maximum 200 words)				
The purpose of this thesis wa	as to improve the proces	s of modeling and analy	yzing ballistic vulnerability	
data. This was accomplished	by addressing two of th	e more urgent needs of	vulnerability analysts; the	
ability to display fault tree da	ita and to edit target desc	criptions. A vulnerabilit	v data visualization program	
called VISAGE was modifie			1 6	
VISAGE was originally creat		tline plots and subseque	ently grew into a full-featured	
visualization package for vul	lnerability target descrip	tions and analyses data	The next logical step in the	
visualization package for vulnerability target descriptions and analyses data. The next logical step in the				
programs evolution was to include the needed editing and fault tree display capabilities.				
The editing features were divided into basic and advanced categories. The basic editor allows users to				
manipulate parts at the lowest level of a target description. The advanced editor allows users to manipulate				
a target description at its highest levels.				
The display of fault tree data is a cutting edge feature, since, currently, no other vulnerability package can offer the same capability. The fault tree data is also linked to the target description geometry, so that users				
		nked to the target descr	ipnon geometry, so that users	
can view fault tree data depe	endencies.			
14. SUBJECT TERMS			15. NUMBER OF PAGES	
Vulnerability, Ballistic, Visualization, Editing, Fault Tree, FASTGEN,			174	
•	ianzation, Editing, Fault	Tree, FASTGEN,	16. PRICE CODE	
COVART				
	SECURITY CLASSIFICATION OF THIS PAGE	19. SECURITY CLASSIFICATI OF ABSTRACT	ON 20. LIMITATION OF ABSTRACT	
OF REPORT Unclassified	Unclassified	Unclassified	UL	

VISAGE: IMPROVING THE BALLISTIC VULNERABILITY MODELING AND ANALYSIS PROCESS

THESIS

Presented to the Faculty of the Graduate School of Engineering

of the Air Force Institute of Technology

Air University

In Partial Fulfillment of the

Requirements for the Degree of

Master of Science in Computer Systems

Brett F. Grimes

Computer Engineer, 88 CG/SCSA, USAF

January 1995

Accesio	n For		
NTIS DTIC Unanno Justific	TAB ounced	X	
By			
Availability Codes			
Dist	Avail at Spec		
A-1			

Approved for public release; distribution unlimited.

Preface

The purpose of this thesis was to improve the process of modeling and analyzing ballistic vulnerability data. This was accomplished by addressing two of the more urgent needs of vulnerability analysts; the ability to display fault tree data and to edit target descriptions. A vulnerability data visualization program called VISAGE was modified to meet these needs.

I would like to thank all the people who have given me advice, support, and encouragement while writing this thesis. I would like to thank my thesis advisor, Dr. Henry Potoczny, for his insights into Boolean logic. I would also like to thank Lt. Col. Martin Stytz (committee member) and Lt. Col. (Ret.) Patricia Lawlis for their advice and continual patience. My gratitude goes to the sponsors of this thesis, Hugh Griffis and Marty Lentz, for constantly providing me with new challenges. Also, I greatly appreciate the efforts of Capt. Oscar Lessard, who displayed unending skill in discovering "unintended features" in my code. I also appreciate the forbearance and support of my fellow co-workers in 88 CG/SCSA during my attendance at AFIT. Especially, my former supervisor, Dr. Bob Jurick, and my current supervisor, F. Keith Jones, who enthusiastically supported my educational efforts. Finally, I would like to thank my fiancee', Patty and my family, for their continual understanding, love, and support during my endeavors at AFIT.

Brett F. Grimes

Table of Contents

Preface	. ii
List of Figuresv	vii
List of Tablesvi	'iii
Abstract j	ix
I. Introduction	. 1
Problem Statement	. 1
Objectives	2
Approach	2
II. Background	4
Survivability	4
Susceptibility	5
Vulnerability	6
Ballistic Vulnerability Assessment Process.	6
Modeling	7
FASTGEN	7
Analysis	9
COVART1	0
HOOPS Graphics Library	0
Open Software Foundation (OSF) Motif Widgets	. 1
Push Ruttons	2

	Toggle/Radio Buttons	. 12
	Labels	. 12
	Menu Bar	. 12
	Pulldown Menus	. 12
	Option Menus	. 12
	Scales	. 13
	Text Fields	. 13
	Scrolled Windows	. 13
	Scrolled Lists	. 13
	Scrolled Text	. 13
	Message Dialogs	. 13
	File Selectors.	. 14
	Popup Dialogs (Non-standard)	. 14
	Arrow Buttons w/Text Fields (Non-standard)	. 14
V	TSAGE	. 14
C	onclusion	. 19
III.	Methodology	20
E	nhancements Tasks	. 20
T	arget Description Editing Features	. 20
В	asic Editor	20
R	asic Editor Features	21

FASTGEN Bulk Data File (BDF) Organization	21
VISAGE BDF Data Structures	22
Basic Editor Function Implementation	25
Basic Editor GUI Design	26
Advanced Editor	29
Advanced Editor Features	29
Advanced Editor Function Implementation	30
Advanced Editor GUI Design	31
Fault Tree Analysis Background	33
Fault Tree Data Display	35
Intuitive	35
Compact	37
Standard Motif Widgets	37
Interaction	8
Fault Tree Data Format	8
Set Level	9
Function Level3	9
System Level	9
Subsystem Level	.0
Component Level 4	0
Fault Tree Data Viewer (FTDV) GUI Design	n

VISAGE Fault Tree Data Structure	43
IV. Enhancement Effort Results	46
VISAGE 4	16
Pros	16
Cons	16
Structure 4	16
Target Description Editing Enhancements	17
Fault Tree Data Display Enhancement 4	19
V. Conclusions and Recommendations 5	2
Strengths and Limitations 5	2
Target Description Editing	2
Fault Tree Data Display	2
Practical Implications	3
Recommendations 5	3
Conclusion 5	4
Appendix A: Computer Code Routine List (By File)5	5
Appendix B: Computer Code Outline	0
Appendix C: Interface Motif Widget Summary	8
Appendix D: VISAGE 2.2 User's Manual 92	2
Bibliography	2
Vita	A

List of Figures

Figure 1 The Modeling Process	7
Figure 2 The Analysis Process	10
Figure 3 VISAGE Advanced Rendering Example	16
Figure 4 VISAGE Orthogonal Slicer Example	17
Figure 5 BDF Categorization	23
Figure 6 VISAGE BDF Data Structures	25
Figure 7 Basic Editor Preview Capability Example	28
Figure 8 DCE and DV Interfaces	29
Figure 9 Advanced Editor GUI Design	32
Figure 10 Advanced Editor Preview Capability	33
Figure 11 Fault Tree Boolean Logic Operations	34
Figure 12 Example Fault Tree.	36
Figure 13 Simple Fault Tree Example	42
Figure 14 Target Description for Example Fault Tree	43
Figure 15 Fault Tree Segment Names and Organization	45

List of Tables

Table 1 BDF Card Categories	23	
Table 2 Depth-first Tree Traversal Output	36	
Table 3 Breadth-first Tree Traversal Output	37	

AFIT/GCS/ENG/95M-01

Abstract

The purpose of this thesis was to improve the process of modeling and analyzing ballistic vulnerability data. This was accomplished by addressing two of the more urgent needs of vulnerability analysts; the ability to display fault tree data and to edit target descriptions. A vulnerability data visualization program called VISAGE was modified to meet these needs.

VISAGE was originally created to preview static shotline plots and subsequently grew into a full-featured visualization package for vulnerability target descriptions and analyses data. The next logical step in the program's evolution was to include the aforementioned needed capabilities.

The editing features were divided into basic and advanced categories. The basic editor allows users to manipulate parts at the lowest level of a target description. Users can modify existing parts or create entirely new ones. The advanced editor allows users to manipulate a target description at its highest levels. Users can then create or modify large pieces of a target description. A previewing feature available on both editors allows users to double-check any modifications or additions.

The display of fault tree data is a cutting edge feature, since, currently, no other vulnerability package can offer the same capability. To simplify the implementation, the fault tree data is displayed in an outline format. There are two main benefits of using the outline format. First, the format is easily represented by the low-level Motif widgets of which the Graphical User Interface (GUI) of VISAGE is constructed. Second, the outline format is a more compact form for displaying the fault tree data.

VISAGE: IMPROVING THE BALLISTIC VULNERABILITY MODELING AND ANALYSIS PROCESS

I. Introduction

The question of vulnerability modeling and analysis is not why it is needed, but of how it can best be accomplished. The need for vulnerability modeling and analysis is readily demonstrated by a number of incidents from the recent Gulf War, for example:

"In one incident, an F-16C was hit by warhead fragments that damaged both ends of the engine. Although the fan, several compressor stages, and the exhaust nozzle were damaged, the engine and afterburner continued to provide thrust, permitting the aircraft to climb rapidly to high altitude and return 500 miles to base [1:33]."

Without the benefit of vulnerability modeling and analysis early on and throughout the design stages of the F-16, that aircraft, and quite possibly the pilot, would most likely have been lost.

Problem Statement

The problem with the ballistic vulnerability modeling and analysis process is basically a lack of the right software tools. Vulnerability analysts have a choice of several programs to create target descriptions of aircraft and to analyze the vulnerability aspects of these aircraft. However, very few software tools exist that allow the analysts to manipulate and correct the structure of FASTGEN-format target descriptions and view the accompanying analysis results. To simplify the ballistic vulnerability modeling and analysis process, a software tool is needed that will address these issues.

Objectives

The first objective of this project was to determine how to best address the lack of software tools. The obvious answer was to look at the currently used tools. A visualization program called VISAGE is widely used to view FASTGEN-format target descriptions and associated analysis data. VISAGE is an Air Force-owned program previously developed by the author for the sponsors of this project, Hugh Griffis of ASC/XRESV and Marty Lentz of WL/FIVS. It was determined that the simplest course of action would be to add the necessary tools to the VISAGE program. The next objective was to determine what features could be added to VISAGE to provide the needed capabilities. Several meetings were held with the sponsors to determine what features would be the most beneficial to the vulnerability assessment process. From these meetings, two features were identified for addition to the VISAGE program:

- 1. Comprehensive target description editing capabilities.
- 2. Display of vulnerability fault tree data in conjunction with target descriptions.

Approach

To address the issue of editing capabilities, several more meetings with the sponsors were required to determine the editing features needed by vulnerability analysts. Then it was necessary to reconcile those needs with the program structure of VISAGE and the capabilities of the underlying graphics system. This resulted in the set of editing features that would be added to VISAGE. Given the editing features, the next step was to come up with the appropriate Graphical User Interface (GUI) design.

The next step was to determine how to add the fault tree data display capabilities to VISAGE. This required a study of the theory and uses of Fault Tree Analysis (FTA). Having gained an understanding of the uses of FTA in vulnerability assessments, it was

then necessary to determine the best method of presenting fault tree data to the analyst. After a display format was decided upon, it was then necessary to determine how best to implement the display in terms of the GUI of VISAGE.

Having completed the addition of the enhancement features, the results of the effort needed to be evaluated. This was done through a staged release of the program. After completing the target description editing additions, the new VISAGE program was released to selected test sites for evaluation. The results of these evaluations were then used to correct and refine the enhancements. The same approach was taken for the fault tree data display enhancements.

II. Background

Before addressing the process of ballistic vulnerability modeling and analysis, some background is needed.

Survivability

"Aircraft combat survivability is defined here as the capability of an aircraft to avoid and/or withstand a man-made hostile environment [2:1]." The measure of an aircraft's survivability is based on probabilities. Survivability is denoted by P(S), probability of survival, and is the complement of the probability of a kill. The probability of a kill is composed of two other probability factors; susceptibility and vulnerability. Susceptibility is measured by the probability of a kill given a hit.

Probability of Kill = Susceptibility * Vulnerability

$$P(K) = P(H) * P(K/H)$$
 (1)

where

P(K) = Probability of Kill

P(H) = Probability of Hit (susceptibility)

P(K/H)= Probability of Kill given a Hit (vulnerability)

The probability of survival, P(S) is given by:

$$P(S) = 1 - P(K) \tag{2}$$

$$= 1 - (P(H) * P(K/H))$$
 (3)

Examination of equations (1) and (3) lead to the conclusion that to increase the probability of survival, P(S), the reduction of the susceptibility and/or the vulnerability of the aircraft is required. However, these reductions must not significantly degrade the mission capability of the aircraft.

Susceptibility

Susceptibility is defined as an aircraft's inability to avoid a man-made hostile environment and can be quantified as the probability that an aircraft is hit by a damage-causing mechanism. Susceptibility generally consists of three categories:

- 1. threat activity
- 2. detection, identification, and tracking
- 3. threat engagement

The measure of the susceptibility of an aircraft is dependent upon the probability of a threat being ready to engage, the probability of the aircraft being detected, and the probability of the threat being employed against the aircraft. An aircraft's susceptibility can be influenced by factors such as design (signature reduction, maneuverability, etc.), tactics, and survivability equipment (jammers, chaff, etc.). The reduction of an aircraft's susceptibility is usually accomplished in one or more of the following ways:

- 1. threat warning
- 2. electronic jammers and deceivers
- 3. signature reduction (stealth)
- 4. expendables
- 5. threat suppression
- 6. tactics

Vulnerability

Vulnerability is defined as an aircraft's inability to withstand the damage caused by the man-made hostile environment and can be quantified as the probability of a kill given a hit. This probability is expressed as the ratio of the vulnerable area of the aircraft to the presented area of the aircraft. An aircraft's vulnerable area is influenced by the design (component redundancy, location, etc.) and survivability features (damage suppression, etc.). The reduction of an aircraft's vulnerability is usually accomplished in one or more of the following ways:

- 1. component redundancy with separation
- 2. component location
- 3. passive damage suppression
- 4. active damage suppression
- 5. component shielding
- 6. component elimination

Ballistic Vulnerability Assessment Process

Several software programs can be used to create vulnerability assessments. This thesis focuses on the assessments based on data from the FASTGEN and COVART programs. The ballistic vulnerability assessment process deals with the determination of an aircraft's ability to withstand various ballistic threats, such as small arms, machine gun, and cannon fire. This assessment process is composed of two parts; modeling and analysis.

Modeling

Modeling ballistic threats can be done in several ways. This thesis is concerned with the modeling methods used by FASTGEN. The modeling part of the process consists of the following steps:

- 1. Aircraft model generation (from CAD, FEA, or other source)
- 2. Translation of model to FASTGEN target description format (if needed)
- 3. Validation and correction of target description
- 4. Generation of LOS data

These steps are shown in Figure 1.




Figure 1 The Modeling Process

FASTGEN

FASTGEN is a program that generates shotlines using a ray-casting technique. Shotlines are the paths followed by ballistic threats. These paths may or may not intersect with a target description. A target description is a geometric model of an aircraft. In

FASTGEN, a target description file is also known as a bulk data file. A target description has three levels of detail; the Group, Component, and Element levels. The Group level is the top level and is divided into twelve types (for aircraft):

- 1. Aircraft Skin
- 2. Power Plant
- 3. Crew
- 4. Flight Control System
- 5. Fuel System
- 6. Ammunition (including bombs)
- 7. Armament
- 8. Structural Members
- 9. Electrical/Avionics Systems
- 10. Miscellaneous
- 11. Threat (added for VISAGE)
- 12. Fragment (added for VISAGE)

These Group level types cover the main functional areas of an aircraft for the purposes of vulnerability analysis. Each Group can consist of up to 999 Components.

The Component level is the middle level and can consist of a maximum of 999 Elements. No special types are assigned to the component level. Generally, components correspond to the systems and subsystems of a target description.

The Element level is the lowest level. Elements are used to describe the basic parts of a target description.

Target descriptions are generally based on Computer-Aided Drafting (CAD) or Finite Element Analysis (FEA) models, but some are created specifically for vulnerability studies. The CAD and FEA models are then translated into the FASTGEN bulk data format. This transition is not always smooth, since the translation programs may introduce errors. Also, the specifically created models may have errors. To ensure accurate analysis results, the errors in the FASTGEN target description must be corrected. Once the target description is corrected, an analyst can use FASTGEN to create Line-Of-Sight (LOS) data. LOS data is basically a listing of all the components of a target description that are encountered by each shotline. In other words, it is a damage record for each projectile threat. This LOS data can then be used as input data for the COVART program.

Analysis

Analysis of ballistic threats can also be done in several ways. This thesis is mainly concerned with the methods used by COVART. The analysis part of the process consists of the following steps:

- 1. Generation of COVART input files (specifications for threat type, component vulnerabilities, etc.)
- 2. Run COVART with input files and LOS data
- 3. Output of P(K) results
- 4. Output of fault tree data (optional)
- 5. Repeat Step 2 for various threats

These steps are shown in Figure 2.




Figure 2 The Analysis Process

COVART

COVART is a program that can be used to evaluate the FASTGEN shotline data for a target description. COVART has several data input files that are used to describe the aircraft in terms of its vulnerabilities. COVART can produce the various probabilities of failure for each component described by the input data files and the LOS data. COVART can also produce a fault tree output file that describes the interdependencies of all the components of a target description. A fault tree is a graphical representation of the Boolean equation of failure for a target description. Generating a fault tree is an important capability because it allows vulnerability analysts to see the weak points of an aircraft. This is key to applying the six methods of vulnerability reduction listed previously. By being able to tell where an aircraft's weaknesses are, an aircraft designer can go back to the design and implement the appropriate vulnerability reduction technique.

HOOPS Graphics Library

HOOPS is a set of graphics routines used for creating interactive graphics applications. HOOPS is, mainly, a database that stores information about the drawing, display, and rendering of objects. The HOOPS database is organized as a tree-shaped

hierarchy, resembling a file directory. The system provides an application program with tools for modifying, querying, searching, and displaying the HOOPS database.

The data consists of geometric primitives, cameras, lights, modelling attributes, and application-specific information. Related elements are grouped together in segments, which are the units of organization within the database. Each segment may also contain other segments, hence the resulting tree structure. The hierarchical grouping is an efficient way of organizing data, since it lets the user manipulate the component parts of objects, or of groups as a whole.

All information stored in the database can be changed. Geometry can be edited, attributes can be modified, and the hierarchy can be reshaped. After a series of changes is completed, the user directs the system to update the display to reflect the new contents of the database. The sequence of determining the user's request, modifying the database accordingly, and redisplaying the image becomes the major theme in an interactive graphics program [3:1].

Open Software Foundation (OSF) Motif Widgets

Motif is the name for the OSF window management system for the X Window System. The X Window System is a window-based display system found mostly on UNIX-based computer systems. Motif provides software developers with a set of X Window-compliant GUI components known as widgets. These widgets provide basic user interface capabilities and some of them can be combined to create more complex widgets, referred to here as compound widgets. The GUI for VISAGE is based on the standard OSF Motif widget set and some compound widgets created specifically for VISAGE. A summary of the Motif widgets used in the interface can be found in Appendix C. The following is a list of the Motif widgets in the interface and how they are used.

Push Buttons

Push buttons are widgets that initiate an action or function when selected ("clicking on") with the mouse (or other input device).

Toggle/Radio Buttons

Toggle buttons essentially act like "check boxes" and may be used to initiate an action or set an option or flag. Radio buttons are a special case of toggle buttons, in that only one out of a group may be selected at any time. The name is derived from the buttons used for selecting preset stations on radios.

Labels

These are text strings that are used for labeling purposes in an interface.

Menu Bar

This is an organizing widget that only contains pulldown menus.

Pulldown Menus

This is a menu, found in menu bars, that the user activates by selecting once or by holding down the mouse button on the selected menu text. This brings up a menu of push buttons or other widgets for the user to select.

Option Menus

Option menus are a special case of pulldown menus, in that they may appear in places other than a menu bar and have a different appearance. This selection becomes the "top" of the "menu" and is displayed on the widget.

Scales

Scale is the Motif name for a sliding bar. This widget lets the user select a number from a preset range of numbers. Users can elect to "drag" the sliding bar to a selected point using the left mouse button, jump to a selected point using the middle mouse button, or increment or decrement the current selected value by clicking to the right or left, respectively, of the sliding bar.

Text Fields

These widgets allow the user to type in text and may also be called "text type-ins".

Scrolled Windows

Scrolled windows allow the user to scroll around a window containing more items than can be displayed at once in the allotted window size.

Scrolled Lists

Scrolled lists allow the user to scroll through a list of choices and to select one item.

Scrolled Text

Scrolled text widgets are used to allow the user to scroll through text information that may be larger than the available display area.

Message Dialogs

Message dialogs are used to confirm an action, such as exiting the program.

File Selectors

File selectors are compound widgets (composed of several different widgets, but treated as one large widget) that allow the user to select files for input or output purposes.

Popup Dialogs (Non-standard)

Popup dialogs are compound widgets that are created by the GUI designer.

These dialogs are used to separate different functions of the program, to compartmentalize operations and to prevent information overload.

Arrow Buttons w/Text Fields (Non-standard)

These are compound widgets that are similar in function to the Scales. A user can increment or decrement the value displayed in the associated text field by clicking on either the up or down arrows, respectively. The user can also input a specific value by typing inside the text field.

VISAGE

VISAGE is a liberally derived acronym for VISualization of Vulnerability Analysis and GEometry. (The title of VULnerability Geometry and Analysis Results (VULGAR) was a close second.) VISAGE is a U.S. Air Force-developed program written in the C programming language, with the graphics display handled by calls to the HOOPS Graphics Library from Ithaca Software. The Graphical User Interface (GUI) for VISAGE is based on Motif, a window management interface to the X Window System.

VISAGE is a specialized program designed to allow vulnerability analysts to visualize, verify, and correct FASTGEN target descriptions and analysis data. It provides users with a combination of visualization and CAD program features. Each feature was

added to address specific requirements of vulnerability analysts. The end result is a program custom-made for working with FASTGEN data. Some important features of VISAGE are:

- 1. Advanced rendering capabilities
- 2. Orthogonal slicing of target descriptions
- 3. View controls (rotation, zoom, and pan)
- 4. Color contours
- 5. Animation
- 6. Hard copy output (PostScript, EPS, HPGL, CGM, and PICT)
- 7. Motif-based Graphical User Interface (GUI)

The advanced rendering capabilities allows users to determine the visibility, color, and transparency of a target description down to the component level. It also provides lighting with flat, Gouraud, or Phong shading and specular highlighting. The shading is limited to HOOPS "shell" geometry items. Shell geometry items are figures such as hexahedrons, cylinders, or spheres that are created by giving HOOPS a set of points and a connection list (face list) for the points. Non-shell geometry items will be flat-shaded. Figure 3 shows an F-15 with Gouraud shading and the aircraft skin semi-transparent.

The orthogonal slicer provides six cutting planes, with each axis having a cutting plane for the positive and negative directions. Users can activate as many of the six cutting planes as they want and position them anywhere along their respective axes. Figure 4 shows an F15 with a cutting plane applied at the mid-section of its port-side engine.




Figure 3 VISAGE Advanced Rendering Example




Figure 4 VISAGE Orthogonal Slicer Example

The View Controls dialog allows users to specify specific azimuth and elevation coordinates for the camera viewpoint. A pull-down menu allows users to jump to preset views, as defined in the FASTGEN manual. The View Control dialog also serves as the main controls interface. It can summon other control interfaces, such as the Orthogonal Slicer dialog, the Geometry Options dialog, and the Select View dialog. It contains push-buttons for zoom operations and to reset the display to the default view. Another pull-

down menu allows users to select different hidden surface algorithms. There are also controls to set the visibility of the coordinate axes and the target description's grid and element numbers. The View Controls dialog can be seen at the right side of Figures 3 and 4.

VISAGE allows users to display analysis data as color "contours" on the target descriptions. Through the Contour Data File, users can specify that components and elements of a target description be displayed in any of 30 different colors. This feature is linked to the animation capabilities, so that users can step through changes in the data set.

The animation features are currently limited to the camera viewpoint. Sets of viewpoint data enable users to "fly" the camera view around the "space" occupied by a target description.

Users can also output the currently displayed target description in any of five different formats; PostScript, Encapsulated PostScript, HPGL, CGM, and PICT. In addition, the HPGL and CGM formats allow users to specify the plot in either an A (8.5"x11"), B (11"x17"), C (17"x22"), D (22"x34"), or E (34"x44") size.

The most underrated feature is the Motif-based GUI. Most users today take graphical interfaces for granted and have come to expect them in all software. With GUI building and management tools creating an interface for an application is not nearly as hard as it was in the past. The trickiest part of creating an interface is trying to design in intuitiveness of use. Issues as simple as color schemes can take on great importance when evaluating an interface for its "look and feel".

Conclusion

Ballistic vulnerability analysis is an essential part of combat aircraft design and production. Data collected during various wars and conflicts has demonstrated this repeatedly. The problem has been one of the availability of adequate software tools to perform the necessary analyses. The VISAGE software was created to provide some of the capabilities needed by vulnerability analysts. To further address the modeling and analysis issues of the ballistic vulnerability assessment process, the two features of target description editing and fault tree data display were identified for addition to VISAGE. The remainder of this study will be concerned with the development and addition of these two features.

III. Methodology

This thesis focuses on improving the ballistic vulnerability assessment process by adding needed capabilities to the VISAGE vulnerability data visualization software package. This chapter describes the addition of the target description editing and fault tree data display capabilities.

Enhancements Tasks

Two enhancement tasks were identified:

- 1. Add comprehensive target description editing features.
- 2. Add fault tree data display features.

Target Description Editing Features

To simplify the development, the editing features were divided into two categories; basic and advanced. The reason for this was one of scope. The features required by the survivability analysts applied to different levels of the target description. The features identified for the basic editor apply at the Element and Component levels of a target description. The features identified for the advanced editor apply at the Component and Group levels. Thus, all levels of the target description may be edited through the two editors.

Basic Editor

Three steps were followed in adding basic editing features to VISAGE:

- 1. Determine which features are needed.
- 2. Determine how the needed features can be implemented in VISAGE.
- 3. Determine the appropriate GUI interface components.

Basic Editor Features

Four basic features for elements and components were identified:

- 1. creation
- 2. deletion
- 3. editing
- 4. copying

These four features provide all the functionality needed for a basic editor. Next, it was necessary to decide how to best implement these functions in the context of the FASTGEN bulk data file format and the internal data structures of VISAGE.

FASTGEN Bulk Data File (BDF) Organization

The FASTGEN bulk data file format is basically a listing of the components of a target description. The data entries of the BDF are known as "cards," with each 80-character card consisting of 10 fields of 8 characters each. Most BDF data entries are one card long, but some require a second card, referred to as a continuation card. Each component is designated by a special data entry, known as a SECTION card, which specifies the group to which the component belongs, the identification number of the component, the material type of the component, and whether the component contains plate or volume elements. Each component consists of GRID, POINT (optional), and element cards (e.g., CQUAD, CTRI, CSPHERE, etc.), which immediately follow the SECTION card. The GRID cards specify the 3-dimensional coordinates used by the element cards. The POINT cards are used to specify the geometric entities that make up the target description. An example BDF can be found in Appendix A of the VISAGE 2.2 User's Manual, which is found in Appendix D of this document.

VISAGE BDF Data Structures

The original VISAGE BDF data structure was a dynamically allocated 2-dimensional character array. A subroutine would read the contents of a FASTGEN BDF into this array and, using the contents of the array, another subroutine would build the target description. Then, since the data was no longer needed, the array was deallocated. Adding editing capabilities to the program required that the data be retained and kept accessible. The original data structure could have been retained, but it did not provide the best access to the different components of the BDF. Therefore, the next step was to determine a more suitable data structure, taking into account the organization of the BDF. Examination of the BDF format led to the conclusion that the cards in the BDF could be grouped into 5 categories:

- 1. global data
- 2. component data
- 3. grid data
- 4. point data
- 5. element data

The global category is singular, but the component, grid, point, and element categories are repeated for each component in the BDF. The global data category contains all data entries that apply to the complete target description. The component data category holds all cards that supply information about a specific component. The grid and point categories contain all the grid and point cards, respectively, of a component. The element category contains all the element cards of a component. Figure 5 shows an example of the categorization of the BDF.




Figure 5 BDF Categorization

Table 1 lists the BDF cards in each category. A complete description of the formats for these cards can be found in the VISAGE 2.2 User's Manual (Appendix E) and the FASTGEN 4.1 User's Manual.

Global	Component	Grid	Point	Element
VEHICLE	SECTION	GRID	POINT	CCONE1
HOLE	UNITLCL			CCONE2
WALL	CORDAE			CHEX1
\$COMMENT	\$NAME			CHEX2
UNITGBL	\$COMMENT			CLINE
				CQUAD
				CSPHERE
				CTRI

Table 1 BDF Card Categories

In VISAGE, these categories are implemented as two structures; one for the global (or header) data and one for the component, grid, point, and element data. The reason for this is that the global data can be kept in one block, while the componentrelated data must be kept for each component specified in the target description. The global data is kept in a dynamically allocated structure array called TGheader. TGheader is a pointer of type dline. Type dline is a structure that consists of one 82-character array, in which one card may be stored. Initially, TGheader is allocated one dline entry. As global data cards are read in, **TGheader** is allocated more **dline** entries, one per card. The component-related data is kept in a static 2-dimensional array called TGdata. TGdata is a 12 x 1000 array of type targetgeom. Type targetgeom consists of four pointers (comp, grid, point, and elem) of type dline, four integer variables (ccnt, gcnt, pcnt, and ecnt) to serve as counters for the arrays pointed to by comp, grid, point, and elem, and one integer variable (update) that serves as a geometry update flag. Initially, comp, grid, point, and elem are null pointers and the integer variables are set to zero. As the cards of each component in the BDF are read in, the comp, grid, point, and elem pointers of the specified component are allocated dline entries and the entry counts are updated accordingly. The update flag is also set to true. Since the FASTGEN BDF does not require components to be specified in numerical order, the array for the pointers is statically allocated for simplification and to avoid overhead due to dynamic allocation and ordered insertion operations. The dynamic arrays for the individual components are not allocated unless the components are specified in the BDF or are created during an editing session. Figure 6 shows the data structures and the corresponding C programming language declarations.




Figure 6 VISAGE BDF Data Structures

Basic Editor Function Implementation

Given the data structures, the next step was to implement the four basic editing functions of creation, deletion, modification and copying. This was accomplished by making some modifications to the subroutine (read_bdf) used to input the BDF data into the data structures. It was necessary to modify read_bdf to accept input from either a file

or a text buffer associated with the Basic Editor. The four editing operations could then be handled through the Basic Editor code. This would be done by putting the appropriate data entry cards in the text buffer and then calling read_bdf. In this way, the user can create new components and modify or copy existing components. The deletion of components is accomplished by deleting all the entries of an existing component and calling read_bdf. The read_bdf subroutine detects no text in the buffer and frees up the arrays associated with that component and updates the counters.

Basic Editor GUI Design

Given the data structures for the BDF and the implementation of the basic editing functions, the next step was to come up with a GUI design for the Basic Editor. After consultations with my thesis sponsors and selected VISAGE users, it was determined that the most desirable features for the GUI would be:

- 1. A simple method of editing components and elements
- 2. A simple method to create new BDF format cards
- 3. A previewing capability

The first feature was readily taken care of by using an editable scrolled text window widget. Use of this widget allows users to directly edit the elements in one or more components. The widget also provides an internal text buffer that can be accessed by the **read_bdf** subroutine. Another benefit is that the widget provides users with the capability to move or copy text inside its boundaries, making it easy to copy or reorder card entries in a component.

It was determined that the easiest way to implement the second feature would be to create a template mechanism. This template would allow the user to fill in the blanks to create any BDF format card. The design of the template was taken from the BDF card format pages found in the FASTGEN 4.1 User's Manual and the VISAGE 2.2 User's Manual, so as to present users with a familiar format for creating cards.

Implementing the previewing feature required the ability to evaluate the data from the Basic Editor without adding it to the target description. The actual target description geometry is created by two subroutines; read bdf and build geom. The read bdf subroutine inserts BDF data into the BDF data structures and the build geom subroutine creates the target description based on the contents of the BDF data structures. To preview components without prematurely adding them to the target description, it was necessary to duplicate the read bdf and build geom subroutines and the BDF data structures. The preview read and preview geom subroutines duplicate the capabilities of the read bdf and build geom subroutines, but keep the data in structures separate from TGheader and TGdata and only access data from the Basic Editor. Therefore, when the Preview button is activated, the preview read and preview geom subroutines are called and the new geometry is displayed along with the current target description. If the component being previewed already exists, then the target description version is made invisible and the Basic Editor version is displayed instead. The previewed geometry is also displayed with black polygonal faces and red edges to distinguish it from the rest of the target description. Figure 7 shows an example of the previewing feature.




Figure 7 Basic Editor Preview Capability Example

The Basic Editor consists of the Data Card Editor (DCE) and the Data Viewer (DV). The DCE provides the template capability and the DV provides the direct editing and previewing capabilities. Figure 8 shows the DCE and DV interfaces. The DCE was created using label widgets for the field descriptions, text field widgets for the fill-in sections, a pull-down menu widget to select the BDF card type, radio button widgets to select the Header, New, or Existing components to edit, text field widgets to specify the Group and Component, and push-button widgets to Apply or Cancel changes. The DV was created using a scrolled text window widget for the component data, push-button widgets for the Delete (highlighted selection), Delete All (entire component), Undo Delete, and Preview functions, and push-button widgets for the OK, Apply, Reset, and Cancel functions. The functions of all the DCE and DV interface widgets are described in Section 2.9 of the VISAGE 2.2 User's Manual in Appendix D.




Figure 8 DCE and DV Interfaces

Advanced Editor

The same three steps used in creating the basic editor were followed in adding advanced editing features to VISAGE.

Advanced Editor Features

Six advanced editing features for groups and components were identified as needed:

- 1. rotation
- 2. scaling
- 3. translation

- 4. mirroring
- 5. copying
- 6. deletion

These six features provide all the basic functionality needed for the Advanced Editor. Each function can be applied singly or in combinations (except deletion) to groups or components of a target description.

Advanced Editor Function Implementation

The implementation of the copy and deletion features was made easier by the VISAGE BDF data structures. The data structures allow the copy function to be a simple matter of array duplication. The user selects the source component(s) to be copied and the destination component(s) and the source arrays are copied into the destination arrays. The copy function will only be performed if the number of destination components matches the number of source components. If a destination component already exists or a source component does not exist, the copy operation will skip that component and continue. Since the basic editor can only delete one component at a time, the deletion function is also provided in the Advanced Editor to allow users to delete ranges of components or even entire groups. The data structures make the deletion function a simple matter of freeing up the dynamic arrays associated with the deleted components and resetting the array counters to zero.

HOOPS provides complete matrix manipulation routines as part of its geometry manipulation capabilities. Using these matrix operations allows a custom transformation matrix to be assembled from the values specified in the Advanced Editor. The user can create a transformation matrix by specifying the values for any combination of the rotation, scaling, translation, and mirroring functions. The limitations are that the functions can only be used once in a transformation and that they are applied in the following order:

rotation, scaling, translation, and mirroring. Also the user must specify a reference point for the rotation and scaling operations, otherwise the origin (0,0,0) will be used by default.

Advanced Editor GUI Design

It was determined that the most desirable features for the GUI would be:

- 1. A simple method of applying the six advanced editing features
- 2. A previewing capability

Since the method of applying the six features was determined in the implementation phase, the next step was to design the appropriate interface elements for each feature. The design of the GUI consists of six parts:

- 1. Group and Component range
- 2. Reference Point
- 3. Rotate/Scale/Translate operations
- 4. Mirror/Copy operations
- 5. Delete and Preview operations
- 6. OK/Apply/Reset/Cancel functions

The input interface for the Group and Component range was implemented using text widgets (also referred to as type-ins). The Reference Point input interface was implemented using text widgets for the X, Y, and Z coordinates. The Rotate, Scale, Translate, Mirror, and Copy operations all need to be independently selectable, so each is equipped with a toggle button widget for activation. If the toggle button is not activated, editing of the operation interface is disabled and the operation will not be performed. The Rotate, Scale, and Translate interfaces are implemented using text widgets. The Rotate interface requires Roll, Pitch, and Yaw inputs. The Scale and Translate interfaces require

X-axis, Y-axis, and Z-axis inputs. The Mirror and Copy operations are linked because the Mirror operation must create a new component for the mirrored copy. The Copy function can be performed by itself. The Mirror/Copy interface is composed of three toggle buttons that are used to indicate which coordinate planes (YZ, ZX, or XY) around which to mirror the component(s). The YZ, ZX, and XY planes correspond to the X, Y, and Z axes, respectively. The Copy interface is implemented using text widgets and is a duplicate of the Group and Component range input interface. Push-button widgets are used for the Delete, Preview, OK, Apply, Reset, and Cancel functions. The functions of all the Advanced Editor interface widgets are described in Section 2.10 of the VISAGE 2.2 *User's Manual* in Appendix D. Figure 9 shows the GUI design of the Advanced Editor.




Figure 9 Advanced Editor GUI Design

Implementing the previewing feature in the Advanced Editor was much simpler than in the Basic Editor. Since the geometry is already present, it was only necessary to copy the appropriate components into a temporary segment and apply the specified transformations. The previewed geometry is displayed with black polygonal faces and red edges to distinguish it from the rest of the target description. Also, the original components are made invisible to avoid conflicts or confusion. When the user is finished previewing, the temporary segment is removed and the original components are restored. Figure 10 shows an example of the Advanced Editor preview capability.




Figure 10 Advanced Editor Preview Capability

Fault Tree Analysis Background

Fault Tree Analysis (FTA) is a fairly recent analysis approach. It was developed in 1961 by Bell Telephone Laboratories to evaluate the Minuteman Launch Control System and was presented to the public in 1965 in Seattle [5:29]. FTA relies on deductive reasoning and was developed as an alternative to tabular Failure Modes and Effects Analysis (FMEA) and its inductive approach. FMEA is a "bottom-up" technique where all

subsystem. Put more simply, a failure of a component is assumed and all the possible consequences of that failure are mapped out in the FMEA table. FTA takes a "top-down" approach, starting with a failure event (fault) and branching out to the preceding events that caused the fault. The relations between these faults are described by Boolean logic equations.

The fault tree is a graphical representation of the Boolean equation of the failure events. A fault tree consists of elements arranged in serial and/or parallel fashion. The serial and parallel arrangements are equivalent to the Boolean OR and AND operations, respectively. In a simple serial arrangement, at least one element must fail for the entire construct to fail (Figure 11a.). In a simple parallel arrangement, one element in each path must fail for the entire construct to fail (Figure 11b.). A hybrid arrangement, containing both serial and parallel constructs, will fail according to the combined effect of all the constructs (Figures 11c).




Figure 11 Fault Tree Boolean Logic Operations

The usual graphical representation of a fault tree is a block diagram as seen in Figures 11a-c. An advantage of this is that the relationships between elements are readily seen. A disadvantage is that, for large fault trees, the representation may not be completely

displayed on a computer screen and may take many pages to print. Another drawback is that Motif currently does not have a standard widget for displaying data in a tree format. Therefore, it was necessary to determine a display format capable of being represented by combinations of low-level Motif widgets while still adequately conveying the tree-like nature of the data. These problems are addressed by the VISAGE fault tree display features.

Fault Tree Data Display

To display the fault tree data, four requirements must be taken into account:

- 1. The display must be as intuitive as possible.
- 2. The output should be as compact as possible.
- 3. The display must be built using standard Motif widgets.
- 4. The display must be capable of interacting with the target description.

To simply fulfill these requirements, an outline display format was selected. The outline format is basically a row-column matrix. Each row contains only a single entry and the column position indicates the level of the entry in the tree. The organization of the entries in the outline comes from a depth-first traversal of the fault tree the outline represents.

Intuitive

Tree diagrams are easy to interpret because they present the hierarchical and relational aspects of data sets in a simple format. In a tree diagram it easy to see the relationships between elements and how they combine to form larger entities. A tree diagram starts at a root node and branches out into lower levels. Each level down represents a greater degree of detail. The outline format represents this data in a similar fashion, except that each branch is listed down to

its end (or leaf) nodes, as in a depth-first traversal of the tree. A breadth-first traversal could have been used to provide the outline entries, but the relationships between the various levels would have been less intuitive. Figure 12 shows an example fault tree and Tables 2-3 show examples of depth-first and breadth-first tree traversal output. The Boolean operation associated with each entry is listed beside the entry name in the tables.




Figure 12 Example Fault Tree

	-		
ABCDEF01			
ABCDEF0		<and></and>	
ABC0		<and:< td=""><td>></td></and:<>	>
	A 0		<or></or>
	В0		<or></or>
	C0		<or></or>
DEF0		<and:< td=""><td>></td></and:<>	>
	D0		<and></and>
	ΕO		<and></and>
	FO		<and></and>
ABCDEF1		<and></and>	
ABC1		<and:< td=""><td>></td></and:<>	>
	A1		<or></or>
	В1		<or></or>
	C1		<or></or>
DEF1		<and:< td=""><td>></td></and:<>	>
	D1		<and></and>
	E1		<and></and>
	F1		<and></and>

Table 2 Depth-first Tree Traversal Output

ABCDEF01			
ABCDEF0		<and></and>	
ABCDEF1		<and></and>	
ABC0		<and></and>	
DEF0		<and></and>	
ABC1		<and></and>	
DEF1		<and></and>	
	A0	<or></or>	
	D0	<and< td=""><td>></td></and<>	>
	ΕO	<and< td=""><td>></td></and<>	>
	F0	<and< td=""><td>></td></and<>	>
	A1	<or></or>	
	D1	<and:< td=""><td>></td></and:<>	>
	E1	<and< td=""><td>></td></and<>	>
	F1	<and:< td=""><td>></td></and:<>	>
	В0	<or></or>	
	B1	<or></or>	
	CO	<or></or>	
	C1	<or></or>	

Table 3 Breadth-first Tree Traversal Output

Compact

While a tree format is very intuitive, hardcopy output can become quite large. Hardcopy output of large tree diagrams is also limited by current printer technology. Currently, large tree diagrams must either be printed using large pen or electrostatic plotters or be printed out in strips on line printers and assembled by hand. Miniaturization is possible, but can result in an unacceptable loss of detail. The outline format solves this problem because the output consists of lines of text. This allows the user to output the diagram on almost any printer.

Standard Motif Widgets

The requirement for building the display with standard Motif widgets was an issue of portability. Standard Motif widgets were needed to be able to guarantee that the interface would work across all supported platforms. Creating a

custom widget to display tree diagrams would have increased the potential for problems in the future. Changes in Motif or the platform operating systems could have potentially rendered the widget inoperative or faulty. By using standard Motif widgets, compliance and interoperability was assured across all supported platforms.

Interaction

The last requirement was that the interface be able to interact with the target description. This was needed to allow the user to view the relationships between the components listed in the tree data, as well as with the rest of the target description.

Fault Tree Data Format

The fault tree data format is the implementation of the outline format. The data format has a hierarchical nature as a result of the outline format's basis in the depth-first tree traversal. In other words, a data file is composed of several sections, each one representing a pass of the depth-first tree traversal algorithm. This also results in a strict ordering of the data format that allows the fault tree to be constructed as a data file is input. Basically, the format consists of five conceptual levels:

- 1. Set Level
- 2. Function Level
- 3. System Level
- 4. Subsystem Level
- 5. Component Level

Each level represents a corresponding part of a fault tree. In order to accommodate fault trees more than five levels deep, the Subsystem level is recursive. For

very shallow trees, the System and Subsystem levels can be omitted. The following paragraphs explain the function of each level. A complete description of the data cards implementing each level can be found in Section 3.5 of the VISAGE 2.2 User's Manual in Appendix D.

Set Level

The Set Level consists of one or more sets specified by FTSET cards. The FTSET card allows the user to specify a name for the set and how many functions it contains. Each set represents the top level of a particular tree. Generally, there will only be one set (or tree) per input file, but there is no limitation on the number of sets.

Function Level

The Function Level consists of a number of functions specified by FTFUNC cards. The FTFUNC card allows the user to specify a name for the function, how many systems it contains, what Boolean operation links the functions, an optional failure field that specifies the number of failures needed for a fault out of the total elements in an AND operation, and a color identification number for highlighting purposes. Each function represents the top level of a particular function being modeled in the tree.

System Level

The System Level consists of a number of systems specified by FTSYS cards. The FTSYS card allows the user to specify a name for the system, how many subsystems it contains, what Boolean operation links the systems, and an optional failure field that specifies the number of failures needed for a fault out of the total elements in an AND operation.

Subsystem Level

The Subsystem Level consists of a number of subsystems specified by FTSUB cards. The FTSUB card allows the user to specify a name for the subsystem, how many subsystems it contains, what Boolean operation links the subsystems, and an optional failure field that specifies the number of failures needed for a fault out of the total elements in an AND operation. The FTSUB card is unique in that it is the only card that can have other cards of the same type under it, i.e., the FTSUB cards can be nested several layers deep, while the FTSET, FTFUNC, and FTSYS cards can only appear on their respective levels.

Component Level

The Component Level consists of a number of components specified by FTCOMP and \$CNAME cards. The FTCOMP card allows the user to specify a name for the component, how many target description components it contains, and what Boolean operation links the components. The \$CNAME card allows the user to specify the target description group and component numbers, the P(K) table identification number, the kill type, and a 40-character text description of the component. The FTCOMP card is really a special case of the FTSUB card and is used to identify the ends (or leaf nodes) of a particular branch of the tree. These leaf nodes are designated by \$CNAME cards. An FTCOMP card always precedes one or more \$CNAME cards and may take the place of the FTSUB card in branches where the FTSUB card would be redundant.

Fault Tree Data Viewer (FTDV) GUI Design

The dynamic nature of the construction of the FTDV is a unique feature in VISAGE. Each time a fault tree data file is read in, the FTDV must create a whole new set

of push-buttons. The rest of the interfaces in VISAGE are all created at program start-up and are hidden when not being used.

The design of the FTDV was pre-determined by the outline format. Since the outline format consists of text entries and the entries must have the capability to interact with the target description geometry, push-buttons were considered the best choice of widgets for the interface. Push-buttons can display text and, through their activation callbacks, can be used to interact with the geometry. A scrolled window widget was selected to contain the push-button entries, for cases when the fault tree is larger than the viewer display area. A push-button was also used for the Reset Display function, which resets any highlighted geometry to its original state.

Given the outline format and the selected Motif widgets, the next step was to implement a representation of the outline format in the FTDV GUI. Each entry in the format is represented by a push-button. The appearance of each push-button is determined by the type of outline entry it represents. The color of the entry indicates the associated Boolean operation. Red indicates an AND operation, blue indicates an OR operation, and black indicates no associated operation.

All push-buttons are created the same height. This allows the coordinate position of the push-buttons to be used as an index into the fault tree data structure. When a push-button is selected, an X Window utility function (XGetWindowAttributes) provides the Y coordinate of the push-button. This is divided by the push-button width and the resulting quotient is the index of the corresponding entry in the fault tree data structure array. The fault tree data structure is described in the next section.

In the outline format, each row may contain only one entry, which is assigned a width based on its type. All outline entries are of equal width except those representing the \$CNAME cards. The \$CNAME push-buttons must be able to display the Group,

Component, and 40-character description of the entry. The FTFUNC, FTSYS, and FTSUB entry push-buttons must have room to display the Name of the entry and, optionally, the failure count described in the Fault Tree Data Format section. The FTSET and FTCOMP entry push-buttons must have room to display the Name of the entry. For simplicity and readability, it was decided to make the push-buttons for the FTSET, FTFUNC, FTSYS, FTSUB, and FTCOMP all the same width. The \$CNAME entry push-buttons were made five times wider to be able to display the larger amount of information.

Figure 13 shows the Fault Tree Data Viewer with a simple fault tree example and Figure 14 shows the corresponding target description. In Figure 13, the white outline around the red entry at the upper left indicates that the geometry associated with that part of the fault tree is currently being highlighted in the Display Window.




Figure 13 Simple Fault Tree Example

The components corresponding to the selected section of the fault tree are colored blue on the aircraft shown in Figure 14.




Figure 14 Target Description for Example Fault Tree

VISAGE Fault Tree Data Structure

The C language data structure for the fault tree data is shown below:

struct FTAData { Widget ewidget; char ename[BUF64], esegment[BUF256]; } *FTADVentry;

As seen above, the data structure array for the fault tree data is composed of three parts:

- 1. The widget variable name
- 2. The fault tree output text string
- 3. The segment name variable

The widget variable name is assigned when a push-button is created for a fault tree entry. This variable name is needed when adding the activation callback to the push-

button. When a new Fault Tree Data File (FDF) is input, the widget variable name is needed to destroy the push-button, so the new push-buttons can be created in the FTDV.

The fault tree output text string is the text that is written out to the fault tree output file. In the case of the FTSET and FTCOMP entries, the text string is composed of the entry name and the associated Boolean operation. For the FTFUNC, FTSYS, and FTSUB entries, the text string is composed of the entry name, the failure field described previously, and the associated Boolean operation. The \$CNAME entry text string is composed of the Group and Component numbers, the 40-character component description, a P(K) table identification number, and a kill type classification. The fault tree output file is a hardcopy version of the outline format of the fault tree currently being displayed in the FTDV.

The segment name variable holds the name of the HOOPS segment of the current entry. Since only the \$CNAME entries actually reference the target geometry, it was necessary to set up a HOOPS segment sub-tree that would allow non-\$CNAME entry push-buttons to highlight the components associated with the levels below them. The easiest solution for this was to create a segment for each non-\$CNAME entry push-button using the current array index as the segment name. Then, the \$CNAME entries are added at the lowest level of the HOOPS segment tree and, due to the hierarchical inheritance of HOOPS segments, can be highlighted from the upper levels. Figure 15 shows the HOOPS segment names and entry numbers for an example fault tree. The "?plot" string in the segment names is the name of the HOOPS segment that contains the target description geometry. The "?" character in the segment names is a HOOPS convention indicating the inheritance ordering of the segments, similar to UNIX pathnames. The "x_x" strings are a VISAGE convention of using the combined Group and Component numbers as a segment name.




Figure 15 Fault Tree Segment Names and Organization

IV. Enhancement Effort Results

The focus of this thesis was to add editing and fault tree display capabilities to the VISAGE software program. This section discusses the results of those efforts. Since there were no experimental results, this section will comment on the enhancement efforts.

VISAGE

Pros

VISAGE originally provided vulnerability analysts with the ability to visualize FASTGEN-format target descriptions and associated analysis data. It provided these capabilities across several platforms and at no cost to the user, since it is a USAF-developed software package. It provides these capabilities through advanced graphics and a relatively simple Motif-based GUI.

Cons

One of the drawbacks to the VISAGE program is that the graphics performance is not equal across all platforms. Another is that it is dependent upon a non-industry standard graphics library. In terms of this project, it did not already provide full support for the features that had been chosen to be added.

Structure

The VISAGE program consists of three linked parts:

- 1. The internal data structures and application code.
- The HOOPS graphics elements.
- The Motif-based GUI.

The internal data structures and application code are the basis of the program. The HOOPS graphics elements and Motif-based GUI form the display for VISAGE. In order to allow for potential changes, the program is modularized as much as possible. Therefore, if the program should ever need to be implemented with another graphics library or GUI, the changes should not effect the majority of the application code. This modularization also meant that VISAGE was readily modified to support the needed enhancement features. The separation of the internal data structures, the HOOPS graphics elements, and the Motif-based GUI allowed the enhancements to be implemented without a radical redesign of the program.

Target Description Editing Enhancements

In terms of the VISAGE program, the addition of the target description editing capabilities was highly successful. All features required by the project sponsors were added to VISAGE without disruption of the program's basic integrity. By substituting a new internal data structure for storing BDF data, it was possible to easily add the editing features. This data structure change provided an efficient method of storing the target description data, while only requiring slight modifications to the data input and geometry creation subroutines. Use of Motif for the GUI also allowed for the easy addition of interface elements for the basic and advanced editing features. The transformation matrix creation and manipulation capabilities of the HOOPS Graphics Library also provided needed support for the advanced editing features.

Prior to this project, vulnerability analysts had no programs capable of editing a native FASTGEN target description. With the model editing enhancements successfully added to VISAGE during this project, vulnerability analysts now have an editing capability that does not require that data sets be translated into a CAD package data format. The

difficulty in adding the editing capabilities was one of balance. A balance was needed between the analysts' requirements and the complexity of the programming effort. On one hand, the analysts needed certain minimum capabilities to effectively correct target descriptions. On the other hand, the editing interface needed to be simple to avoid straying into areas already adequately covered by existing CAD software packages.

A combination of a template interface and a text editor were decided upon to provide the basic editing capabilities. This avoided the effort of trying to duplicate mouse-based CAD features while simply providing the necessary functionality. The target description elements can be directly edited in the Data Viewer (text editor) and users can also easily create new elements with the Data Card Editor (template interface). Through the combination of these two interface elements, users can create, edit, copy, and/or delete components and elements of a target description.

The analysts also required some advanced editing features to make target description correction easier. The analysts wanted to be able to rotate, scale, translate, mirror, copy, and/or delete parts of a target description. These features are easily applied at the Component and Group levels of a target description. This allows analysts to easily manipulate large sections of target descriptions at one time.

With the addition of the Basic and Advanced Editors to VISAGE, analysts are provided complete target editing description capabilities. Without these features the analysts must edit the target descriptions by hand or translate them into a format usable by some CAD package. Editing the target descriptions by hand can be an unpleasant and daunting task. Most target description files are tens or hundreds of thousands of lines long and often are inadequately documented. Correcting the larger files by hand could take several man-weeks or man-months of effort. The alternative of editing the target description with a CAD package is not a much better choice. This requires not only

translating the target description into another format, but also translating it back into the FASTGEN format, thus doubling the possibility of errors being introduced into the data.

The editing features have been tested by three different groups working on two different projects and have been found to satisfy the vulnerability analysts' needs. The VISAGE editing capabilities have successfully been used to correct defects in the F/A-18 and B-1B FASTGEN target descriptions. Use of the VISAGE editing capabilities on other aircraft target descriptions is planned. The editing capabilities have been reviewed by the sponsors of this project, Hugh Griffis of ASC/XRESV and Marty Lentz of WL/FIVS, and have been pronounced "excellent".

Fault Tree Data Display Enhancement

The other purpose of this thesis was to provide vulnerability analysts with the capability to view fault tree data along with a corresponding FASTGEN target description. In the course of my research into the topic of Fault Tree Analysis (FTA), I found ample support for FTA as an important facet of vulnerability analysis, but very few software tools. This was amazing considering that FTA has been around since 1961. FTA is also widely used for safety analysis studies, but, again, very few software tools appear to be available. Because of this lack, the VISAGE fault tree data display capability represents an important advance in vulnerability analysis.

In terms of the VISAGE program, the addition of the fault tree data display capabilities was more of a study in GUI design than anything else. Since the fault tree data was not integral to the target description, it was only necessary to take advantage of "hooks" into the target description geometry provided by the hierarchical structure of HOOPS. Given these links to the target description, the issue of how to best present the fault tree data was the next challenge. The design of the interface was then just a matter of

providing an efficient solution based on the sponsors' requirements and the features of the standard Motif GUI elements.

To satisfy the survivability analysts' requirements, the fault tree data display needed to be intuitive, compact, composed of standard Motif widgets, and able to interact with target descriptions. The use of the outline format allowed the display to be intuitive and compact. Creating the display with Motif push-button widgets provided the standard and interactive characteristics. The fault tree data display interface meshed well with the VISAGE fault tree data structure. X Window and Motif utility functions also allowed the interface and the data structure to be easily linked together.

Having decided upon the outline format for the fault tree data display and how to implement the Motif interface, the next task was to create a fault tree data file format. COVART currently has support for the input of fault tree data, but the format is complex and the data entries are spread across multiple input files. This makes it difficult not only to create a COVART fault tree data file, but also to input the data into programs such as VISAGE. Therefore, it was decided to create a new fault tree data format; one that could be produced by COVART.

Fault tree data is organized hierarchically. A fault tree data set represents an aircraft in terms of functions, systems, subsystems, and components. Each of these corresponds to different levels in a fault tree. Representing these levels more simply is the purpose of the outline format. The VISAGE fault tree data format is the result of the conversion of the fault tree representation to the outline representation. This conversion is accomplished through the depth-first tree traversal algorithm. This algorithm converts the levels of the fault tree format into the corresponding levels in the outline format. These levels are then represented by the entries in the VISAGE fault tree data format.

The VISAGE fault tree format has been submitted to the COVART development team and is expected to be incorporated into the next release of the product. The format is also being used by personnel in ASC/XRESV for documentation in support of current vulnerability studies. The VISAGE fault tree data format and the Fault Tree Data Viewer have been examined and approved by the sponsors of this project. The sponsors described the VISAGE fault tree capabilities as being an impressive and important new tool for vulnerability analysts.

V. Conclusions and Recommendations

Strengths and Limitations

Target Description Editing

The editing capabilities added to VISAGE during this project have four major strengths:

- The Basic and Advanced editors allow vulnerability analysts to visualize and verify FASTGEN target descriptions with one software package.
- 2. The Basic Editor provides users with easy access to all Component and Element data in a target description.
- 3. The Advanced Editor provides users with the ability to easily create complex components.
- 4. The editors allow users to preview any changes before they are applied to the target description.

The editors also have two major limitations:

- 1. The Basic Editor currently only supports the FASTGEN BDF format.
- Transformations in the Advanced Editor can only be applied in a specified sequence and individual transformations can only be used once in each application.

Fault Tree Data Display

The fault tree data display capabilities added to VISAGE have four major strengths:

- 1. The Fault Tree Data Viewer provides users with an intuitive and compact interface for viewing fault tree data in an outline format.
- 2. The FTDV allows users to view the fault tree data in conjunction with the rest of a target description.

- 3. The VISAGE fault tree input data format is well-structured, yet flexible.
- 4. The VISAGE fault tree output data format provides users with a concise listing of fault tree data sets.

The fault tree data display capabilities have two major limitations:

- 1. Fault tree data sets cannot be created or edited with the FTDV interface
- 2. Due to CRT screen sizes, the FTDV and the VISAGE Display Window have some overlap.

Practical Implications

The added editing capabilities mean that survivability analysts now have a method of verifying and correcting FASTGEN target descriptions without having to use several different software packages or translators. The editing capabilities are also tailored to the FASTGEN data format, so users do not have to be concerned about finding appropriate and compatible software tools.

The fault tree data display capabilities give vulnerability analysts a much-needed tool for understanding vulnerability study results. Fault trees focus on the critical parts of an aircraft, and being able to see those parts in relation to the rest of the aircraft can be extremely useful. The flexibility of the fault tree data input format and the display interface also allow for the display of non-fault tree data sets. A user can create data files that delineate an aircraft's major and minor systems and subsystems. These files can serve to illustrate design or safety issues, or even be used as documentation for reports.

Recommendations

The VISAGE program now provides survivability analysts with several important tools for conducting ballistic vulnerability analyses. To further enhance the effectiveness of VISAGE, the following items are recommended for further work:

- 1. The editing and fault tree limitations listed above should be addressed.
- In order to improve graphics performance while maintaining portability, the feasibility of transitioning the underlying graphics system of VISAGE from the HOOPS graphics library to the OpenGL graphics library should be determined.
- 3. Since VISAGE is based on earlier coding efforts by the author, a more thorough effort to bring the code up to current Software Engineering standards could be undertaken.
- 4. The capability to display Line-Of-Sight data sets should be incorporated into VISAGE.
- 5. To improve model appearance, the mesh resolution of the cone and sphere geometry elements should be dynamically determined according to the relative size of the elements.

Conclusion

The VISAGE software package represents an important link in the ballistic vulnerability analysis process. By combining the properties of CAD and visualization packages, VISAGE allows survivability analysts to bridge the gap between the generation of target descriptions and the generation of analysis data. VISAGE serves as a feedback mechanism by allowing analysts to view target descriptions and analysis data simultaneously. VISAGE also makes a significant contribution to vulnerability analysis by providing one of the few available tools for displaying fault tree data. With the conclusion of this project, VISAGE now stands as a significant achievement in the improvement of the ballistic vulnerability process.

Appendix A: Computer Code Routine List (By File)

	vis_display.c		
void	UpdateDisplay (mpick)		
void	ResetView ()		
void	SetBusyPointer (sbpflag)		
void	SetGeomDispOps ()		
void	SetCuttingPlanes ()		
void	PlayAnimation (animcont)		
void	SelectView (symanflag, tmindex)		
void	time_style_segment (tmindex)		
void	SelectGeom(segment, key, geomtype)		
void	Mouse (button)		
void	mouse_cam (xwin_next, ywin_next)		
Bool	TestEvent (display, event, type)		
int	Keyboard (keysym, key)		
	vis_misc.c		
void	change_key (long origkey, long elemID, int elemType, char *Scope)		
void	PrintHardcopy ()		
void	selcolor (segname, grpnum)		
void	selcontcol (segname,csnum,scolor,gtype,gpattern)		
void	plotinfo (secnum,cmpnum,eidnum,eidtypind)		
	SED void build_boxview_seg ()		
	SED void box_view ()		
	SED void rubber_box (x0,y0,x1,y1)		
UNU:	SED void Get_String (context,string)		
int	unpack_key (long key, long *elemID, long *elemType)		
	vis FTA.c		

```
vis rdcontour.c
void
       rdcontour (cfname)
int
       validcdkey ()
                             vis rdfastgen.c
void
       rdfastgen (dfile)
void
       build geom (group, comp, Eval Comp)
void
       build cylcone (targetseg, r1,r2,th1,th2,e1flag,e2flag)
void
       build sphere (targetseg, cntrpt, r1, th)
void
       camcalc ()
void
       change coords (grpnum,compnum,segname)
void
       init labels ()
void
       insert elemlabels (grpnum, compnum, current)
void
       maxel err (gnum,cnum,currcard,current)
void
       maxmin(x, y, z)
       seg_setup (segname, eid, chkeid, currsnum, curelcnt)
void
void
       setaxes ()
void
       preview geom (showgeom)
void
       compute transform (tmatrixptr)
void
       copy components (CompGroup,CompFirst,CompLast,
void
       transform components (Group, First, Last, Matrix)
void
       preview_transform (prevOn,Group,First,Last)
void
       delete components (Group, First, Last)
int
       read bdf (DataFile, FromFile)
int
       get points (loopent, curreard, typpnts, current)
int
       validElemData (dkey)
int
       validCompData (dkey)
int
       validHeaderData (dkey)
int
       cardContinued (dkey)
int
       validkey (dkey)
int
       extract line (curros, prevbuffer)
int
```

preview read ()

```
vis rdgrpdef.c
      rdgrpdef (gfname)
void
       validgdkey ()
int
                            vis wininit.c
      wininit ()
void
      colorbar (topseg)
void
void
      def pointer ()
void
      def CB colors ()
void
       def mat colors ()
                            vis wrfastgen.c
      write file (FileType, FileName)
void
Motif interface files
                            visage2.c
main (argc,argv)
                            VISAGE.c
static Widget Uxbuild VISAGE()
Widget create VISAGE()
void postmesg (mesg, printout)
static void activateCB menu1 File open()
static void
            activateCB menul File save()
static void
            activateCB menu1 File saveas()
static void
            activateCB menul File print()
static void
            activateCB menu1 File exit()
            activateCB_menu1_Edit Basic()
static void
static void
            activateCB menu1 Edit Advanced()
            valueChangedCB menul Options IndepScale()
static void
```

```
static void
            valueChangedCB menu1 Options GeomSelOutput()
static void
            valueChangedCB menu1 Options FTCompDisp()
static void
            valueChangedCB menul Options FTOutline()
static void
            activateCB menu1 Help on()
char
      *extract string (cs)
                           viewCtlsbBD.c
static Widget Uxbuild viewCtlsbBD()
Widget create viewCtlsbBD()
ResetViewControls()
ResetGeomControls()
           focusCB viewCtlsbBD()
static void
static void
            activateCB hSurfs b1()
static void
            activateCB hSurfs b2()
static void
            activateCB hSurfs b3()
static void
            valueChangedCB refAxestB()
static void
            valueChangedCB labelELEMtB()
            valueChangedCB labelGRIDtB()
static void
static void
            valueChangedCB colorBartB()
static void
            activateCB zoomOut()
            activateCB zoomIn()
static void
            activateCB selectView()
static void
static void
            activateCB resetView()
static void
            activateCB orthoSlicerpB()
static void
            activateCB geomOpspB()
static void
            activateCB viewType Ortho()
static void
            activateCB viewType Persp()
static void
            valueChangedCB azimuthSc()
static void
            valueChangedCB elevationSc()
            activateCB presetAZEL 0 0()
static void
static void
            activateCB presetAZEL 45 0()
static void
            activateCB presetAZEL 90 0()
static void
            activateCB presetAZEL 135 0()
static void
            activateCB presetAZEL 180 0()
static void
            activateCB presetAZEL 225 0()
static void
            activateCB presetAZEL 270 0()
static void
            activateCB presetAZEL 315 0()
static void
            activateCB presetAZEL 0 45()
static void
            activateCB presetAZEL 45 45()
```

activateCB presetAZEL 90 45()

static void

```
static void
            activateCB presetAZEL 135 45()
static void
            activateCB presetAZEL 180 45()
static void
            activateCB presetAZEL 225 45()
            activateCB presetAZEL 270 45()
static void
static void
            activateCB presetAZEL 315 45()
            activateCB presetAZEL 0 n45()
static void
static void
            activateCB presetAZEL 45 n45()
            activateCB presetAZEL 90 n45()
static void
            activateCB presetAZEL 135 n45()
static void
static void
            activateCB presetAZEL 180 n45()
            activateCB presetAZEL 225 n45()
static void
static void
            activateCB presetAZEL 270 n45()
            activateCB presetAZEL 315 n45()
static void
            activateCB presetAZEL 0 90()
static void
            activateCB presetAZEL 0 n90()
static void
```

geomDispOpsbBD.c

```
static Widget _Uxbuild_geomDispOpsbBD()
Widget create geomDispOpsbBD()
```

```
ResetSelGroups()group, state, action)
```

SetGroupInfo()group)

ResetGeomDispOps ()

setgeomcolwin (gcolor)

static void focusCB_geomDispOpsbBD()

static void activateCB_geomDispOpsOKpB()

static void activateCB_geomDispOpsResetpB()

static void activateCB_geomDispOpsApplypB()

static void activateCB_geomDispOpsCancelpB()

static void valueChangedCB_groupNametF()

static void valueChangedCB_grouptB0()

static void valueChangedCB_grouptB1()

static void valueChangedCB_grouptB2()

static void valueChangedCB_grouptB3()

static void valueChangedCB_grouptB4() static void valueChangedCB grouptB5()

static void valueChangedCB grouptB6()

static void valueChangedCB_grouptB7()

static void valueChangedCB grouptB8()

static void valueChangedCB grouptB9()

static void valueChangedCB_grouptB10()

static void valueChangedCB grouptB11()

```
static void
            valueChangedCB compFirsttF()
static void
            valueChangedCB compLasttF()
            losingFocusCB compLasttF()
static void
static void
            exposeCB geomColorSeldA()
            singleSelectionCB geomColorSelsL()
static void
static void
            activateCB gVisibility b1()
            activateCB gVisibility_b2()
static void
static void
            activateCB gVisibility b3()
            valueChangedCB transparencySc()
static void
            activateCB gShading b1()
static void
static void
            activateCB gShading b2()
static void
            activateCB gShading b3()
            activateCB gShading b4()
static void
```

animationCtlsbBD.c

static Widget _Uxbuild_animationCtlsbBD() Widget create animationCtlsbBD()

ResetAnimControls()

```
static void focusCB animationCtlsbBD()
            activateCB playReversedB1()
static void
            activateCB playForwarddB()
static void
static void
            activateCB resetAnimdB1()
static void
            activateCB playStopdB()
static void
            activateCB tCycle b1()
static void
            activateCB tCycle b2()
            activateCB tCycle b3()
static void
static void
            activateCB stepIncDecaB()
static void
            activateCB stepIncIncaB()
            activateCB stepInctF()
static void
            activateCB currStepDecaB()
static void
            activateCB currStepIncaB()
static void
static void
            activateCB currSteptF()
```

orthoSlicerbBD.c

static Widget _Uxbuild_orthoSlicerbBD()
Widget create_orthoSlicerbBD()

ResetOrthoSlicer()

static void focusCB_orthoSlicerbBD()

```
static void
            valueChangedCB positiveXtB()
            valueChangedCB negativeXtB()
static void
static void
            valueChangedCB positiveYtB()
static void
            valueChangedCB negativeYtB()
            valueChangedCB positiveZtB()
static void
static void
            valueChangedCB negativeZtB()
static void
            valueChangedCB positiveXtF()
static void
            valueChangedCB negativeXtF()
static void
            valueChangedCB positiveYtF()
static void
            valueChangedCB negativeYtF()
static void
            valueChangedCB positiveZtF()
            valueChangedCB negativeZtF()
static void
static void
            activateCB orthoSLicerOKpB()
static void
            activateCB orthoSlicerApplypB()
static void
            activateCB orthoSlicerResetpB()
            activateCB orthoSlicerCancelpB()
static void
```

selectViewbBD.c

static Widget Uxbuild selectViewbBD()

Widget create selectViewbBD()

```
static void
            focusCB selectViewbBD()
            valueChangedCB cameraPosXtF()
static void
static void
            valueChangedCB cameraPosYtF()
            valueChangedCB cameraPosZtF()
static void
static void
            valueChangedCB cameraTarXtF()
static void
            valueChangedCB cameraTarYtF()
static void
            valueChangedCB cameraTarZtF()
static void
            valueChangedCB viewAngleSc()
            activateCB selViewOKpB()
static void
static void
            activateCB selViewResetpB()
static void
            activateCB selViewApplypB()
static void
            activateCB selViewCancelpB()
```

printOpsbBD.c

static Widget Uxbuild printOpsbBD() Widget create printOpsbBD()

SetPOFileType()pofiletype, state) SetPOSize()size, state)

```
SetPOOrientation()orient, state)
SetPOOutput()pooutput, state)
ResetPrintOps ()
```

```
static void
            focusCB printOpsbBD()
            valueChangedCB printPStB()
static void
            valueChangedCB printEPStB()
static void
static void
            valueChangedCB printHPGLtB()
static void
            valueChangedCB printCGMtB()
            valueChangedCB printPICTtB()
static void
            valueChangedCB printAtB()
static void
            valueChangedCB printBtB()
static void
            valueChangedCB printCtB()
static void
static void
            valueChangedCB printDtB()
static void
            valueChangedCB printEtB()
            valueChangedCB printLandtB()
static void
            valueChangedCB printPorttB()
static void
static void
            valueChangedCB printPrintertB()
            valueChangedCB printFiletB()
static void
            valueChangedCB printFiletF()
static void
            valueChangedCB printPrintertF()
static void
static void
            valueChangedCB printNCopytF()
static void
            activateCB printOKpB1()
            activateCB printResetpB()
static void
            activateCB printCancelpB()
static void
```

fileOpenOpsbBD.c

static Widget _Uxbuild_fileOpenOpsbBD()
Widget create fileOpenOpsbBD()

```
ResetReadFileOps (reploption, state)
void
           valueChangedCB openFTOpsBDFtB()
static void
           valueChangedCB openFTOpsCDFtB()
static void
           valueChangedCB openFTOpsGDFtB()
static void
static void
           valueChangedCB openFTOpsFDFtB()
static void
           activateCB openFTOpsReadpB()
           activateCB openFTOpsCancelpB()
static void
           valueChangedCB openFTOpsRAlltB()
static void
           valueChangedCB openFTOpsAddOtB()
static void
           valueChangedCB openFTOpsAddNOtB()
static void
```

helpWindowbBD.c
static Widget _Uxbuild_helpWindowbBD() Widget create_helpWindowbBD()
void SelectHelpFile (whichmsg) static void activateCB_pushButton1()
confirmErroreD.c
static Widget _Uxbuild_confirmErroreD() Widget create_confirmErroreD()
static void cancelCB_confirmErroreD() static void helpCB_confirmErroreD() static void okCallback_confirmErroreD()
confirmExitqD.c
static Widget _Uxbuild_confirmExitqD() Widget create_confirmExitqD()
static void cancelCB_confirmExitqD() static void helpCB_confirmExitqD() static void okCallback_confirmExitqD()
confirmFCLosswD.c
static Widget _Uxbuild_confirmFCLosswD() Widget create_confirmFCLosswD() Widget _UxUxParent)
static void okCallback_confirmFCLosswD()
confirmWarningwD.c
static Widget _Uxbuild_confirmWarningwD() Widget create_confirmWarningwD() Widget _UxUxParent)
static void cancelCB_confirmWarningwD()

```
static void okCallback confirmWarningwD()
                         DisplayWindow.c
static Widget Uxbuild DisplayWindow()
Widget create DisplayWindow()
void setup GL()gl widget) [SGI CONDITIONAL CODE]
void test overlay ()
                        [SGI CONDITIONAL CODE]
     get best visual (display, visual depth, visual type, visual info)
void
static void createCB DisplayWindow()
static void exposeCB DisplayWindow()
static void inputCB DisplayWindow()
static void resizeCB DisplayWindow()
                         openBDFfSBD.c
static Widget _Uxbuild_openBDFfSBD()
Widget create openBDFfSBD()
static void cancelCB openBDFfSBD()
static void helpCB openBDFfSBD()
static void okCallback openBDFfSBD()
                         openCDFfSBD.c
static Widget Uxbuild openCDFfSBD()
Widget create openCDFfSBD()
static void cancelCB openCDFfSBD()
static void helpCB openCDFfSBD()
static void okCallback openCDFfSBD()
                         openFDFfSBD.c
static Widget Uxbuild openFDFfSBD()
Widget create openFDFfSBD()
static void cancelCB openFDFfSBD()
          helpCB openFDFfSBD()
static void
```

```
static void okCallback openFDFfSBD()
                          openGDFfSBD.c
static Widget Uxbuild openGDFfSBD()
Widget create openGDFfSBD()
static void
           cancelCB openGDFfSBD()
           helpCB openGDFfSBD()
static void
static void okCallback openGDFfSBD()
                          viewDCEDatabBD.c
static Widget Uxbuild viewDCEDatabBD()
Widget create viewDCEDatabBD()
     ResetDataViewer ()
void
      SetDataViewer (mode)
void
           focusCB viewDCEDatabBD()
static void
           activateCB_ dvDeleteSelpB()
static void
static void
           activateCB dvDeleteAllpB()
           activateCB dvUndoDeletepB()
static void
           activateCB dvPreviewComppB()
static void
static void
           activateCB sparepB1()
           activateCB sparepB2()
static void
           activateCB sparepB3()
static void
           activateCB sparepB4()
static void
           activateCB sparepB5()
static void
static void
           activateCB sparepB6()
static void
           activateCB viewDCEDataOKpB()
           activateCB viewDCEDataApplypB()
static void
           activateCB viewDCEDataResetpB()
static void
static void
           activateCB viewDCEDataCancelpB()
                          bdfCardsbBD.c
static Widget Uxbuild bdfCardsbBD()
Widget create bdfCardsbBD()
void
     GetCardText ()
     UpdateDataViewer ()
void
```

SetCardType (CardType)

void

- void ResetCardType ()
- static void focusCB bdfCardsbBD()
- static void valueChangedCB textField1()
- static void losingFocusCB textField1()
- static void valueChangedCB textField2()
- static void losingFocusCB textField2()
- static void valueChangedCB textField3()
- static void losingFocusCB textField3()
- static void valueChangedCB_textField4()
- static void losingFocusCB textField4()
- static void valueChangedCB textField5()
- static void losingFocusCB textField5()
- static void valueChangedCB textField6()
- static void losingFocusCB textField6()
- static void valueChangedCB textField7()
- static void losingFocusCB textField7()
- static void valueChangedCB textField8()
- static void losingFocusCB textField8()
- static void valueChangedCB textField9()
- static void losingFocusCB textField9()
- static void valueChangedCB textField10()
- static void losingFocusCB textField10()
- static void valueChangedCB textField11()
- static void losingFocusCB textField11()
- static void valueChangedCB_textField12()
- static void losingFocusCB textField12()
- static void valueChangedCB_textField13()
- static void losingFocusCB_textField13()
- static void valueChangedCB_textField14()
- static void losingFocusCB_textField14()
- static void valueChangedCB_textField15()
- static void losingFocusCB_textField15()
- static void valueChangedCB_textField16()
- static void losingFocusCB_textField16()
- static void valueChangedCB_textField17()
- static void losingFocusCB_textField17()
- static void valueChangedCB_textField18()
- static void losingFocusCB_textField18() static void valueChangedCB textField19()
- static void losingFocusCB textField19()
- static void valueChangedCB textField20()
- static void losingFocusCB_textField20()
- static void activateCB_bdfCardsApplypB()
- static void activateCB_bdfCardsResetpB()

```
static void
            activateCB bdfCards ccone1()
static void
            activateCB bdfCards ccone2()
static void
            activateCB bdfCards chex1()
static void
            activateCB bdfCards chex2()
static void
            activateCB bdfCards cline()
static void
            activateCB bdfCards cquad()
static void
            activateCB bdfCards csphere()
static void
            activateCB bdfCards ctri()
static void
            activateCB bdfCards grid()
static void
            activateCB bdfCards hole()
static void
            activateCB bdfCards section()
            activateCB bdfCards vehicle()
static void
static void
            activateCB bdfCards wall()
static void
            activateCB bdfCards comment()
static void
            activateCB bdfCards name()
static void
            activateCB bdfCards cordae()
static void
            activateCB bdfCards point()
static void
            activateCB bdfCards unitgbl()
static void
            activateCB bdfCards unitlcl()
static void
            activateCB cdfCards comment()
static void
            activateCB gdfCards comment()
static void
            activateCB caseCards comment()
static void
            valueChangedCB dceGrouptF()
static void
            activateCB dceComptF()
static void
            valueChangedCB dceComptF()
static void
            valueChangedCB dceEditNewtB()
            valueChangedCB dceEditExistingtB()
static void
static void
            valueChangedCB dceEditHeadertB()
```

advancedEditorbBD.c

static Widget _Uxbuild_advancedEditorbBD() Widget create advancedEditorbBD()

```
ResetAdvancedEditor()
```

```
void ApplyTransforms ()
void SetScaleVal (svaltext)
```

static void focusCB_advancedEditorbBD()

static void valueChangedCB_advEdGrouptF()

static void valueChangedCB_advEdCompFirsttF()

static void losingFocusCB_advEdCompFirsttF()

static void valueChangedCB_advEdCompLasttF()

static void losingFocusCB_advEdCompLasttF()

```
static void
            valueChangedCB rotatetB()
static void
            valueChangedCB rotateXtF()
static void
            valueChangedCB rotateYtF()
static void
            valueChangedCB rotateZtF()
            valueChangedCB scaletB()
static void
static void
            valueChangedCB scaleXtF()
static void
            losingFocusCB scaleXtF()
static void
            valueChangedCB scaleYtF()
            losingFocusCB scaleYtF()
static void
static void
            valueChangedCB scaleZtF()
static void
            losingFocusCB scaleZtF()
            valueChangedCB translatetB()
static void
static void
            valueChangedCB translateXtF()
static void
            valueChangedCB translateYtF()
            valueChangedCB translateZtF()
static void
static void
            valueChangedCB refPointXtF()
            valueChangedCB refPointYtF()
static void
static void
            valueChangedCB refPointZtF()
            valueChangedCB mirrortB()
static void
static void
            valueChangedCB yzPlanetB()
            valueChangedCB zxPlanetB()
static void
static void
            valueChangedCB xyPlanetB()
static void
            valueChangedCB copytB()
static void
            valueChangedCB copyGrouptF()
static void
            valueChangedCB copyFirsttF()
static void
            valueChangedCB copyLasttF()
static void
            losingFocusCB copyLasttF()
static void
            activateCB advancedEditorDeletepB()
static void
            activateCB advancedEditorPreviewpB()
static void
            activateCB advancedEditorOKpB()
static void
            activateCB advancedEditorApplypB()
static void
            activateCB advancedEditorResetpB()
static void
            activateCB advancedEditorCancelpB()
```

FTADataViewerbBD.c

```
static Widget _Uxbuild_FTADataViewerbBD()
Widget create_FTADataViewerbBD()

void change_seg_attrib (segname, attrib, pattrib)
void activateCB_FTADVentries (wgt, cd, cb)
void AddFTADVEntry (ftaindex, xpos, ypos, etype, eqcolor)
static void focusCB_FTADataViewerbBD()
```

static void createCB_FTADVform()
static void activateCB_FTADVClosepB()

writeBDFfSBD.c

static Widget _Uxbuild_writeBDFfSBD()

Widget create_writeBDFfSBD()

static void cancelCB_writeBDFfSBD()
static void helpCB_writeBDFfSBD()
static void okCallback writeBDFfSBD()

Appendix B: Computer Code Outline

This outline lists the routines as they are diagramed by the CodeCenter software design tool. Each tab stop indicates the next call level of the program. Unused and architecture-dependent routines have been annotated. All routines containing the letters "Ux" are either UIM/X utility routines or are part of the interface construction. Global routines and expurgated routines have been marked according to the legend.

```
Legend:
             : global routine
       +++
             : routine contains calls to other routines which have been previously shown
int main()
       void *create VISAGE()
              void * Uxbuild VISAGE()
                    void activateCB menu1 File open()
                           UxPopupInterface(fileOpenOpsbBD)
                    void activateCB menu1 File save()
                           void write file()
                    void activateCB menu1 File saveAs()
                           UxPopupInterface(write BDFfSBD)
                    void activateCB menu1 File print()
                           UxPopupInterface(printOpsbBD)
                    void activateCB menu1 File exit()
                           UxPopupInterface(confirmExitqD)
                    void activateCB menu1 Edit Basic()
                           UxPopupInterface(bdfCardsbBD)
                                  UxPopupInterface(viewDCEDatabBD)
                    void activateCB menul Edit Advanced()
                           UxPopupInterface(advancedEditorbBD)
                    void valueChangedCB menu1 Options IndepScale()
                           ==> void postmesg()
                    void valueChangedCB menu1 Options GeomSelOutput()
                           ==> void postmesg()
                    void valueChangedCB menu1 Options FTCompDisp()
                           ==> void postmesg()
                    void valueChangedCB menul Options FTOutline()
                           ==> void postmesg()
                    void activateCB menu1 Help on()
                           void SelectHelpFile()
```

```
void *create write BDFfSBD()
       void * Uxbuild writeBDFfSBD()
             void cancelCB writeBDFfSBD()
             void helpCB writeBDFfSBD()
                    ==> void SelectHelpFile()
             void okCallback writeBDFfSBD()
                    ==> void write file()
                    char *extract string()
void *create FTADataViewerbBD()
      void * Uxbuild FTADataViewerbBD()
             void focusCB FTADataViewerbBD()
             void createCB FTADVform()
             void activateCB FTADVClosepB()
                    void change seg attrib()
                                                ***RECURSIVE***
                    void Update Display()
                           => void SetBusyPointer()
                           ==> void ResetView()
                    ==> void SetBusyPointer()
void *create animationCtlsbBD()
      void * Uxbuild animationCtlsbBD()
             void focusCB animationCtlsbBD()
             void activateCB playReversedB1()
                    void PlayAnimation()
                           void SelectView()
                                  => void Update Display()
                           void time style segment()
                                  void selcontcol()
                                         void selcolor()
                                  => void Update Display()
                           int TestEvent()
             void activateCB playForwarddB()
                    ==> void PlayAnimation()
             void activateCB resetAnimdB1()
                    int ResetAnimControls()
                           ==> void Update Display()
                    ==> void PlayAnimation()
             void activateCB playStopdB()
                    ==> void Update Display()
             void activateCB tCycle b1()
             void activateCB tCycle b2()
             void activateCB tCycle b3()
```

```
void activateCB stepIncDecaB()
             void activateCB stepIncIncaB()
             void activateCB stepInctF()
                    ==> void postmesg()
             void activateCB currStepDecaB()
                    ==> void PlayAnimation()
             void activateCB currStepIncaB()
                    ==> void PlayAnimation()
             void activateCB currSteptF()
                    => void PlayAnimation()
                    ==> int ResetAnimControls()
                           => void Update Display()
void *create confirmWarningwD()
                                 **CURRENTLY UNUSED**
void *create confirmExitqD()
      void * Uxbuild confirmExitqD()
             void cancelCB confirmExitqD()
                    UxPopdownInterface(confirmExitqD)
             void helpCB confirmExitqD()
             void okCallback confirmExitqD()
                    UxPopdownInterface(confirmExitgD)
                    exit()
void *create helpWindowbBD()
      void * Uxbuild helpWindowbBD()
             void activateCB pushButton1()
                    UxPopdownInterface(helpWindowbBD)
void *create selectViewbBD()
      void * Uxbuild selectViewbBD()
             void focusCB selectViewbBD()
             void valueChangedCB cameraPosX()
             void valueChangedCB cameraPosY()
             void valueChangedCB cameraPosZ()
             void valueChangedCB cameraTarX()
             void valueChangedCB cameraTarY()
             void valueChangedCB cameraTarZ()
             void valueChangedCB viewAngleS()
             void activateCB selViewOKpB()
                    UxPopdownInterface(selViewOKpB)
                    ==> void SelectView()
             void activateCB selViewResetpB()
                    ==> int ResetSelectView()
```

```
void activateCB selViewApplypB()
                    => void SelectView()
             void activateCB selViewCancelpB()
                    UxPopdownInterface(selViewOKpB)
                    ==> int ResetSelectView()
void *create DisplayWindow()
      void * Uxbuild DisplayWindow()
             void setup GL()
                                 **SGI CONDITIONAL CODE**
             void test overlay()
                                 **SGI CONDITIONAL CODE**
             void get best visual()
             void createCB DisplayWindow()
             void exposeCB DisplayWindow()
             void inputCB DisplayWindow()
             void resizeCB DisplayWindow()
void *create advancedEditorbBD()
      void * Uxbuild advancedEditorbBD()
             void focusCB advancedEditorbBD()
             void valueChangedCB advEdGrouptF()
                    => void postmesg()
             void valueChangedCB advEdCompFirsttF()
                    ==> void postmesg()
             void losingFocusCB advEdCompFirsttF()
             void valueChangedCB advEdCompLasttF()
                    ==> void postmesg()
             void losingFocusCB advEdCompLasttF()
                    ==> void postmesg()
             void valueChangedCB rotatetB()
             void valueChangedCB rotateXtF()
             void valueChangedCB rotateYtF()
             void valueChangedCB rotateZtF()
             void valueChangedCB scaletB()
             void valueChangedCB scaleXtF()
                    ==> void postmesg()
             void losingFocusCB scaleXtF()
                    void SetScaleVal()
             void valueChangedCB scaleYtF()
                    ==> void postmesg()
             void losingFocusCB scaleYtF()
                    ==> void SetScaleVal()
             void valueChangedCB scaleZtF()
                    ==> void postmesg()
             void losingFocusCB scaleZtF()
```

```
==> void SetScaleVal()
void valueChangedCB translatetB()
void valueChangedCB translateXtF()
void valueChangedCB translateYtF()
void valueChangedCB translateZtF()
void valueChangedCB refPointXtF()
void valueChangedCB refPointYtF()
void valueChangedCB refPointZtF()
void valueChangedCB mirrortB()
void valueChangedCB yzPlanetB()
void valueChangedCB zxPlanetB()
void valueChangedCB xvPlanetB()
void valueChangedCB copytB()
void valueChangedCB copyGrouptF()
      ==> void postmesg()
void valueChangedCB copyFirsttF()
       ==> void postmesg()
void valueChangedCB copyLasttF()
       => void postmesg()
void losingFocusCB copyLasttF()
       ==> void postmesg()
void activateCB advancedEditorDeletepB()
       void delete components()
             => void UpdateDisplay()
             ==> void postmesg()
void activateCB advancedEditorPreviewpB
      void preview transform()
             void compute transform()
             ==> void UpdateDisplay()
void activateCB advancedEditorOKpB()
       UxPopdownInterface(advancedEditorbBD)
       void ApplyTransforms()
             => void compute transform()
             void transform components()
                    ==> void build geom()
                    ==> void postmesg()
             void copy components()
                    => void postmesg()
void activateCB advancedEditorApplypB()
       void ApplyTransforms()
             ==> void compute transform()
             ==> void transform components()
                    ==> void build geom()
                    ==> void postmesg()
```

```
==> void copy components()
                                  ==> void postmesg()
             void activateCB advancedEditorResetpB()
                    int ResetAdvancedEditor()
             void activateCB advancedEditorCancelpB()
                    UxPopdownInterface(advancedEditorbBD)
                    ==> int ResetAdvancedEditor()
void *create confirmErroreD()
      void * Uxbuild confirmErroreD() **CURRENTLY UNUSED**
void *create viewDCEDatabBD()
      void * Uxbuild viewDCEDatabBD()
             void focusCB viewDCEDatabBD()
             void activateCB dvDeleteSelpB()
             void activateCB dvDeleteAllpB()
             void activateCB dvUndoDeletepB()
             void activateCB dvPreviewComppB()
                    void preview read()
                           int validElemData()
                           int validCompData()
                           int cardContinued()
                           int extract line()
                    void preview geom()
                    ==> void postmesg()
             void activateCB sparepB1()
             void activateCB sparepB2()
             void activateCB sparepB3()
             void activateCB sparepB4()
             void activateCB sparepB5()
             void activateCB sparepB6()
             void activateCB viewDCEDataOKpB()
                    UXpopdownInterface(viewDCEDatabBD)
                    void ResetCardType()
                           void SetCardType()
                                  void UpdateDataViewer()
                                         void GetCardText()
                    int read bdf()
                           ==> int validElemData()
                           ==> int validCompData()
                           ==> int validHeaderData()
                           ==> int cardContinued()
                           ==> int extract line()
                           ==> void postmesg()
```

```
void build geom()
                          void build cylcone()
                                 ==> void postmesg()
                          void build sphere()
                                 int get points()
                                        ==> void postmesg()
                          void change coords()
                          ==> int get points()
                                 ==> void postmesg()
                          void insert elemlabels()
                          void maxel err()
                                 ==> void postmesg()
                          void maxmin()
                          void seg setup()
                                 ==> void selcontcol()
                                        => void selcolor()
                          void change key()
                          ==> void UpdateDisplay()
                                 void ResetView()
                                 void SetBusyPointer()
                           ==> void ResetSelGroups()
                          => void postmesg()
             void activateCB viewDCEDataApplypB()
                    ==> int read bdf()
                                                     +++
                    => void build geom()
                                                     +++
             void activateCB viewDCEDataResetpB()
             void activateCB viewDCEDataCancelpB()
                    UXpopdownInterface(viewDCEDatabBD)
void *create fileOpenOpsbBD()
      void * Uxbuild fileOpenOpsbBD()
             void valueChangedCB openFTOpsBDFtB()
             void valueChangedCB openFTOpsCDFtB()
             void valueChangedCB openFTOpsGDFtB()
             void valueChangedCB openFTOpsFDFtB()
             void activateCB openFTOpsReadpB()
                    UXpopdownInterface(fileOpenOpsbBD)
             void activateCB openFTOpsCancelpB()
                    UXpopdownInterface(fileOpenOpsbBD)
                    void ResetReadFileOps()
             void valueChangedCB openFTOpsRAlltB()
                    ==> void ResetReadFileOps()
             void valueChangedCB openFTOpsAddOtB()
                    ==> void ResetReadFileOps()
```

```
==> void ResetReadFileOps()
void *create orthoSlicerbBD()
       void * Uxbuild orthoSlicerbBD()
             void focusCB orthoSlicerbBD()
             void valueChangedCB positiveXtB()
             void valueChangedCB negativeXtB()
             void valueChangedCB positiveYtB()
             void valueChangedCB negativeYtB()
             void valueChangedCB positiveZtB()
             void valueChangedCB negativeZtB()
             void valueChangedCB positiveXtF()
             void valueChangedCB negativeXtF()
             void valueChangedCB positiveYtF()
             void valueChangedCB negativeYtF()
             void valueChangedCB positiveZtF()
             void valueChangedCB negativeZtF()
             void activateCB ortoSLicerOKpB()
                    UXpopdownInterface(orthoSlicerbBD)
                    void SetCuttingPlanes()
                           ==> void UpdateDisplay()
             void activateCB ortoSlicerApplypB()
                    void SetCuttingPlanes()
                                                       +++
             void activateCB ortoSlicerResetpB()
                    void ResetOrthoSlicer()
             void activateCB ortoSlicerCancelpB()
                    UXpopdownInterface(orthoSlicerbBD)
                    void ResetOrthoSlicer()
void *create viewCtlsbBD()
       void * Uxbuild viewCtlsbBD()
             void focusCB viewCtlsbBD()
             void activateCB hSurfs b1()
                    ==> void UpdateDisplay()
             void activateCB hSurfs b2()
                    ==> void UpdateDisplay()
             void activateCB hSurfs b3()
                    ==> void UpdateDisplay()
             void valueChangedCB refAxestB()
                    ==> void UpdateDisplay()
             void valueChangedCB labelELEMtB()
                    ==> void UpdateDisplay()
             void valueChangedCB labelGRIDtB()
```

void valueChangedCB openFTOpsAddNOtB()

```
==> void UpdateDisplay()
void valueChangedCB colorBartB()
      ==> void UpdateDisplay()
void activateCB zoomOutpB()
       ==> void UpdateDisplay()
void activateCB zoomInpB()
      ==> void UpdateDisplay()
void activateCB selectViewpB()
void activateCB resetViewpB()
      void ResetViewControls()
             void ResetGeomControls()
             ==> void UpdateDisplay()
      void ResetView()
             ==> void UpdateDisplay()
void activateCB orthoSlicerpB()
void activateCB geomOpspB()
void activateCB viewType Ortho()
       ==> void UpdateDisplay()
void activateCB viewType Persp()
      => void UpdateDisplay()
void valueChangedCB azimuthSc()
       ==> void UpdateDisplay()
void valueChangedCB elevationSc()
      ==> void UpdateDisplay()
void activateCB presetAZEL 0 0()
       ==> void UpdateDisplay()
void activateCB presetAZEL 45 0()
       ==> void UpdateDisplay()
void activateCB presetAZEL 90 0()
      => void UpdateDisplay()
void activateCB presetAZEL 135 0()
      ==> void UpdateDisplay()
void activateCB presetAZEL 180 0()
      => void UpdateDisplay()
void activateCB presetAZEL 225 0()
      => void UpdateDisplay()
void activateCB presetAZEL 270 0()
      ==> void UpdateDisplay()
void activateCB presetAZEL 315 0()
      => void UpdateDisplay()
void activateCB presetAZEL 0 45()
      => void UpdateDisplay()
void activateCB presetAZEL 45 45()
      => void UpdateDisplay()
```

```
void activateCB presetAZEL 90 45()
                    ==> void UpdateDisplay()
             void activateCB presetAZEL 135 45()
                    => void UpdateDisplay()
             void activateCB presetAZEL 180 45()
                    ==> void UpdateDisplay()
             void activateCB presetAZEL 225 45()
                    => void UpdateDisplay()
             void activateCB presetAZEL 270 45()
                    ==> void UpdateDisplay()
             void activateCB presetAZEL 315 45()
                    ==> void UpdateDisplay()
             void activateCB presetAZEL 0 n45()
                    => void UpdateDisplay()
             void activateCB presetAZEL 45 n45()
                    => void UpdateDisplay()
             void activateCB presetAZEL 90 n45()
                    ==> void UpdateDisplay()
             void activateCB presetAZEL 135 n45()
                    ==> void UpdateDisplay()
             void activateCB presetAZEL 180 n45()
                    => void UpdateDisplay()
             void activateCB presetAZEL 225 n45()
                    ==> void UpdateDisplay()
             void activateCB presetAZEL 270 n45()
                    ==> void UpdateDisplay()
             void activateCB presetAZEL 315 n45()
                    ==> void UpdateDisplay()
             void activateCB presetAZEL 0 90()
                    => void UpdateDisplay()
             void activateCB presetAZEL 0 n90()
                    ==> void UpdateDisplay()
void *create geomDispOpsbBD()
      void * Uxbuild geomDispOpsbBD()
             void focusCB geomDispOpsbBD()
             void activateCB geomDispOpsOKpB()
                    void SetGeomDispOps()
                           ==> void UpdateDisplay()
                          ==> void SetBusyPointer()
             void activateCB geomDispOpsApplypB()
                    void SetGeomDispOps()
                                                      +++
             void activateCB geomDispOpsResetpB()
                    int ResetGeomDispOps()
```

void ResetSelGroups() void SetGroupInfo() void setgeomcolwin() void activateCB geomDispOpsCancelpB() int ResetGeomDispOps() +++ void valueChangedCB groupNametF() void valueChangedCB grouptB0() void SetGroupInfo() +++ void valueChangedCB grouptB1() void SetGroupInfo() +++ void valueChangedCB grouptB2() void SetGroupInfo() +++ void valueChangedCB grouptB3() void SetGroupInfo() +++ void valueChangedCB grouptB4() void SetGroupInfo() +++ void valueChangedCB grouptB5() void SetGroupInfo() +++ void valueChangedCB grouptB6() void SetGroupInfo() +++ void valueChangedCB grouptB7() void SetGroupInfo() +++ void valueChangedCB grouptB8() void SetGroupInfo() +++ void valueChangedCB grouptB9() void SetGroupInfo() +++ void valueChangedCB grouptB10() void SetGroupInfo() +++ void valueChangedCB grouptB11() void SetGroupInfo() +++ void valueChangedCB compFirsttF() ==> void postmesg() void valueChangedCB compLasttF() ==> void postmesg() void losingFocusCB compLasttF() ==> void postmesg() void exposeCB_geomColorSeldA() ==> void UpdateDisplay() void singleSelectionCB geomColorSelsL() void setgeomcolwin() void activateCB gVisibility b1() void activateCB gVisibility b2() void activateCB gVisibility b3() void valueChangedCB transparencySc()

```
void activateCB gShading b1()
                     ==> void UpdateDisplay()
              void activateCB gShading b2()
                     ==> void UpdateDisplay()
              void activateCB gShading b3()
                     ==> void UpdateDisplay()
              void activateCB gShading b4()
                     ==> void UpdateDisplay()
void *create openBDFfSBD()
       void * Uxbuild openBDFfSBD()
              void cancelCB openBDFfSBD()
              void helpCB openBDFfSBD()
                     void SelectHelpFile()
              void okCallback openBDFfSBD()
                     void wininit()
                            void colorbar()
                                   void selcontcol()
                                          void selcolor()
                            void def pointer()
                     void rdfastgen()
                            int read bdf()
                                   int validElemData()
                                   int validCompData()
                                   int validHeaderData()
                                   int cardContinued()
                                   int extract line()
                                   => void postmesg()
                            void build geom()
                                   void build cylcone()
                                   void build sphere()
                                   void change coords()
                                   int get points()
                                   void insert elemlabels()
                                   void maxel err()
                                   void maxmin()
                                   void seg setup()
                                   void change key()
                                   ==> void UpdateDisplay()
                                   ==> void ResetSelGroups()
                                   ==> void postmesg()
                            void camcalc()
                            void init labels()
                            void setaxes()
```

```
void UpdateDisplay()
                                  ==> void SetBusyPointer()
                                  ==> void ResetView()
                           void ResetSelGroups()
                           void SetBusyPointer()
                           void SetGeomDispOps()
                                  ==> void UpdateDisplay()
                                  ==> void SetBusyPointer()
                           void postmesg()
                           int ResetGeomDispOps()
                                  void SetGroupInfo()
                                  ==> void ResetSelGroups()
                           ==> void ResetView()
void *create openCDFfSBD()
      void * Uxbuild openCDFfSBD()
             void cancelCB openCDFfSBD()
             void helpCB openCDFfSBD()
                    void SelectHelpFile()
             void okCallback openCDFfSBD()
                    void rdcontour()
                           int validcdkey()
                           ==> void postmesg()
                    ==> char *extract string()
void *create openGDFfSBD()
      void * Uxbuild openGDFfSBD()
             void cancelCB openGDFfSBD()
             void helpCB openGDFfSBD()
                    void SelectHelpFile()
             void okCallback openGDFfSBD()
                    void rdgrpdef()
                           int validgdkey()
                           ==> void SetBusyPointer()
                           ==> void postmesg()
                    ==> char *extract_string()
void *create openFDFfSBD()
      void * Uxbuild openFDFfSBD()
             void cancelCB openFDFfSBD()
             void helpCB openFDFfSBD()
             void okCallback openFDFfSBD()
                    void rdFTA()
                           int validftakey()
```

```
==> void postmesg()
                           void AddFTADVEntry()
                                  void activateCBFTADVentries()
                                         void change seg attrib()
                                         ==> void UpdateDisplay()
                                         ==> void SetBusyPointer()
                    ==> char *extract string()
void *create bdfCardsbBD()
      void * Uxbuild bdfCardsbBD()
             void focusCB bdfCardsbBD()
             void valueChangedCB textField1()
             void losingFocusCB textField1()
             void valueChangedCB textField2()
             void losingFocusCB textField2()
                    void UpdateDataViewer()
                           void GetCardText()
             void valueChangedCB textField3()
             void losingFocusCB textField3()
                    void UpdateDataViewer()
                           void GetCardText()
             void valueChangedCB textField4()
             void losingFocusCB textField4()
                    void UpdateDataViewer()
                           void GetCardText()
             void valueChangedCB textField5()
             void losingFocusCB textField5()
                    void UpdateDataViewer()
                           void GetCardText()
             void valueChangedCB textField6()
             void losingFocusCB textField6()
                     void UpdateDataViewer()
                           void GetCardText()
             void valueChangedCB textField7()
             void losingFocusCB textField7()
                     void UpdateDataViewer()
                           void GetCardText()
             void valueChangedCB textField8()
             void losingFocusCB textField8()
                    void UpdateDataViewer()
                           void GetCardText()
             void valueChangedCB textField9()
             void losingFocusCB textField9()
                    void UpdateDataViewer()
```

- void GetCardText()
- void valueChangedCB_textField10()
- void losingFocusCB_textField10()
 - void UpdateDataViewer()
 - void GetCardText()
- void valueChangedCB_textField11()
- void losingFocusCB_textField11()
 - void UpdateDataViewer()
 - void GetCardText()
- void valueChangedCB_textField12()
- void losingFocusCB_textField12()
 - void UpdateDataViewer()
 - void GetCardText()
- void valueChangedCB_textField13()
- void losingFocusCB textField13()
 - void UpdateDataViewer()
 - void GetCardText()
- void valueChangedCB_textField14()
- void losingFocusCB_textField14()
 - void UpdateDataViewer()
 - void GetCardText()
- void valueChangedCB_textField15()
- void losingFocusCB_textField15()
 - void UpdateDataViewer()
 - void GetCardText()
- void valueChangedCB_textField16()
- void losingFocusCB textField16()
 - void UpdateDataViewer()
 - void GetCardText()
- void valueChangedCB_textField17()
- void losingFocusCB_textField17()
 - void UpdateDataViewer()
 - void GetCardText()
- void valueChangedCB_textField18()
- void losingFocusCB_textField18()
 - void UpdateDataViewer()
 - void GetCardText()
- void valueChangedCB_textField19()
- void losingFocusCB_textField19()
 - void UpdateDataViewer()
 - void GetCardText()
- void valueChangedCB_textField20()
- void losingFocusCB_textField20()
 - void UpdateDataViewer()

11.0 (0.10)	
void GetCardText()	
void activateCB_bdfCardsApplypB())
void UpdateDataViewer()	
<pre>void GetCardText()</pre>	
<pre>void activateCB_bdfCardsResetpB()</pre>	
<pre>void SetCardType()</pre>	
void UpdateDataViev	ver()
void GetCard	Γext()
<pre>void activateCB_bdfCards_ccone1()</pre>	V
void SetCardType()	+++
void activateCB bdfCards ccone2()	
void SetCardType()	+++
void setcard type() void activateCB bdfCards chex1()	111
	1.1.1
void SetCardType()	+++
void activateCB_bdfCards_chex2()	
void SetCardType()	+++
void activateCB_bdfCards_cline()	
void SetCardType()	+++
<pre>void activateCB_bdfCards_cquad()</pre>	
<pre>void SetCardType()</pre>	+++
<pre>void activateCB_bdfCards_csphere()</pre>	
<pre>void SetCardType()</pre>	+++
<pre>void activateCB_bdfCards_ctri()</pre>	
<pre>void SetCardType()</pre>	+++
<pre>void activateCB_bdfCards_grid()</pre>	
void SetCardType()	+++
<pre>void activateCB_bdfCards_section()</pre>	
<pre>void SetCardType()</pre>	+++
<pre>void activateCB_bdfCards_vehicle()</pre>	
<pre>void SetCardType()</pre>	+++
<pre>void activateCB_bdfCards_wall()</pre>	
<pre>void SetCardType()</pre>	+++
void activateCB_bdfCards_comment	()
<pre>void SetCardType()</pre>	+++
<pre>void activateCB_bdfCards_name()</pre>	
void SetCardType()	+++
<pre>void activateCB_bdfCards_cordae()</pre>	
void SetCardType()	+++
void activateCB bdfCards point()	
void SetCardType()	+++
void activateCB_bdfCards unitgbl()	-
void SetCardType()	+++
void activateCB bdfCards unitlcl()	
void SetCardType()	+++
void seleard Type()	1 FT

```
void activateCB cdfCards comment()
                    void SetCardType()
             void activateCB gdfCards comment()
                    void SetCardType()
             void activateCB caseCards comment()
                    void SetCardType()
                                               +++
             void valueChangedCB dceGrouptF()
                    ==> void postmesg()
             void activateCB dceComptF()
                    void ResetCardType()
                                               +++
                    void SetDataViewer()
             void valueChangedCB dceComptF()
                    ==> void postmesg()
             void valueChangedCB dceEditNewtB()
                    void ResetCardType()
                                               +++
                    void ResetDataViewer()
             void valueChangedCB dceEditExistingtB()
                    void ResetCardType()
                                               +++
                    void ResetDataViewer()
             void valueChangedCB dceEditHeadertB()
                    void ResetCardType()
                                               +++
                    void SetDataViewer()
void *create printOpsbBD()
      void * Uxbuild printOpsbBD()
             void focusCB printOpsbBD()
             void valueChangedCB printPStB()
                    int SetPOSize()
             void valueChangedCB printEPStB()
                    int SetPOSize()
             void valueChangedCB printHPGLtB()
                    int SetPOSize()
             void valueChangedCB printCGMtB()
                    int SetPOSize()
             void valueChangedCB printPICTtB()
                    int SetPOSize()
             void valueChangedCB printAtB()
             void valueChangedCB printBtB()
             void valueChangedCB printCtB()
             void valueChangedCB printDtB()
             void valueChangedCB printEtB()
             void valueChangedCB printLandtB()
             void valueChangedCB printPorttB()
             void valueChangedCB printPrintertB()
```

```
void valueChangedCB_printFiletB()
              void valueChangedCB printFiletF()
              void valueChangedCB printPrintertF()
              void valueChangedCB printNCopytF()
              void activateCB_printOKpB1()
                    void PrintHardcopy()
                           ==> void SetBusyPointer()
                           => void postmesg()
             void activateCB_printResetpB()
                    int ResetPrintOps()
                           ==> void SetBusyPointer()
                           ==> void postmesg()
                           void SetPOFileType()
                           void SetPOSize()
                           void SetPOOrientation()
                           void SetPOOutput()
             void activateCB printCancelpB()
void *create confirmFCLosswD()
      void *_Uxbuild confirmFCLosswD()
```

void okCallback_confirmFCLosswD()

Appendix C: Interface Motif Widget Summary

The following is list of the primary widgets used in the VISAGE GUI. Each widget's function, relevant attributes, and utility functions are listed.

XmArrowButton

Function: an arrow-shaped push-button

Attributes: XmNactivateCallback - list of callbacks for button activation

Utilities: none

XmBulletinBoard

Function: provides simple geometry management for children widgets base

for all popup dialogs (only bulletin board dialogs in VISAGE)

Attributes: XmNdialogTitle - sets title of dialog

Utilities: none

XmDialogShell

Function: used for message dialogs

Attributes: XmNdialogType - specifies dialog type

XmDIALOG_ERROR XmDIALOG_QUESTION XmDIALOG_WARNING

XmNcancelCallback - list of callbacks for cancel
XmNhelpCallback - list of callbacks for help

XmNokCallback - list of callbacks for ok

Utilities: none

XmFileSelectionBox

Function: used to select files

Attributes: XmNdialogType - specifies dialog type

XmDIALOG FILE SELECTION

XmNpattern - specifies file search pattern
XmNcancelCallback - list of callbacks for cancel
XmNhelpCallback - list of callbacks for help
- list of callbacks for ok

Utilities: none

XmLabel

Function: used for labeling of widgets

Attributes: XmNlabelString - text string for label

Utilities: none

XmList

Function: used to select 1 or more items from a group of choices

all VISAGE lists are Single Select

Attributes: XmNitemCount - specifies total number of items

XmNitems - points to array of compond string list items

XmNselectionPolicy - defines selection action

XmSINGLE SELECT

XmNsingleSelectionCallback - list of callbacks for single selection

XmNvisibleItemCount- specifies number of items visible

Utilities: XmListAddItem - adds item to list

XmListDeselectAllItems - deselect all items in list
XmListSelectPos - select a position in a list
XmListItemPos - returns item position

XmPushButton

Function: issues commands

Attributes: XmNlabelString - text string for label

XmNactivateCallback - list of callbacks for activation

Utilities: none

XmRowColumn

Function: used for row/column ordering, radio boxes, menus, menu bars

Attributes: XmNrowColumnType - set type of row/column

XmWORK_AREA (default)

XmMENU_BAR
XmMENU_POPUP
XmMENU_PULLDOWN
XmMENU_OPTION

for menus:

XmCascadeButton - used in menus

XmNmenuHistory - used to set options menus

for radio buttons:

XmNradioBehavior - enforces behavior on toggle buttons

XmScale

Function: value selector

Attributes: XmNdecimalPoints - to specify decimal places in value

XmNmaximum - specify max value (> min value)
XmNminimum - specify min value (< max value)
XmNscaleMultiple - specifies amount to move slider

XmNshowValue - specify whether to show current value XmNvalue - current slider position (min <= x <= max)

XmNtitleString - text string for title

XmNvalueChangedCallback - list of callbacks for value change

Utilities: XmScaleGetValue - gets scale value

XmScaleSetValue - sets scale value

XmScrolledWindow

Function: combines 1 or 2 ScrollBars and a viewing area for window onto

larger data display default values used

Attributes: none relevant

Utilities: none

XmText

Function: provides single-line and multi-line text editor

Attributes: XmNeditable - specifies whether text is editable

XmNeditMode - specifies set of keyboard bindings

XmMULTI LINE EDIT

XmNvalue - specifies string value (char *)
 XmNcolumns - specifies initial width in characters
 XmNrows - specifies initial height in characters
 XmNactivateCallback - list of callbacks for activation

XmNvalueChangedCallback - list of callbacks for text changes

Utilities: XmTextGetString - get text string value

XmTextSetString - set text string value
XmTextGetInsertionPosition - get insertion position
XmTextSetInsertionPosition - set insertion position
XmTextInsert - insert text in text string
XmTextReplace - replace part of text string
XmTextRemove - remove selected text

XmTextField

Function: single line text editor

Attributes: XmNeditable - specifies whether text field is editable

XmNvalue - specifies string value (char *)
XmNactivateCallback - list of callbacks for carriage return

XmNvalueChangedCallback - list of callbacks when text is typed

Utilities: XmTextFieldGetValue - gets text value

XmTextFieldSetValue - sets text value

XmToggleButton

Function: set non-transitory state data

Attributes: XmNindicatorType - set type of toggle button

XmONE_OF_MANY = radio button XmN_OF_MANY = toggle button XmNlabelString - text string for label

XmNvalueChangedCallback - list of callbacks for value change

Utilities: XmToggleButtonGetState - get toggle button state

XmToggleButtonSetState - set toggle button state

Appendix D: VISAGE 2.2 User's Manual

The VISAGE 2.2 User's Manual is found on the following pages.


VISAGE 2.2 User's Manual

Brett F. Grimes, 88 CG/SCSA

December 1994

A program for displaying and editing FASTGEN 4 data sets

SCSA Technical Report Project SCSA-120



VISAGE 2.2 User's Manual			
	94		

Table of Contents

1.0 Ir	ntro	duction	101
	1.1	Purpose	101
	1.2	New Features	101
		1.2.1 Advanced Rendering	101
		1.2.2 Target Description Editing	101
		1.2.3 Fault Tree Data Representation	101
	1.3	Planned Enhancements for VISAGE	101
		1.3.1 Line-of-Sight (LOS) Data Representation	101
		1.3.2 Target Description Animation	101
	1.4	GUI Description	102
		1.4.1 Overview	102
		1.4.2 Open Software Foundation (OSF) Motif Widgets	104
		1.4.3 Widget Colors	106
	1.5	Installation.	113
	1.6	Operating System Requirements	113
	1.7	Memory Requirements	
	1.8	Feedback	114
	1.9	Other Issues	114
		1.9.1 Sun Version	114
		1.9.2 SGI Version	114
		1.9.3 All Versions	114
2.0 U	Sin	g VISAGE	115
	2.1		
		2.1.1 File Menu.	
		2.1.2 Edit Menu	
		2.1.3 Options Menu	
		2.1.4 Help Menu	
	2.2	Open File Types Reference	
		File Selectors	
	2.4	View Controls Reference	
	2.5	Geometry Controls Reference	
	2.6	Animation Controls Reference	
	2.7	Orthogonal Slicer Reference	125
	2.8	Select View Reference	
	2.9	Basic Editor Reference	
	2.10	Advanced Editor Reference	130
	2.11	Fault Tree Data Viewer Reference	133
	2.12	Mouse Functions	134
		2.12.1 Select Geometry	134

		2.12.2 Select Camera Target134	4
		2.12.3 Quick Zoom	4
3.0	Data	File Formats13	5
	3.1	Introduction138	5
	3.2	VISAGE Data Deck138	5
		CORDAE13'	7
		POINT	8
		UNITGBL139	9
		UNITLCL140	0
	3.3	Contour Data File (CDF)14	1
		CD	
		LIMITS14	3
		$ ext{TMSTEPS}$	
		VIEW	
	3.4	Group Defaults File (GDF)	
		COLORGR14'	
		GRPNAME	
	3.5	Fault Tree Data File (FDF)	
		FTSET	
		FTFUNC	
		FTSYS	
		FTSUB	
		FTCOMP	
		\$CNAME 15"	1
App	endix	A: Bulk Data File Example15	9
App	endix	B: Contour Data File Example16	7
App	endix	C: Group Defaults File Example16	8
App	endix	D: Fault Tree Data File Example16	9
Ann	endix	E: Fault Tree Output File Example 17	1

List of Figures

FIGURE	1	VISAGE (F-15 with Cutting Plane through Port-side Engine)	107
FIGURE	2	Shaded and Transparent Image of an F-15 Target Description	. 108
FIGURE	3	VISAGE Data Card Editor and Data Viewer	. 109
FIGURE	4	VISAGE Advanced Editor	. 110
FIGURE	5	VISAGE Fault Tree Data Viewer	. 111
FIGURE	6	VISAGE Popup Dialogs	. 112
FIGURE	7	File Selectors	. 118
FIGURE	8	VISAGE Data Deck Order	. 136
FIGURE	9	CDF Data Deck Order	. 141
FIGURE	10	GDF Data Deck Order	. 146
FIGURE	11	FDF Data Deck Order	151

98	

List of Tables

TABLE	1	Open File Types Reference	.117
TABLE	2	View Controls Reference	. 119
TABLE	3	Geometry Controls Reference	. 122
TABLE	4	Animation Controls Reference	
TABLE	5	Orthogonal Slicer Reference	.125
TABLE	6	Select View Reference	
TABLE	7	Data Card Editor Reference	. 127
TABLE	8	Data Viewer Reference	. 129
TABLE	9	Advanced Editor Reference	. 131
TABLE	10	Fault Tree Data Viewer Reference	. 133

1.0 Introduction

1.1 Purpose

VISAGE is a Graphical User Interface (GUI) designed for the visualization and interrogation of FASTGEN 4 bulk data sets. It is assumed that the user is familiar with FASTGEN 4 formats and technical terms. **VISAGE 2.2 replaces VISAGE 2.1**.

1.2 New Features

1.2.1 Advanced Rendering

VISAGE 2.2 has the capability to produce shaded images with transparency. The flat, Gouraud, and Phong shading algorithms are available.

1.2.2 Target Description Editing

Using the Basic Editor (Data Card Editor and Data Viewer dialogs), the user can now edit and save target descriptions. See Section 2.10 for details on the Basic Editor. Also available is an Advanced Editor that allows the user to rotate, scale, translate, mirror, and copy components. See Section 2.11 for details on the Advanced Editor.

1.2.3 Fault Tree Data Representation

Users are able to visualize fault tree data using a file generated by COVART 4.

1.3 Planned Enhancements for VISAGE

1.3.1 Line-of-Sight (LOS) Data Representation

Users will be able to visualize the LOS results using a data file generated by FASTGEN 4.

1.3.2 Target Description Animation

Expansions to the Contour Data File (CDF) format will allow for the animation of up to 12 separate "objects" (one per Group) as well as the current camera translation features.

1.4 GUI Description

The GUI is based on the OSF Motif Widget Set and is composed of several display and dialog windows:

1.4.1 Overview

1] VISAGE (Main Window)

This window contains a menu bar and a scrolled text area. The menu bar contains the overall application controls. The scrolled text area provides the user with various information relating to the target description and the menu selections.

- 2] Display Window
 This window is where the target description is displayed.
- 3] Open File Types
 Dialog for selecting the types of files to load into VISAGE.
- 4] Bulk Data File Selector File selector dialog for loading a FASTGEN Bulk Data File (BDF) into VISAGE.
- 5] Contour Data File Selector File selector dialog for loading a VISAGE Contour Data File (CDF) into VISAGE.
- 6] Fault Tree Data File Selector
 File selector dialog for loading a VISAGE Fault Tree
 Data File (FDF) into VISAGE.
- 7] Group Defaults File Selector File selector dialog for loading a VISAGE Group Defaults File (GDF) into VISAGE.
- 8] Basic Editor
 Consists of two dialogs; the Data Card Editor and the
 Data Viewer. Allows for component-level editing of the
 target description.

9] Advanced Editor
Allows for copying and spatial manipulation of
components, i.e., rotation, scaling, translation, and
mirroring.

10] Fault Tree Data Viewer
Allows user to see relationships between COVART 4
fault tree data and the FASTGEN 4 target description.

11] Animation Controls

Controls for data input through the CDF.

12] View Controls

Basic controls governing the viewing aspect of the current target description.

13] Geometry Options
Option settings for the appearance of the current target description.

14] Orthogonal Slicer
Controls for selecting the position and orientation of the orthogonal cutting planes.

15] Select View

Controls for selecting a specific camera view of the current target description.

16] Print Options
Options for hardcopy output of the current view of the target description.

17] Confirm Exit

This is a message dialog asking the user to confirm his decision to exit VISAGE.

18] Help Window
A scrolled text window for the display of help files on assorted VISAGE topics.

19] Color Bar with Index and User-Assigned Values
This window provides the user with a visual of the color
bar and any assigned ranges of values the user may have
specified for the colors.

1.4.2 Open Software Foundation (OSF) Motif Widgets

The GUI for VISAGE is based on the standard OSF Motif widget set. Motif is quickly becoming the GUI of choice on Unix workstations.

The following is a list of the Motif widgets in the interface and how they are used:

Note: Unless specified, all mouse actions are done using the left mouse button.

11 Push Buttons

Push buttons are widgets that initiate an action or function when clicked on ("pushed") with the mouse.

2] Toggle Buttons

These buttons are widgets that essentially act like "check boxes" and may initiate an action or set an option.

3] Radio Buttons

These buttons are really just toggle buttons, but only one out of a group may be selected at one time. The name is derived from the push buttons for selecting preset stations on radios.

4] Pulldown Menus

This is a menu that the user activates by clicking once on or by holding down the mouse button on the selected menu text. This brings up a "menu" of push buttons for the user to select from.

5] Option Menus

Option menus are activated by holding down the mouse button over the menu and highlighting a selection on the "menu". This selection becomes the "top" of the "menu" and is displayed on the widget.

61 Scales

Scale is the Motif name for a sliding bar. This widget lets the user select a number from a preset range of numbers. Users can elect to "drag" the sliding bar to a selected point using the left mouse button, jump to a selected point using the middle mouse button, or increment or decrement the current selected value by one by clicking to the right or left, respectively, of the sliding bar.

71 Text Fields

These widgets allow the user to type in text.

8] Scrolled Windows

Scrolled windows allow the user to scroll around a window containing more items than can be displayed at once in the allotted window size.

91 Scrolled Lists

Scrolled lists allow the user to scroll through a list of choices and select one item.

10] Scrolled Text

Scrolled text is used in the VISAGE and Help Windows to allow the user to scroll through information that may be larger than the available display area.

11] Message Dialogs

Message dialogs appear to confirm a choice, such as exiting the program.

12] File Selectors

File selectors are compound widgets (composed of several different widgets, but treated as one large one) that allow the user to select files for input or output purposes.

13] Popup Dialogs

These are compound widgets that are created by the GUI designer. These dialogs are used to separate different functions of the program, to compartmentalize the operation and to prevent information overload.

14] Arrow Buttons w/Text Fields

These are compound widgets that are similar in function to the Scales. A user can increment or decrement the value displayed in the associated text field by clicking on either the up or down arrows, respectively. The user can also input a specific value by typing in the text field.

1.4.3 Widget Colors

Color is used to indicate the function and/or the state of a widget. Except as designated below, **Active** widgets will be **Blue** or **Royal Blue** and **Inactive** widgets (separators and labels) will be either **Dark Grey** or **Navy Blue**.

The push buttons are one of two types:

Immediate

Extended

Immediate push buttons are **Blue** in color and will flash red when activated.

Extended push buttons are **Gold** in color and will flash red when "pressed". These push buttons will cause popup dialogs to appear.

Toggle and **Radio** buttons are **Royal Blue** in color and will turn **Red** when toggled to active mode. Some buttons are active by default and are initially **Red**.

Text Fields, Scrolled Lists, and Scrolled Text are Grey with White text. They will not change color, except Scrolled Lists, which will reverse highlight the selection.

Scales and Option Menus are Royal Blue and will not change color.

Indicator Text Fields are **Black** with **Green** text. These cannot be edited and will not change color.

The main **Pulldown Menu Bar** is **Navy Blue** with **Royal Blue** "menus".

Non-button areas and indicators are Dark Grey.

Figures 1-6 illustrate features of the VISAGE GUI.




FIGURE 1

VISAGE (F-15 with Cutting Plane through Port-side Engine)





FIGURE 2

Shaded and Transparent Image of an F-15 Target Description



VISAGE Data Card Editor and Data Viewer

FIGURE 3





FIGURE 4

VISAGE Advanced Editor



VISAGE Fault Tree Data Viewer

FIGURE 5


















FIGURE 6

VISAGE Popup Dialogs

1.5 Installation

VISAGE is available on the following platforms:

Sun 4's / SPARCstations

Silicon Graphics Inc. Iris 4D, Indigo, Power, Crimson, and Reality Engine series

(DEC available by request)

To install VISAGE simply download all the files on the distribution tape for your particular platform onto your system. The commands to do this are:

(SGI, DEC)	(Sun)	(Solaris)
tar xvp	tar xvpf /dev/rst8	tar xvpf /dev/rmt/0
cd visage_2.2	cd visage_2.2	cd visage_2.2
./install-visage	./install-visage	./install-visage

The files will include the VISAGE executables, a shell script that acts as a front end to the executable, sample data files, an installation script, a de-installation script, and a PostScript copy of this manual. To begin using VISAGE, type in the following:

visage

Optionally, you can direct VISAGE to look for files in a directory other than the one you are executing in by setting the VIS_HOME environment variable, e.g.:

setenv VIS_HOME <directory-pathname>

1.6 Operating System Requirements

Sun: SunOS 4.1.3 (X11R5) or Solaris 2.3 (SunOS 5.3) and above

SGI: IRIX 5.2 and above

1.7 Memory Requirements

The VISAGE program is currently set to allow the user to view files of any size that can be accommodated by the main memory in the user's system, dependent upon the restrictions found in the FASTGEN 4 User's Manual regarding the FASTGEN 4 data files. VISAGE will work best on systems equipped with at least 32 MB of main memory (RAM). Systems with less than this can execute VISAGE, but expect excessive paging of memory on large data files.

1.8 Feedback

Any feedback from users on the interface design and the improved capabilities would be welcome. Please feel free to e-mail any comments and/or problems to me at:

tacit@msrc.wpafb.af.mil

1.9 Other Issues

1.9.1 Sun Version

- 1] The color bar window cannot be dismissed once you have activated it. This is because the window is created by the HOOPS graphics library and in the current version it does not respond well to X11 and Motif window directions.
- 2] Related to the color bar problem is the main Display Window. Too much moving or resizing of the Display Window will cause HOOPS to "lose" track of where in the Motif display area the HOOPS window should be located. According to HOOPS, this is a problem only when you display Motif windows under Sun's OpenWindows interface. This will not be an issue if you are running Motif on your Sun systems.

1.9.2 SGI Version

1] In the SGI version, to take advantage of the GL driver, a "mixed-mode" version of a Motif drawing area widget is used. The Display Window will come up in technicolor the first time VISAGE is started up. This has to do with colormap usage and does not cause any problems.

1.9.3 All Versions

1] The ray-tracing capabilities and the problems with its integration in the HOOPS library by Ithaca Software have rendered the ray-tracing option unusable. It will probably not return. The good news is that transparency is now available without the advanced rendering module, so the only capability missing is shadow generation.

2.0 Using VISAGE

2.1 The Menu Bar

The menu bar is the first level of the GUI the user will encounter. The menu bar consists of the following main categories:

File

Edit

Options

Help

2.1.1 File Menu

The File menu selection currently has 5 selections:

1] Open...

This selection will popup the Open File Types dialog.

2] Save

This will save the current target description using the current filename.

3] Save As...

This will bring up the Save As file selector so the user can select a new filename to use for the current target description.

41 Print...

This selection will popup the Print Options dialog.

51 Exit

This selection will popup the Confirm Exit message dialog.

2.1.2 Edit Menu

The Edit menu selection has two selections:

11 Basic Editor

This selection will popup the Data Card Editor and the Data Viewer dialogs.

21 Advanced Editor

This selection will popup the Advanced Editor.

2.1.3 Options Menu

The Options menu has four selections:

1] Allow Independent Scaling

This toggle button allows the Scale function of the Advanced Editor to work independently on each of the X, Y, and Z axes. The default setting is to lock scaling to the same value for all axes.

2] Output Geometry Selection

This toggle button enables the output of data from the mouse button selection of geometry elements. Information on geometry selections is output to a text file that is named by appending the '.sel' suffix to the name of the current Bulk Data File (BDF). The default setting is to not output the geometry selection information.

3] Show Fault Tree Components

This toggle button allows user to set the Fault Tree Data Viewer to display or not display the bottom level components defined in a fault tree. This is useful for displaying large trees when the lowest level components do not need to be displayed. The default setting is to display fault tree components.

4] Output Fault Tree Outline

This toggle button allows user to set the Fault Tree Data Viewer to output a text listing of the fault tree data, whenever a Fault Tree Data File (FDF) is input. This output capability mimics the view of the fault tree in the Fault Tree Data Viewer in a text format. The data is output to a text file that is named by appending the '.txt' suffix to the name of the current FDF. The default setting is to output the fault tree information.

2.1.4 Help Menu

The Help menu selection currently has only 1 selection:

11 On VISAGE

This selection will popup up the Help Window with a short summary of the VISAGE software.

2.2 **Open File Types Reference**


The Open File Types popup dialog allows the user to load any combination of the 4 types of files expected by VISAGE (see Ch. 3.0); the Contour Data File (CDF), the Group Defaults File (GDF), the Fault Tree Data File (FDF), or the Bulk Data File (BDF). The CDF, GDF, and FDF are optional files and are used in conjunction with the BDFs. The user may visually combine two or more target descriptions by loading the files separately and selecting the appropriate Read File Option. To load in any combination of the three file types (a BDF file must be used if no previous target description has been loaded), the user simply selects the file types and then selects the appropriate files from the File Selectors. These selections are described in Table 1.

TABLE 1


Open File Types Reference

Item

Effect



Select File Types to Open: These toggle buttons allow the user to select a combination of the four FASTGEN and VISAGE file types: BDF, CDF, GDF, and FDF. The default selection is Bulk Data File.



Read File Options: These radio buttons allow the user to select the way the new data will overwrite the existing target description data. Choices are to **Replace** All, Add (overwrite), and Add (no overwrite). For BDF's, Replace All will completely replace the existing target description. Add (overwrite) will replace any existing components found in the new BDF. Add (no overwrite) will not replace any existing components found in the new BDF. CDF, GDF, and FDF data will always be completely replaced. The default setting is Replace All.


Read File(s)/Cancel



These push-buttons control the use of the Open File Types dialog. *OK* will bring up the file selectors for the chosen file types and dismiss the popup dialog. Cancel will reset the options and dismiss the popup dialog.

2.3 File Selectors

The File Selectors allow the user to select the appropriate files as specified in the Open File Types popup dialog. Each data file type has its own File Selector. File Selectors are brought up in their predefined loading order. Figure 3 below shows the four File Selectors.










FIGURE 7

File Selectors

2.4 View Controls Reference

The View Controls popup dialog contains menu selections that provide the user with the capability to duplicate any orientation in FASTGEN 4. The initial view orientation is at 0 degrees azimuth, 0 degrees elevation. These selections are described in Table 2.


TABLE 2

View Controls Reference

Item

Effect

Azimuth/Elevation.....



Positive azimuthal and elevational rotation in 1 degree increments between 0 and 360 degrees, and-90 and +90 degrees, respectively. The user can directly select an azimuth or elevation by clicking the middle mouse button on the sliding bar path. Clicking on either side of the sliding bar will increment or decrement the value by one. Holding down the left mouse button on top of the sliding bar and dragging will more quickly increment or decrement the value.

Presets (AZ, EL)



This option menu toggles the camera view to preset azimuth and elevation values defined in the FASTGEN 4.0 User's Manual. The default is AZ: 0. EL: 0.



Orthographic/Perspective This option menu toggles the camera projection between perspective and orthographic. The default is orthographic.

XYZ Axes



.......... These toggle the visibility of the coordinate axes in the Display Window off or on. The default for this toggle button is on.

ELEMENT Labels



These toggle the visibility of the ELEMENT labels of the currently visible geometry. The ELEMENT labels appear above the center point of their respective Elements and are shown in dark red. The default for this toggle button is off.

GRID Labels

↑ GRIII Labels


These toggle the visibility of the GRID labels of the currently visible geometry. The GRID labels appear below the center point of their respective Grid points and are shown in dark blue. The default for this toggle button is off.

Color Bar

Color Bar

Brings up the Color Bar Window, showing the possible color choices for the user in highlighting the various Components and Elements of a target description. On the right side of the Color Bar are the Color Bar index numbers needed by the *Highlight Component(s)* menu selection. These are also the index numbers used in the Contour Data File (see Chapter 3). Underneath the colors of the Color Bar are the user-assigned values which VISAGE reads from the Contour Data File.

Hidden Surfaces



This option menu toggles the hidden surfaces algorithms on or off. The Draft option is a quick Z-sort algorithm and will not be a true hidden surface representation when used with complex target descriptions. The Full option provides the best possible hidden surface representation. The default for this option menu is *None*. (NOTE: It is recommended that the user position the target description before turning on the hidden surfaces, to allow the program to save time in redrawing the target description.)

Zoom Out

Zoom the current camera view out by a factor of 1.5.




Zoom In

......Zoom the current camera view in by a factor of 1.5.

Zoom In

Select View




Brings up the Select View popup dialog which allows the user to select a new camera Position, Target, and Viewing Angle. The default Position is (1.0, 0.0, 0.0). The default Target is (0.0, 0.0, 0.0). and the default View Angle is 15.0 degrees. The view angle determines how much of the scene can be shown. An angle of 90.0 degrees is the maximum. The default value best approximates

what the human eve would perceive. Increasing the view angle effectively moves the camera "back" from the camera target, so that more of the target is visible, similar to the way a zoom lens works. Fish-eve effects are NOT possible.




This selection returns the target description to the initial view (at start-up time). This will not affect any Components or Elements that have been highlighted, or the current visibility of the target description.




Lighting Options Brings up the Rendering Options popup dialog which allows the user to select the lighting and rendering options for the current description.

Geometry Options



Brings up the Geometry Options popup dialog which allows the user to select the color, lighting. transparency, and geometry type (wireframe or solid) options for the current target description.

Ortho Slicer..



Brings up the Orthogonal Slicer popup dialog which allows the user to select from six orthogonal cutting planes to apply to the current target description.

2.5 **Geometry Controls Reference**

The Geometry Effects Menu contains selections that allow the user to alter the target description's geometric presentation in the Plot Window. These selections are described in Table 3.


TABLE 3

Geometry Controls Reference

Item

Effect

Set Group Options.....




This set of radio buttons allows the user to select which Group's options to display. The *Group(s)* are the Groups in FASTGEN 4. (e.g. aircraft skin, power plant, crew, etc.) This is a dynamic menu in that buttons will only be active for the Group(s) that have been read in by the program from the data file.

Geometry Type



Change the geometry type of the current Group to a choice of Off, Wireframe, or Solid. The default is that the first Group to be read in will be in Wireframe mode. All other Groups will be Off.

Group Name




Displays the currently selected Group's name. This can be edited by the user. All values changed by the user will be retained for the current geometry. The Group Defaults File allows the user to change the default names for the Group(s).



current Group on which to apply the geometra options. Individual components can be selected by putting the same value in both text fields. The default range is 1 to 999.

Current Color




Displays the currently selected Group's default color. This can be changed by the user by selecting a new color from the scrolled list. All values changed by the user will be retained for the current geometry. The Group Defaults File allows the user to change the default display color of Elements in the particular Groups.

Transparency.....



Allows the user to select the amount of transparency to apply to the current Group/Component selection. 0% transparency makes the geometry completely opaque. 100% transparency makes the geometry completely transparent. The default is 0%.

Surface Shading.....



Allows the user to select between one of the following lighting options: None, Flat, Gouraud, and Phong. None indicates that no lighting calculations are to be done on the target description. Flat indicates that lighting should be calculated for each polygon, with no interpolation. Gouraud indicates that lighting should be calculated at each vertex of a polygon and these are interpolated. Phong indicates that lighting should be calculated for a "vertex normal" at each vertex (which is calculated from the surrounding polygon face normals) and these are interpolated. Phong is the best lighting approximation, with Gouraud second and Flat third. The default is *None*.

OK/Apply/Reset/Cancel..



These push-buttons control the use of the Geometry Options. *OK* will apply any changes to the options and dismiss the popup dialog. *Apply* will apply any changes to the options and retain the popup dialog. *Reset* returns the options to their start-up defaults. *Cancel* will reset the options and dismiss the popup dialog.

2.6 Animation Controls Reference

The Visual Effects Menu contains selections that allow the user to alter the color schema, visibility, and construction (solid or wireframe) of the target description. These alterations are performed at the Group and Component levels of the target description. These selections are described in Table 4.

TABLE 4

Animation Controls Reference

Item

Effect


Step Increment.....



Current Step



Step Cycle Type.....



Current Value ...



Sets the Step Increment for the current Contour Data. This is a range from 1 to 10. Users can decrement or increment the value by clicking on the down or up arrows, respectively. Values can be directly input by typing in the text field (must be terminated by a <return> to be valid).

Sets the Current Step value for the current Contour Data. This is a range from 1 to 500, currently. Users can decrement or increment the value by clicking on the down or up arrows, respectively. Values can be directly input by typing in the text field (must be terminated by a <return> to be valid). Changing this value will result in the data at the new Step being applied to the current target description.

Determines the cycle of the steps. This can be Linear, Bounce, or Continuous. Linear stepping will stop at the first or last data step, depending on Play direction. Bounce stepping will cycle back and forth between the first and last steps indefinitely. Continuous stepping will loop through the data set, in the Play direction, indefinitely.

This displays the value of the current step, that was assigned in the CDF.

PLAY <<</PLAY >>>/

RESET/STOP....



These push-buttons control the actions of the Animation Controls popup dialog. **PLAY** <<< will start *reverse* play of the data set. **PLAY** >>> will start *forward* play of the data set. **RESET** returns all settings to their original values. **STOP** halts playback of the data set.

2.7 Orthogonal Slicer Reference

These selections are described in Table 6.


TABLE 5

Orthogonal Slicer Reference

Menu Selection

Effect

Cutting Planes.....



These toggle buttons and text fields allow the user to setup 6 orthogonal cutting planes (2 per axis). By activating the toggle buttons, the user can "turn on" a cutting plane. The position along the axis is determined by the associated Location text field. The cutting planes are setup so that geometry on the positive and negative sides of an axis can be "cut away", i.e., the +X plane will "cut away" all geometry on the positive side of its associated Location value and the -X plane will "cut away" all geometry on the negative side of its associated Location value. The same holds for the +Y, -Y, +Z, and -Z axes. To "turn off" an existing cutting plane, simply disable its toggle button. The default is that all cutting planes are disabled.

OK/Apply/Reset/Cancel.....



These push-buttons control the use of the Orthogonal Slicer. *OK* will apply any changes to the options and dismiss the popup dialog. *Apply* will apply any changes to the options and retain the popup dialog. *Reset* returns the options to their start-up defaults. *Cancel* will reset the options and dismiss the popup dialog.

2.8 Select View Reference

These selections are described in Table 7.


TABLE 6

Select View Reference

Menu Selection


Effect

Camera POSITION




camera position by specifying the coordinates. The default coordinates are (1.0, 1.0, 1.0).

Camera TARGET....




These text fields allow the user to setup the camera target by specifying the XYZ coordinates. The default coordinates are (0.0, 0.0, 0.0).

Camera POSITION.



. These text fields allow the user to setup the camera view field by specifying the angle. The default angle is 15.0.



OK/Apply/Reset/Cancel...... These push-buttons control the use of the Select View dialog. OK will apply any changes to the options and dismiss the popup dialog. Apply will apply any changes to the options and retain the popup dialog. Reset returns the options to their start-up defaults. Cancel will reset the options and dismiss the popup dialog.

2.9 **Basic Editor Reference**

The Basic Editor is composed of two popup dialogs:

Data Card Editor

Data Viewer


The Data Card Editor (DCE) is a template mechanism for creating the various card types found in the BDF. In future versions, this will be expanded to include the CDF, GDF, and Case Control deck. The DCE is setup to resemble the card description pages of the FASTGEN 4 User's Manual. The user is expected to be familiar with the terminology used by that manual.

The Data Viewer (DV) allows the user to view and/or edit a single component at a time, in conjunction with the use of the DCE. The DCE can be used to create new cards in the current component or the user may create new entries, or edit or copy existing ones in the DV.


The selections for the DCE are described in Table 8 and the selections for the DV are described in Table 9.

Data Card Editor Reference TABLE 7

Effect Menu Selection



found in the BDF. The BDF Cards pulldown option menu selection allows the user to select which card they would like to edit. The <Tab> and <Shift><Tab> keys allow the user to move forward and back, respectively, in the active text fields and any changes are automatically updated to the DV.



card found in the BDF into the Card Template. The CDF, GDF, and Case Cards are for future versions.

Editing.....



These radio buttons allow the user to determine which part of the target description, if it exists, should be loaded into the DV. These radio buttons work in conjunction with the Group/Component text fields. New will create a new component. Existing will load an existing component in the DV. Header will load the header portion, if any, in the DV. If the user selects New and specifies an existing component in the Group/Component text fields, then the Existing button will be selected and the component loaded into the DV. If the user selects existing and specifies a non-existent component, then the New button will be selected and the DV will be cleared.

Group/Component

Selection ..



These text fields allow the user to determine which component of the target description, if it exists, should be loaded into the DV. These text fields work in conjunction with the Editing radio buttons. To specify the *Group* a user only has to type in text field. However, to specify the Component the user must type in <Enter> for <Return>) after the typing in the number to activate the DV.




Apply/Reset These push buttons allow the user to Apply any changes to the DV or to Reset the current card selection to its default values.

TABLE 8

Data Viewer Reference

Menu Selection

Effect



being edited. The user may edit cards directly or use the DCE to create new ones. The mouse functions for the Data View Area are as follows:

> Left: hold and drag to select text single-click to select cursor position double-click to select a word triple-click to select a line quadruple-click to select all

Middle: single-click to copy selected text

hold down over selected text and drag to

move text


single-click to paste last selected X-win-Right:

dow text

Delete Selection/

Delete All/

Undo Delete/



Undo capability and to preview the current data. By using the Delete Selection and Delete All buttons instead of the <Backspace> button, the user has a last-action undo capability. The *Preview* Component button allows the user to see what changes will look like without actually changing the current data. All previewed geometry will be shown with black faces and red edges to distinguish it from the original data.

OK/Apply/Reset/Cancel.....



. These push-buttons control the use of the Data Card Editor and Data Viewer dialogs. OK will apply any changes to the target description and dismiss the popup dialogs. Apply will apply any changes to the target description and retain the popup dialogs. Reset returns the dialogs to their start-up defaults. Cancel will reset and dismiss the popup dialogs.

Advanced Editor Reference 2.10

The Advanced Editor (AE) allows the user to apply transformations to single or multiple Components. It also allows the user to copy single or multiple Components, either in the same Group (space permitting) or to another Group. (NOTE: By default, Scaling is limited to equal values for each axes. The user must select independent axis scaling by selecting Independent Scaling under the Options menu on the menu bar.)


The selections for the AE are described in Table 10.

TABLE 9

Advanced Editor Reference


Menu Selection

Effect



Group/Component Range These text fields allow the user to specify the Group and range of Components to which to apply the transformations.

Reference Point



These text fields allow the user to specify a reference point for use in calculating the Rotate and Scale transformations. This point does NOT apply to any other transformations.

ROTATE/SCALE/

TRANSLATE....



These toggle buttons and text fields allow the user to specify the rotation, scaling, and translation transformations to apply to the specified component(s). The user can select combination of the three, but the transformations will always be applied in the following order: Rotate, Scale, Translate.

MIRROR/COPY &

COPY TO



These toggle buttons and text fields allow the user to specify how to mirror the specified component(s) and copy to the specified Group and Component(s). A mirror operation requires a Copy operation, so the two functions are linked. The user can also specify a Copy operation without doing a Mirror operation.


Delete Component &

Preview Component.....



These push buttons allow the user to Delete a component and to Preview any transformations. The Delete button will delete the component(s) specified in the Group and Component Range text fields. The Preview button allows the user to check if the transformations are being applied as expected.

OK/Apply/Reset/Cancel.....



These push-buttons control the use of the Advanced Editor dialog. *OK* will apply any changes to the target description and dismiss the popup dialog. *Apply* will apply any changes to the target description and retain the popup dialog. *Reset* returns the dialog to its start-up defaults. *Cancel* will reset and dismiss the popup dialog.

Fault Tree Data Viewer Reference 2.11

The Fault Tree Data Viewer allows the user to view fault trees produced by COVART 4 in an outline format. This format is used to simplify the display of the fault tree. The Fault Tree Data Viewer also links the fault tree to the target description by the components defined in the Fault Tree Data File (FDF). See Ch. 3.5 for a more detailed description of the FDF.


The usage of the Fault Tree Data Viewer is described in Table 10.

TABLE 10

Fault Tree Data Viewer Reference

Menu Selection

Effect



Fault Tree Display...... This scrolled window holds the push-buttons that link the fault tree to the FASTGEN target description. The user can highlight the associated target description components by clicking on the push-buttons.

condition of no fault tree components highlighted in the target description.



2.12 Mouse Functions

Certain areas of the VISAGE GUI have functions tied to the mouse selection buttons. A standard 3-button mouse is assumed.

The Display Window area of the GUI has 3 functions tied to the mouse buttons. These 3 functions are:

- 1] Select Geometry
- 2] Select Camera Target
- 3] Quick Zoom

2.12.1 Select Geometry

Select Geometry allows the user to select any visible geometry element in the Display Window and its Element ID information will be displayed in the VISAGE information area. The target description must be displayed in Draft or Full hidden surfaces to enable this action. If not, an error message will be displayed in the information area. This function is tied to the *left mouse button*.

2.12.2 Select Camera Target

Select Camera Target allows the user to designate a new camera target. By selecting a point in the Display Window, VISAGE will effectively turn that point into the new camera target, which will become the approximate center of the new view. This function is tied to the *middle mouse button*.

2.12.3 Quick Zoom

Quick Zoom allows the user to "zoom" the camera view into or out of an area of the currently displayed geometry. By selecting a point in the Display Window, VISAGE will use that point as the new camera target and zoom in by a factor of 2. This function is tied to the *right mouse button*.

To zoom in, the user can click once with the right mouse button at the desired position.

To zoom out, the user must hold down the <shift> button and click once with the right mouse button at the desired position.

Note: The **Zoom Out** and **Zoom In** buttons should be used for fine adjustments of the camera view.

3.0 Data File Formats

3.1 Introduction

VISAGE expects data files of four possible formats: the FASTGEN 4 bulk data deck format (BDF), the VISAGE Contour Data File (CDF), the VISAGE Group Defaults File (GDF), and the VISAGE Fault Tree Data File (FDF).

3.2 VISAGE Data Deck

VISAGE in its current implementation supports the following FASTGEN 4 bulk data deck cards:

SECTION	CCONE1	CCONE2
GRID	CHEX1	CHEX2
ENDDATA	CLINE	CQUAD
\$COMMENT	CSPHERE	CTRI

The following data deck cards are not found in the FASTGEN 4 bulk data deck. They are extensions for endgame analysis support:

POINT	UNITGBL	UNITLCL
CORDAE		

Also, files using the following NASTRAN bulk data deck cards can be viewed:

GRID	CTRIA1	CTRIA2
CTRIA4	CQUAD1	CQUAD2
CQUAD4	CHEXA1	CHEXA2

with the addition of SECTION and ENDDATA cards at the beginning and end of the file, respectively.

Please refer to the **FASTGEN 4.0 Users' Manual** for the FASTGEN 4 - NASTRAN cross reference, and for more information on these cards. Currently, all unsupported cards are treated as non-valid and are ignored. Likewise, an incorrectly spelled valid "card" is also ignored.

Appendix A shows an example BDF.

The following is a breakdown of the valid Groups:

Group	Description
0-9	Target bulk data
10	Attacker bulk data (The missile and fuze cone need to be in separate components)
11	Fragments, although POINT "cards" may appear in any Group, this is reserved for point data only. Each Time Step should be a separate component.

Figure 8 illustrates the order dependencies of the VISAGE bulk data deck.




FIGURE 8

VISAGE Data Deck Order

Bulk Data Deck Card: CORDAE

Description:

Allows the user to translate Component(s) and to apply yaw, pitch, and roll rotations to the Component(s). This "card" is used in conjunction with one or two POINT cards, which must follow immediately after the CORDAE "card". These POINT cards are part of the 10,000 POINT per SECTION limit. This "card" is optional.

Format, Example, and Data Type:

Field 1	Field 2	Field 3	Field 4	Field 5	Field 6	Field 7	Field 8	Field 9	Field 10
CORDAE	cid	rpid	tpid	yaw	pitch	roll			
CORDAE	1	0	777	0.0	90.0	0.0			
string	integer	integer	integer	real	real	real			

<u>Field</u>	Contents
cid	Component ID number (integer > 0).
rpid	Reference POINT ID (integer >=0). This references a POINT "card" that provides the reference point on the Component to use for any translations or rotations.
tpid	Translation POINT ID (integer > 0). This references a POINT "card" that provides the point to translate the Component to. If RPID = 0, then the x,y,z values of the TPID POINT "card" are used as translational displacement distances (Δx , Δy , Δz).
yaw	Value for rotation about a Component's local Z-axis (real).
pitch	Value for rotation about a Component's local Y-axis (real).
roll	Value for rotation about a Component's local X-axis (real).
Remarks:	The CORDAE "card" expects at least one POINT "card", which must immediately follow the CORDAE "card", if not VISAGE will ignore the "card", print a warning, and proceed.

All rotations and/or translations are based on the "right-hand rule".

Bulk Data Deck Card: POINT

Description:

User defines an x,y,x location in space representing a point. The VIS field is used to distinguish whether a POINT "card" is to visible or not. This is important when using the POINT "card" in conjunction with the CORDAE "card". This "card" is optional.

Format, Example, and Data Type:

Field 1	Field 2	Field 3	Field 4	Field 5	Field 6	Field 7	Field 8	Field 9	Field 10
POINT	pid	vis	х	у	z				
POINT	15	0	29.82	236.32	138.55				
string	integer	integer	real	real	real				

<u>Field</u>	<u>Contents</u>						
pid	POINT ID number (integer > 0). 1 to 1000 reserved for POINT cards used with VIEW cards > 1000 reserved for all other POINT cards						
vis	POINT Visibility flag (0 <= integer 0 = Visible Reference Point 2 = Visible Non-Hit 4 = Visible Hit	<= 5). 1 = Invisible Reference Point 3 = Invisible Non-Hit 5 = Invisible Hit					
X	Point position on X axis (real).						
у	Point position on Y axis (real).						
Z	Point position on Z axis (real).						

Remarks:

The POINT "card" is for introducing point data and is not part of the FASTGEN 4 bulk data deck. POINTs are treated as any other Elements (e.g. CQUAD, CTRI, etc.). POINT cards used with VIEW cards must have a unique PID number between 1 and 1000. NOTE: Each SECTION can have no more than 10,000 POINT cards.

Bulk Data Deck Card: UNITGBL

Description:

Global UNITs "card". The user provides a divisor to be used in scaling all GRID and POINT "card" data in the "deck". This "card" must be before the first SECTION "card". This "card" is optional and VISAGE will default to 1.0 in its absence.

Format, Example, and Data Type:

Field 1	Field 2	Field 3	Field 4	Field 5	Field 6	Field 7	Field 8	Field 9	Field 10
UNITGBL	uval								
UNITGBL	12.0								
string	real								

Field Contents

uval

Value to be used as divisor for data (real).

Remarks:

The UNITGBL "card" must appear before the first SECTION card in a file. VISAGE will ignore it if it appears elsewhere in a file and use the default value.

UNITLCL cards will override the UNITGBL value (either the user-specified value or the default value). If the UNITLCL "card" is specified, then that Component will use the UNITLCL divisor and all succeeding Components will use the UNITGBL divisor.

Rulk	Data	Deck Card:	IINITI	CL.
	768868			1.7.1.4

Description:

Local UNITs "card". User provides a divisor to be used in scaling all GRID and POINT "card" data in the current SECTION. This "card" is optional.

Format, Example, and Data Type:

Field 1	Field 2	Field 3	Field 4	Field 5	Field 6	Field 7	Field 8	Field 9	Field 10
UNITLCL	uval								
UNITLCL	12.0								
string	real								

Field Contents

uval Value to be

Value to be used as divisor for data (real).

Remarks:

UNITLCL cards will override the UNITGBL value (either the user-specified value or the default value). If the UNITLCL "card" is specified, then that Component will use the UNITLCL divisor and all succeeding Components will use the UNITGBL divisor.

3.3 Contour Data File (CDF)

The CDF is an optional file that allows the user to redefine the color schema of individual Elements of the target description drawn from the bulk data deck. It also allows the user to assign values to the chosen colors, which will be displayed on the Color Bar potion of the VISAGE window. Any colors not used in the CDF will remain without values. Appendix B shows an example CDF.

VISAGE will override any mistakes in the type (i.e. real or integer) of the entries, but it cannot correct any subsequent errors resulting from these mistakes, so if an incorrect color is displayed or the color's assigned value is incorrect, check the CDF for entry value typecast errors.

(NOTE: All Contour Data File filenames should end with an extension of ".cdf")

Figure 9 illustrates the order dependencies of the VISAGE Contour Data File.




FIGURE 9

CDF Data Deck Order

Contour Data File Card: CD

Description:

Contour data. This "card" sets the color for the specified Element or Component, at the specified time step. The number of CD cards is limited by the number of Elements in the target description(s). CD cards can be used in conjunction with VIEW cards, or by themselves. If VIEW cards are used, the TIME value for the VIEW cards must correspond to those used in the CD cards.

Format, Example, and Data Type:

Field 1	Field 2	Field 3	Field 4	Field 5	Field 6	Field 7	Field 8	Field 9	Field 10
CD	gr	co	eid	time	mag				
CD	0	1	1	1.00	0.24				
string	integer	integer	integer	real	real				

<u>Field</u>	Contents
gr	Group ID number ($0 \le integer \le 11$).
со	Component ID number (integer > 0).
eid	Element ID number (integer < 0 (Component) or integer > 0 (Element)).
time	Time step value (real).
mag	Magnitude value (real).

Remarks:

By specifying a NEGATIVE value for the Element ID number, VISAGE will set the color of the entire Component, rather than just a specific Element.

All Elements with time steps must be defined for all time steps, otherwise the non-defined Elements will default to the last color specified.

Contour Data File Card: LIMITS

Description:

User defines the limits of magnitude for individual color bar values. (Maximum of 32 LIMITS cards.)

Format, Example, and Data Type:

Field 1	Field 2	Field 3	Field 4	Field 5	Field 6	Field 7	Field 8	Field 9	Field 10
LIMITS	cbid	max	min						
LIMITS	1	1.0	0.0						
string	integer	real	real						

Field Contents

cbid Color bar ID number (0 <= integer <= 31).

max Maximum magnitude value (real).

min Minimum magnitude value (real).

Remarks: The following is a list of the approximate color ranges and the corresponding CBIDS:

Color Range	CBIDs
Red (5 shades)	0 - 4
Orange (5 shades)	5 - 9
Yellow (5 shades)	10 - 14
Green (5 shades)	15 - 19
Blue (5 shades)	20 - 24
Purple (5 shades)	25 - 29
Invisible	30
Default Group Color	31

Contour Data File Card: TMSTEPS

Description:

User provides the number of time steps in the CDF and sets the color bar title. This "card" must be used if CD or VIEW cards are used.

Field 1	Field 2	Field 3	Field 4	Field 5	Field 6	Field 7	Field 8	Field 9	Field 10
TMSTEPS	num	text	"						
TMSTEPS	2	color	bar title						
string	integer	16-char	string						

<u>Field</u>	Contents
num	Number of time steps in CDF (1 <= integer <= 500).
text	Title to be used for the color bar window (maximum 16 character string).

Contour Data File Card: VIEW

Description:

User can provide camera-to-target viewpoint for each time step. By specifying a camera position, a camera target, the time, and the view angle, the user can have progressive viewpoint changes. This "card" must be followed by two POINT cards, which will designate the camera position (CPPID) and the camera target (CTPID). VIEW cards can be used in conjunction with CD cards, or by themselves. If CD cards are used, the TIME value for the VIEW cards must correspond to those used in the CD cards.

Format, Example, and Data Type:

Field 1	Field 2	Field 3	Field 4	Field 5	Field 6	Field 7	Field 8	Field 9	Field 10
VIEW		cppid	ctpid	time	vangle				
VIEW		444	555	1.00	15.0				
string		integer	integer	real	real				

<u>Field</u>	Contents
cppid	Camera Position POINT ID (1 \leq integer \leq 1000).
ctpid	Camera Target POINT ID (1 \leq integer \leq 1000).
time	Time step value (real).
vangle	View Angle value (real > 0.0).

Remarks:

The POINTs used with this "card" are not visible and will not be part of the POINT database. Also, the two POINT cards **must** have unique POINT ID numbers between 1 and 1000.

3.4 Group Defaults File (GDF)

The GDF is an optional file that allows the user to redefine the name and the default colors of the Groups of a target description drawn from the bulk data deck. The *COLORGR* and *GRPNAME* cards allow the user to change the default Group names and default display colors of a target description. This allows for multiple target descriptions to be displayed from the same data set. Appendix C shows an example GDF.

The following is a breakdown of the default colors of the Groups:

Group	Default Color	Default Name
0	Grey	Skin
1	Salmon	Power Plant
2	Gold	Crew
3	Yellow Green	Controls
4	Cornflower	Fuel System
5	Yellow	Ammunition
6	Sky Blue	Armaments
7	Maize	Structure
. 8	Olive Green	Electrical
9	Lavender	Miscellaneous
10	Cadet Blue	Missile

(NOTE: All Group Defaults File filenames should end with an extension of ".gdf")

Figure 10 illustrates the order dependencies of the VISAGE Group Defaults File.




FIGURE 10

GDF Data Deck Order

Group Defaults File Card: COLORGR

Description:

User can define the default display color of a Group.

Format, Example, and Data Type:

Field 1	Field 2	Field 3	Field 4	Field 5	Field 6	Field 7	Field 8	Field 9	Field 10
COLORGR	gr	coid	:						
COLORGR	0	55							
string	integer	integer							

Field Contents

gr Group ID number $(0 \le integer \le 11)$.

coid Color ID number (0 \leq integer \leq 63).

Remarks: On the following page is a list of the available colors and the

corresponding COIDS:

Color Name	COID
aquamarine	0
med. aquamarine	1
black	2
blue	3
cadet blue	4
cornflower blue	5
dark slate blue	6
light blue	7
light steel blue	8
med. blue	9
med. slate blue	10
midnight blue	11
navy blue	12
sky blue	13
slate blue	14
steel blue	15
coral	16
cyan	17
firebrick	18
gold	19
goldenrod	20

Color Name	COID
dark goldenrod	21
green	22
dark green	23
dark olive green	24
forest green	25
lime green	26
med. sea green	27
med. spring green	28
olive drab	29
pale green	30
sea green	31
spring green	32
yellow green	33
dark slate grey	34
dim grey	35
light grey	36
dark khaki	37
magenta	38
maroon	39
orange	40
orchid	41

Color Name	COID
dark orchid	42
med. orchid	43
pink	44
plum	45
red	46
indian red	47
pale violet red	48
orange red	49
violet red	50
salmon	51
sienna	52
tan	53
thistle	54
turquoise	55
dark turquoise	56
med. turquoise	57
violet	58
blue violet	59
wheat	60
white	61
yellow	62
green yellow	63

Description:

User can define Group "name" to be displayed on the Visual Effects menu target description type buttons (wireframe/solid).

Field 1	Field 2	Field 3	Field 4	Field 5	Field 6	Field 7	Field 8	Field 9	Field 10
GRPNAME	gr	text							
GRPNAME	0	group	name						
string	integer	16-char	string						

<u>Field</u>	<u>Contents</u>
gr	Group ID number (0 \leq integer \leq 11).
text	Text to be substituted for the default Group name (maximum 16-character string).

3.5 Fault Tree Data File (FDF)

The FDF is an optional file that allows the user to display fault tree data. This fault tree data may have come from the COVART 4 program or the user may have created his own tree data file.

A fault tree is a graphical representation of a Boolean equation of a failure event. A fault tree consists of elements arranged in serial and/or parallel fashion. Respectively, the serial and parallel arrangements are equivalent to the Boolean OR and AND operations. In a simple serial arrangement, at least one element must fail for the entire construct to fail. In a simple parallel arrangement, one element in each path must fail for the entire construct to fail. A hybrid arrangement, containing both serial and parallel constructs, will fail according to the combined effect of all the constructs.

The usual graphical representation of a fault tree is a block diagram. An advantage of this is that the relationships between elements are readily seen. A disadvantage is that, for large fault trees, the representation may not be completely displayed on a computer screen and may take many pages to print out. Therefore, it was necessary to determine a display format capable of being represented by combinations of low-level Motif widgets while still adequately conveying the tree-like nature of the data.

To simply fulfill these requirements, an outline display format was selected. The outline format is preferable for several reasons. First, it is easily created using only push-button widgets, since no connecting lines are required to delineate the tree structure. Second, the push-button callback functions enable the highlighting of the associated fault tree components in the corresponding target description. Third, it is easily input using the strictly ordered format. Fourth, the tree can be easily rendered, as each card is read in, without having to recompute the entry arrangements. Fifth, the outline format allows for hardcopy output of the tree data in a form that is almost as intuitive as the tree format itself and is easier to produce than tree diagrams.

The data format is strictly ordered to simplify the input subroutines. Basically, the format consists of several conceptual levels; the Set, Function, System, Subsystem, and Component Levels. Each of these levels is designated by formatted data entries referred to as cards. These levels represent the component parts of the tree; the various sub-trees and the leaf (end) nodes.

An input file is produced by traversing a pre-defined fault tree in a depth-first manner and each entry is designated by the appropriate

card, based on the entry's position in the tree. In the outline format, each row may contain only one entry. Entries are designated by the FTSET, FTFUNC, FTSYS, FTSUB, FTCOMP, and \$CNAME cards, which are described on the following pages. Appendix D shows an example FDF.

VISAGE will override any mistakes in the type (i.e. real or integer) of the entries, but it cannot correct any subsequent errors resulting from these mistakes, so if an incorrect value or text description is seen, check the FDF for entry value typecast errors.

(NOTE: All Fault Tree Data File filenames should end with an extension of ".fdf")

Figure 11 illustrates the order dependencies of the VISAGE Fault Tree Data File.




FIGURE 11

FDF Data Deck Order

Fault Tree Data File Card: FTSET

Description:

The FTSET card allows the user to specify a name for the set and how many functions it contains. Each set represents the top level of a particular tree. Generally, there will only be one set (or tree) per input file, but there is no limitation on the number of sets.

Field 1	Field 2	Field 3	Field 4	Field 5	Field 6	Field 7	Field 8	Field 9	Field 10
FTSET	setnam	nfuncs							
FTSET	WING	1							
string	С	I							

<u> Field</u>	<u>Contents</u>
setnam	Name of the fault tree set (max. 8 chars.).
nfuncs	Number of functions in the set (int. > 0).

Fault Tree Data File Card: FTFUNC

Description:

The FTFUNC card allows the user to specify a name for the function, how many systems it contains, what Boolean operation links the functions, an optional field that specifies the number of failures needed for a fault out of the total elements in an AND operation, and a color identification number for highlighting purposes. Each function represents the top level of a particular function being modeled in the tree.

Field 1	Field 2	Field 3	Field 4	Field 5	Field 6	Field 7	Field 8	Field 9	Field 10
FTFUNC	fncnam	nsys	op	M/N	cbid				
FTFUNC	FLAP 1	2	AND	2/2	0				
string	С	ı	С	С	ı				

<u>Field</u>	Contents
fncnam	Name of the function (max. 8 chars.).
nsys	Number of systems in the function (int. > 0).
op	Boolean operation for the function. (AND, OR, or blank).
M/N	Number of faults needed for a failure in an AND operation directly under the function.
cbid	Color Bar ID of highlight color for the function (0 < integer < 31).

Fault Tree Data File Card: FTSYS

Description:

The FTSYS card allows the user to specify a name for the system, how many subsystems it contains, what Boolean operation links the systems, and an optional field that specifies the number of failures needed for a fault out of the total elements in an AND operation.

Field 1	Field 2	Field 3	Field 4	Field 5	Field 6	Field 7	Field 8	Field 9	Field 10
FTSYS	sysnam	nsubs	ор	M/N					
FTSYS	HYDR	3	OR						
string	С	ı	С	С					

Field	Contents
sysnam	Name of the system (max. 8 chars.).
nsubs	Number of subsystems in the system (int. > 0).
op	Boolean operation for the function. (AND, OR, or blank).
M/N	Number of faults needed for a failure in an AND operation directly under the system.

Fault Tree Data File Card: FTSUB

Description:

The FTSUB card allows the user to specify a name for the subsystem, how many subsystems it contains, what Boolean operation links the subsystems, and an optional field that specifies the number of failures needed for a fault out of the total elements in an AND operation. The FTSUB card is unique in that it is the only card that can have other cards of the same type under it, i.e., the FTSUB cards can be nested several layers deep, while the FTSET, FTFUNC, and FTSYS cards can only appear on their respective levels.

Field 1	Field 2	Field 3	Field 4	Field 5	Field 6	Field 7	Field 8	Field 9	Field 10
FTSUB	subnam	nitems	op	M/N					
FTSUB	HYD 1	3	AND	3/3					
string	С	I	С	С					

Field	Contents
subnam	Name of the system (max. 8 chars.).
nitems	Number of subsystems or components in the system (int. > 0).
op	Boolean operation for the function. (AND, OR, or blank).
M/N	Number of faults needed for a failure in an AND operation directly under the system.

Fault Tree Data File Card: FTCOMP

Description:

The FTCOMP card allows the user to specify a name for the component, how many target description components it contains, and what Boolean operation links the components.

Field 1	Field 2	Field 3	Field 4	Field 5	Field 6	Field 7	Field 8	Field 9	Field 10
FTCOMP	cmpnam	ncomps	ор						
FTCOMP	LINE 5	5	OR						
string	С	J	С						

Field	Contents
cmpnam	Name of the component (max. 8 chars.).
nitems	Number of (target description) components in the component (int. > 0).
op	Boolean operation for the component. (AND, OR, or blank).

Fault Tree Data File Card: \$CNAME

Description:

The CNAME card allows the user to specify the target description group and component numbers, the P(K) table identification number, the kill type, and a 40-character text description of the component.

Field 1	Field 2	Field 3	Field 4	Field 5	Field 6	Field 7	Field 8	Field 9	Field 10
\$CNAME	gr	со	pknum	ktype	text				
\$CNAME	3	5	11	к	Hydraul	pump	#2		
string	С	I	l	С	40-char	string			

<u>Field</u>	Contents
gr	Group number $(0 < int. < 12)$.
CO	Component number $(1 \le int. \le 999)$.
pknum	P(K) table number (int. > 0).
ktype	Kill type of the component (e.g., KK, K, A, B, C; max. 8 chars.).
text	Text description of the component (max. 40 chars.).

Data	File	For	rmats
Dala	1 110		

Appendix A: Bulk Data File Example

```
Bulk Data Format Example testall.bdf
             Author: Modified by Brett Grimes
SCOMMENT
$COMMENT
             Date:?
VEHICLE
        TARGET
SCOMMENT THIS TARGET DESCRIPTION IS GENERATED FROM THE SAMPLE
SCOMMENT CASES BUILT FOR THE FASTGEN4 SOFTWARE CHECK OUT.
SCOMMENT SAMPLE CASES WERE MODIFIED SO THAT GID'S AND EID'S
$COMMENT ARE UNIQUE. ADDITIONALLY, THE LOCATION OF ELEMENTS WERE
$COMMENT MOVED SO THAT THE ELEMENTS WOULD NOT OVERLAP EACH OTHER.
SCOMMENT
         THIS IS THE BULK DATA DECK FOR A LINE
SCOMMENT
SCOMMENT123456781234567812345678123456781234567812345678123456781234567812345
                              5
                   1
                         1
SECTION
            0
                     -20.00
                            10.00
                                   5.00
GRID
            1
                     -20.00 10.00
                                  10.00
GRID
                     -20.00 10.00
GRID
            3
                                   15.00
GRID
            4
                     -20.00
                           10.00
                                   20.00
CLINE
           01
                  55
                         1
                                                  .20
                                                        0.99
           02
                  56
                                                  .20
                                                        0.99
CLINE
           03
                  57
                         3
                                                        0.99
                                                  .20
$COMMENT123456781234567812345678123456781234567812345678123456781234567812345
         THIS IS THE BULK DATA DECK FOR A LINE
SCOMMENT
            2
                  3
                         2
SECTION
            0
                                4
           11
                     -16.00
                           10.00
GRID
           12
                     -16.00
                           10.00 10.00
GRID
GRID
           13
                     -16.00
                           10.00 15.00
                     -16.00
                           10.00
                                   20.00
GRID
           14
CLINE
           11
                  55
                        11
                               12
                                                  .00
                                                        0.99
           12
                  56
                        12
                               13
                                                        0.99
CLINE
                                                  .00
                  57
                        13
CLINE
           13
                               14
         THIS IS THE BULK DATA DECK FOR A LINE THREAT RADIUS TEST
5
SCOMMENT
                  3
SECTION
            0
                         1
                                4
           21
                     -30.00
                            10.00
                                   5.00
GRID
GRID
           22
                     -30.00
                           10.00
                                  10.00
GRID
           23
                     -30.00
                           10.00 15.00
GRID
           24
                     -30.00
                            10.00
           21
                        21
                               22
                                                        0.99
CLINE
                  21
                                                  .00
CLINE
           22
                  22
                        22
                               23
                                                  .00
                                                        0.99
                  23
                        23
                               24
CLINE
         THIS IS THE BULK DATA DECK FOR A LINE THREAT RADIUS TEST
SCOMMENT
$COMMENT
            2
                   3
                         4
                                5
SECTION
                   4
```

```
GRID
            31
                      -0.00 10.00
                                     5.00
GRID
            32
                       -0.00 10.00 10.00
            33
                       -0.00
                            10.00
                                    15.00
GRID
                       -0.00
                              10.00
GRID
            34
                                     20.00
                          31
                                 32
                                                     .00
                                                           0.99
CLINE
            31
                   21
                   2.2
                          32
                                 33
                                                     .00
                                                           0.99
CLINE
            32
                                                     .00
                                                           0.99
            33
                   23
                          33
                                 34
CLINE
$COMMENT123456781234567812345678123456781234567812345678123456781234567812345678
           2 3 4 5 6
                                             7
SCOMMENT
            1
                   1
                         1
                                 4
SECTION
            41
                       +3.00
                              07.00
                                    05.00
GRID
            42
                       +3.00 07.00
                                     20.00
GRID
GRID
            43
                       +3.00 13.00
                                     20.00
GRID
            44
                       +3.00
                              13.00
                                     05.00
                   41 41
                              42
                                     43
                                              44 .15
            41
CQUAD
$COMMENT1234567812345678123456781234567812345678123456781234567812345678
                              5
                                               7
                                                       8
           2
                 3
                        4
                                       6
SCOMMENT
                   2
SECTION
            1
                          1
                                 4
            51
                       +9.00 07.00 05.00
GRID
            52
                       +9.00 07.00 20.00
GRID
GRID
            53
                       +9.00 13.00
                                     20.00
            54
                       +9.00 13.00
                                    05.00
GRID
            51
                   41
                        51
                              52
                                     53
                                               54
                                                    .15
$COMMENT1234567812345678123456781234567812345678123456781234567812345678
        2 3 4 5 6
                                            7
                                                     8
                                                              9
SCOMMENT
            2
                          1
                    1
                                 4
SECTION
                       15.00 00.00 00.00
GRID
            61
            62
                       15.00 00.00
                                     20.00
GRID
            63
                       15.00 20.00
                                     20.00
GRID
                       15.00 20.00 00.00
            64
GRID
                       40.00 00.00
                                    00.00
            65
GRID
GRID
            66
                       40.00 00.00
                                     20.00
            67
                       40.00 20.00
                                     20.00
GRID
            68
                       40.00
                              20.00
                                     00.00
GRID
                                                     65
                                                           6661
                   51
                        61
                              62
                                     63
CHEX1
            61
                                               64
61
            67
                   68
                                                     .05
          THIS IS THE BULK DATA DECK FOR A HEXAHEDRON
$COMMENT1234567812345678123456781234567812345678123456781234567812345678
             2 3
                       4 5 6 7
                                                    8
                                                              9
SCOMMENT
            2
                          2
                    2
                                 4
SECTION
GRID
            71
                       45.00 00.00 00.00
GRID
            72
                       45.00
                             00.00
                                     20.00
            73
                       45.00
                             20.00
                                     20.00
GRID
                       45.00
                             20.00 00.00
            74
GRID
            75
                       60.00
                            00.00 00.00
GRID
GRID
            76
                       60.00
                              00.00
                                     20.00
            77
                       60.00
GRID
                              20.00
                                     20.00
            78
                       60.00
                              20.00 00.00
GRID
                                                     75
                                                             7631
            71
                   51
                          71
                              72
                                        73
                                               74
CHEX1
                                                     .00
31
            77
                   78
         THIS IS THE BULK DATA DECK FOR A HEXAHEDRON
$COMMENT1234567812345678123456781234567812345678123456781234567812345678
                                               7
             2
                3
                       4
                              5
                                      6
                                                       8
                                                              9
SCOMMENT
```

```
2
           2
SECTION
                     75.00 00.00 00.00
           81
GRID
                     75.00 00.00 20.00
           82
GRID
           83
                      75.00 20.00 20.00
GRID
                      75.00
                            20.00
                                 00.00
GRID
           84
           85
                      95.00
                            00.00
                                   00.00
GRID
                     95.00 00.00
                                   20.00
           86
GRID
           87
                      95.00
                            20.00
                                   20.00
GRID
GRID
           88
                     95.00
                            20.00
                                 00.00
           81
                        81
                             82
                                   83
                                           84
                                                 85
CHEX2
                  51
           87
                  88
        THIS IS THE BULK DATA DECK FOR A THICK PLATE
$COMMENT1234567812345678123456781234567812345678123456781234567812345678
        2 3 4 5 6 7 8 9
$COMMENT
                        2
           2
SECTION
                     105.00 00.00 00.00
           91
GRID
           92
                     105.00
                           00.00
                                   20.00
GRID
           93
                     105.00 20.00 20.00
GRID
                     105.00 20.00 00.00
GRID
           94
                     120.00 00.00 00.00
           95
GRID
           96
                    120.00
                            00.00
                                   20.00
GRID
                    120.00 20.00 20.00
           97
GRID
           98
                    120.00 20.00 00.00
GRID
                    140.00 00.00 00.00
GRID
           99
                    140.00 00.00
                                   20.00
GRID
          110
                    140.00 20.00 20.00
GRID
          111
                    140.00
                            20.00 00.00
          112
GRID
                                   93
                                                 95
                                                        9631
                 51 91
                            92
                                            94
          91
CHEX2
           97
                  98
31
                       95 96 97 98 99
                                                        11032
          92
                 51
CHEX2
          111
                 112
$COMMENT
        THIS IS THE BULK DATA DECK FOR A TRIANGLE
$COMMENT1234567812345678123456781234567812345678123456781234567812345
$COMMENT 2 3 4 5 6 7 8
           3
                  1
                        1
SECTION
                     155.00 00.00 00.00
          101
GRID
                    155.00 00.00 20.00
GRID
          102
GRID
          103
                    155.00 20.00 20.00
          104
                    155.00 20.00 00.00
GRID
                  51 101 102
52 101 103
                                   103
                                                 .05
          101
CTRI
                                                 .05
          102
                 52
                       101
                              103
                                   104
CTRI
        THIS IS THE BULK DATA DECK FOR A QUADRILATERAL
$COMMENT123456781234567812345678123456781234567812345678123456781234567812345
         2 3 4 5 6
                                          7
                                                  8
$COMMENT
SECTION
           3
                  2
                         1
                               4
                    165.00 00.00 00.00
          111
GRID
          112
                     165.00
                            00.00 20.00
GRID
                     165.00
                            20.00
                                   20.00
GRID
          113
GRID
          114
                     165.00
                            20.00
                                   00.00
                  51 111
                             112
                                   113
                                           114 .05
COUAD
          111
$COMMENT THIS IS THE BULK DATA DECK FOR A SPHERE
$COMMENT1234567812345678123456781234567812345678123456781234567812345
        2 3 4 5 6 7 8
SCOMMENT
```

```
SECTION 10 1 1 4
         117
                 200.00 00.00 00.00
GRID
CSPHERE 117 51 117
                                              5.0 10.0
$COMMENT THIS IS THE BULK DATA DECK FOR A SPHERE
$COMMENT123456781234567812345678123456781234567812345678123456781234567812345
$COMMENT 2 3 4 5 6 7 8
                             4
SECTION
         10
                2
                    2
                 230.00 00.00 00.00
GRID
         118
       118 51 118
CSPHERE
SCOMMENT THIS IS THE BULK DATA DECK FOR A THIN WALL CONE
$COMMENT12345678123456781234567812345678123456781234567812345
$COMMENT 2 3 4 5 6
                                       7 8
                1 4
260.00 00.00 10.00
290.00 00.00
SECTION
          4
GRID
         126
         127
GRID
        126
                65 127 126
                                              .05 05.031
CCONE1
       10.0 1 1
$COMMENT THIS IS THE BULK DATA DECK FOR A THIN WALL CONE
SCOMMENT1234567812345678123456781234567812345678123456781234567812345
$COMMENT 2 3 4 5 6 7 8 SECTION 4 4 1 4
SECTION
               330.00 00.00 00.00
330.00 00.00 50.00
GRID
         128
GRID
         129
        128
                65 128 129
2 2
                                              .05 05.031
        10.0 2
31
$COMMENT THIS IS THE BULK DATA DECK FOR A THIN WALL CONE
$COMMENT1234567812345678123456781234567812345678123456781234567812345
$COMMENT 2 3 4 5 6 7 8
              5 2
SECTION
          4
                           4
        136
                370.00 00.00 -10.00
340.00 00.00 -10.00
GRID
         137
GRID
        136
        136 65 137 136
10.0 2 2
CCONE1
                                              .00 05.031
SCOMMENT THIS IS THE BULK DATA DECK FOR A THICK WALL CONE
$COMMENT1234567812345678123456781234567812345678123456781234567812345
$COMMENT 2 3 4 5 6 7 8 SECTION 4 6 2 4
SECTION
               430.00 00.00 00.00
400.00 00.00 00.00
          146
GRID
        147 400.00 11.1
146 65 147 146
10.0 03. 07.
GRID
CCONE2
                                                    05.031
SCOMMENT THIS IS THE BULK DATA DECK FOR VOLUME SUBTRACTION
HOLE 4 8 4 998
$COMMENT12345678123456781234567812345678123456781234567812345
$COMMENT 2 3 4 5
SECTION 4 998 2 4
                                   6
               490.00 00.00 00.00
460.00 00.00 00.00
         156
GRID
         157
                   460.00 00.00 00.00
GRID
         156
                62 157 156
                                               .00 03.031
CCONE1
      07.0
                2
                     2
$COMMENT1234567812345678123456781234567812345678123456781234567812345
$COMMENT 2 3 4 5 6 7
                             4
                      2
SECTION
          4
                 8
```

```
166
                  490.00 00.00 00.00
GRID
        167
                  460.00 00.00 00.00
        166
                61 167 166
                                            .00 05.031
CCONE1
             2
        10.0
                     2
SCOMMENT THIS IS THE BULK DATA DECK FOR VOLUME INTERFERENCE
WALL 4 9 4 999
$COMMENT123456781234567812345678123456781234567812345678123456781234567812345
$COMMENT 2 3 4 5 6 7
                                              Q
               9 2
SECTION
          4
               560.00 00.00 00.00
530.00 00.00 00.00
         176
GRID
GRID
         177
        176
                61 177 176
        10.0
               2
                    2
SCOMMENT123456781234567812345678123456781234567812345678123456781234567812345
$COMMENT 2 3 4 5 6 7 8
        4 999 2 4
186 559.00 00.00 00.00
187 531.00 00.00 00.00
SECTION
GRID
GRID
        186
               62 187 186
                                            .00 04.031
CCONE1
       09.0
               2
                     2
SCOMMENT
      THIS IS THE BULK DATA DECK FOR VOLUME SUBTRACTION
HOLE 5 1 5 2
$COMMENT 2 3 4 5 6 7
                                             8
                    2
          5
SECTION
                1
                           4
                605.00 00.00 00.00
        211
GRID
        212
                  605.00 00.00 20.00
GRID
        213
                  605.00 20.00 00.00
GRID
        241
                  620.00 00.00 00.00
GRID
        242
                  620.00 00.00 20.00
                  620.00 20.00 00.00
GRID
        243
                                           .00
         211 18
212 48
               18 213 212 211
CTRI
                                            .00
                    243
                          242
                                241
SCOMMENT1234567812345678123456781234567812345678123456781234567812345
$COMMENT 2 3 4 5 6 7
SECTION
          5
               2 2
                          4
                610.00 00.00 00.00
        221
                  610.00 00.00 20.00
GRID
        222
                  610.00 20.00 00.00
        223
GRID
        231
GRID
                  615.00 00.00 00.00
GRID
        232
                  615.00 00.00 20.00
         233
                  615.00 20.00 00.00
GRID
         221

    28
    223
    222
    221

    38
    233
    232
    231

                                            .00
                                                    1
CTRI
         222
$COMMENT THIS IS THE BULK DATA DECK FOR VOLUME INTERFERENCE
      5 5 5 6
$COMMENT1234567812345678123456781234567812345678123456781234567812345
$COMMENT 2 3 4 5 6
                                     7
                     2
          5
               5
SECTION
                           4
GRID
        311
                655.00 00.00 00.00
GRID
        312
                  655.00 00.00 20.00
        313
                  655.00 20.00 00.00
GRID
        341
GRID
                  670.00
                         00.00 00.00
```

```
GRID
           342
                      670.00
                               00.00
                                      20.00
           343
                      670.00
                               20.00
                                      00.00
GRID
                                                               1
           311
                   18
                        313
                                312
                                       311
                                                       .00
CTRI
                                                       .00
                          343
                                 342
                                        341
                                                                1
           312
                    48
CTRI
$COMMENT12345678123456781234567812345678123456781234567812345
                                 5
                                        6
                                                '7
                                                        8
SCOMMENT
           2
                   3
                          4
SECTION
            5
                    6
                            2
                                  4
                       660.00
                              00.00
                                     00.00
           321
GRID
GRID
                       660.00
                              00.00
                                      20.00
           322
                              20.00
                                     00.00
           323
                       660.00
GRID
                              00.00
           331
GRID
                       665.00
                                      00.00
                                      20.00
                       665.00
                              00.00
GRID
           332
                       665.00
                               20.00
                                      00.00
GRID
           333
                                 322
                                                       .00
                   28
                          323
                                        321
                                                                1
CTRI
           321
CTRI
                   38
                          333
                                 332
                                        331
                                                       .00
                                                                1
           332
         THIS IS THE BULK DATA DECK FOR VOLUME SUBTRACTION
$COMMENT
            6
                   1
                       6
                                2
$COMMENT1234567812345678123456781234567812345678123456781234567812345
                        4 5
                                      6
                                               7
$COMMENT
           2.
                    3
                            2
             6
                    1
                                   4
SECTION
                       700.00
                              00.00
                                      00.00
           411
GRID
                       700.00
                              00.00
                                      20.00
GRID
           412
           413
                       700.00
                              20.00
                                      20.00
GRID
                       700.00
                              20.00
                                      00.00
GRID
           414
           441
                       720.00
                              00.00
                                      00.00
GRID
                              00.00
                                      20.00
GRID
           442
                       720.00
                              20.00
GRID
           443
                       720.00
                                      20.00
                       720.00
                               20.00
                                      00.00
GRID
           444
                                       413
                                                              44219
CHEX2
           411
                   18
                         411
                                412
                                               414
19
           443
                   444
$COMMENT1234567812345678123456781234567812345678123456781234567812345678
           2 3 4 5 6
                                             7
                                                      8
SCOMMENT
                    2
                           2.
                                  4
SECTION
            6
                       705.00
                              05.00
                                      05.00
GRID
            421
GRID
           422
                       705.00
                              05.00
                                      15.00
                       705.00
           423
                              15.00
                                      15.00
GRID
                       705.00
                              15.00
GRID
           424
                       715.00
                              05.00
                                      05.00
           431
GRID
GRID
                       715.00
                              05.00
                                      15.00
           432
                                      15.00
GRID
           433
                       715.00
                              15.00
GRID
           434
                       715.00
                              15.00
                                      05.00
                    28
                                422
                                        423
                                               424
                                                       .00
                                                                2
COUAD
           421
                         421
                                        433
                                               434
                                                       .00
                                                                2
            422
                    38
                          431
                                 432
CQUAD
                                                       .00
                                                                2
                                                424
                          421
                                 431
                                        434
           423
                    48
CQUAD
                                                423
                                                       .00
                                                                2
           424
                    58
                          422
                                 432
                                        433
CQUAD
                                                       .00
                                                                2
COUAD
           425
                    68
                          421
                                 431
                                        432
                                                422
                    78
                          424
                                 434
                                        433
                                                423
                                                       .00
CQUAD
            426
         THIS IS THE BULK DATA DECK FOR VOLUME INTERFERENCE
$COMMENT
                       7
          7
                                2
                 1
5
                                     6
                                               7
                                                       8
             2
                   3
                         4
$COMMENT
             7
                    1
                          2
SECTION
                       800.00
                               00.00
                                     00.00
GRID
            511
```

```
GRTD
         512
                   800.00 00.00 20.00
         513
GRID
                   800.00 20.00 20.00
GRID
         514
                   800.00 20.00 00.00
                   820.00 00.00 00.00
GRID
         541
         542
GRID
                  820.00 00.00 20.00
GRID
         543
                  820.00 20.00 20.00
         544
                  820.00 20.00 00.00
GRID
                                      514 541 54219
               18 511 512 513
CHEX2
         511
              544
         543
$COMMENT1234567812345678123456781234567812345678123456781234567812345678
$COMMENT 2 3 4 5 6 7 8
                      2
          7
                            4
SECTION
                805.00 05.00 05.00
GRID
        521
        522
GRID
                  805.00 05.00 15.00
        523
                  805.00 15.00 15.00
GRID
        524
                  805.00 15.00 05.00
GRID
                  815.00 05.00 05.00
        531
GRID
GRID
         532
                  815.00 05.00 15.00
         533
                  815.00 15.00 15.00
GRID
                815.00 15.00 05.00
        534
GRID
              28 521 522 523
38 531 532 533
48 521 531 534
58 522 532 533
                                            .00
CQUAD
         521
                                      524
                                      534
                          532 533
531 534
                                            .00
         522
COUAD
         523
                                      524
                                            .00
COUAD
         524
                                533
                                      523
                                             .00
CQUAD
                68 521 531
78 524 534
                               532
533
        525
526
                                       522
                                             .00
COUAD
                78
                                             .00
                                       523
SCOMMENT THIS IS THE BULK DATA DECK FOR VOLUME INTERFERENCE
WALL
       8 1 8 2
      9 1 9 2
$COMMENT1234567812345678123456781234567812345678123456781234567812345
$COMMENT 2 3 4 5 6 7 8 SECTION 8 1 2 4
SECTION
        8
611
                905.00 00.00 00.00
GRID
                  905.00 00.00 20.00
GRID
        612
        613
                  905.00 20.00 00.00
GRID
        641
                  920.00 00.00 00.00
GRID
        642
                  920.00 00.00 20.00
                920.00 20.00 00.00
        643
GRID
         611 18
612 48
               18 613 612 611
48 643 642 641
                                            .00
CTRI
$COMMENT1234567812345678123456781234567812345678123456781234567812345
$COMMENT 2 3 4 5 6 7 8
                2 1
                          4
SECTION
          8
         621
                910.00 00.00 00.00
GRID
         622
                  910.00 00.00 20.00
GRID
                910.00 20.00 00.00
GRID
         623
         621
                28 623 622 621
                                             .05
SCOMMENT1234567812345678123456781234567812345678123456781234567812345
$COMMENT 2 3 4 5 6 7
          9
                1 2
SECTION
                          4
         711
                905.00 00.00 00.00
        712
                  905.00 00.00 20.00
GRID
GRID
         713
                   905.00
                          20.00 00.00
```

GRID	741		920.00	00.00	00.00			
GRID	742		920.00	00.00	20.00			
GRID	743		920.00	20.00	00.00			
CTRI	711	18	713	712	711		.00	1
CTRI	712	48	743	742	741		.00	1
\$COMMENT123	345678123	456781	23456783	12345678:	12345678123	3456781234	1567812345	
\$COMMENT	2	3	4	5	6	7	8	
SECTION	9	2	1	4				
GRID	721		910.00	00.00	00.00			
GRID	722		910.00	00.00	20.00			
GRID	723		910.00	20.00	00.00			
CTRI	721	28	723	722	721		.05	1
\$COMMENT123	3 4 5678123	456781	23456783	123456783	12345678123	3456781234	1567812345	
\$COMMENT	2	3	4	5	6	7	8	
SECTION	10	2	1	4				
GRID	821		1010.00	00.00	00.00			
GRID	822		1010.00	00.00	20.00			
GRID	823		1010.00	20.00	00.00			
CTRI	821	28	823	822	821		.05	1
\$COMMENT123	345678123	456781	23456781	123456783	12345678123	3 4 56781234	15678	
SECTION	11	1	1	1				
POINT	1		-324.42	49.47	-93.92	0	20	
POINT	2		94.01		140.48	0	20	
POINT	3		3.70		218.95	0	20	
POINT	4			-276.61		0	20	
POINT	5		-15.78	219.23		0	20	
POINT	6			-289.00	-9.22	0	20	
POINT	7		-344.40	-107.07	-44.40	0	20	
POINT	8		34.02	180.37		0	20	
POINT	9			-245.33	-73.22	0	20	
POINT	10		-307.86	-185.04	-49.12	0	20	
POINT	11		-324.32		-49.93	0	20	
POINT	12			-60.56		0	20	
POINT	13			-100.43		0	20	
POINT	14			-238.60	64.90	0	20	
POINT	15		-211.94	231.44	66.56	0	20	
ENDDATA								

$Appendix\,B{:}\,Contour\,Data\,File\,Example$

\$COMMENT	,====== = ==	=====	======	=======	==== = =	=======================================	
\$COMMENT	Con	Contour Data Format Example ae.cdf					
\$COMMENT	Aut	Author: Brett F. Grimes					
\$COMMENT	Dat	e:?					
						=======================================	
\$COMMENT	12345678123	456781	23456783	L23 45 6781	.23456781	.234567812345678	
LIMITS	1	0.1	0.0				
LIMITS	2	0.2	0.1				
LIMITS	3	0.3	0.2				
LIMITS	4	0.4	0.3				
LIMITS	5	0.5	0.4				
LIMITS	6	0.6	0.5				
LIMITS	7	0.7	0.6				
LIMITS	8	0.8	0.7				
LIMITS	9	0.9	0.8				
LIMITS	10	1.0	0.9				
TMSTEPS	2						
\$COMMENT	VIEW cards	}					
VIEW		555	444	1.00	5.0		
POINT	444	1	0.00	0.00	0.00		
POINT	555	1	110.00	110.00	110.00		
VIEW		888	777		15.0		
POINT	777	1	0.00	0.00	0.00		
POINT	888	1	110.00	-110.00	110.00		
\$COMMENT	CD cards						
CD	0	1	5001	1.00	0.24		
CD	0	1	5001	2.00	0.54		
ENDDATA							

Appendix C: Group Defaults File Example

\$COMMENT====		========
\$COMMENT	Group Defaults Format Example ep.gdf	
\$COMMENT	Author: Brett F. Grimes	
\$COMMENT	Date:?	1
\$COMMENT====		========
\$COMMENT1234	5678123456781234567812345678123456781234567812345678	
COLORGR	0 0	
GRPNAME	0 SAUCER SECTION	
COLORGR	1 26	
GRPNAME	1 WARP NACELLES	
COLORGR	7 21	
GRPNAME	7 MAIN HULL	
ENDDATA		

$Appendix \, D\hbox{:}\, Fault \, \mathit{Tree} \, \mathit{Data} \, \mathit{File} \, \mathit{Example}$

\$COMMEN	T=======		========			
\$COMMENT		Fault Tree	Data Forma	t Example pitchn02a.fdf		
\$COMMENT		Author: Br	ett F. Grim	nes		
\$COMMENT		Date:11/94				
\$COMMENT===================================						
\$COMMEN	T12345678	1234567812	34567812345	6781234567812345678123456781234567812345678		
FTSET	B1BPITCH	1				
FTFUNC	PITCHN02	1	AND	30		
FTSYS	PITN02R	2	AND			
FTSUB	P&RCNT12	2	OR			
FTCOMP	P&RCONT1	1	AND			
\$CNAME	3	51	3051	PITCH/ROLL CONTRLR 2 ELECT		
FTCOMP	P&RCONT2	1	AND			
\$CNAME	3	52	3052	PITCH/ROLL CONTRLR 2 ELECT		
\$COMMEN	T======					
\$COMMEN	T12345678	1234567812	34567812345	6781234567812345678123456781234567812345678		
FTSUB	ENGR	2	OR			
FTSUB	ENGRR	4	AND			
FTCOMP	PITCHSV1	2	OR			
\$CNAME	3	210	3210	SCAS CYLINDER LINK 1		
\$CNAME	3	903	3903	INBOARD PITCH/ROLL SCAS (#1)		
FTSUB	ENG34	2	OR			
FTCOMP	ENG3	9	AND			
\$CNAME	1	410	1410	FAN ENGINE #3		
\$CNAME	1	430	1430	COMPRESSOR		
\$CNAME	1	450	1450	COMBUSTOR		
\$CNAME	1		1470	TURBINE		
\$CNAME	1		1490	TURBINE FRAME		
\$CNAME	1		1510	AUGMENTOR		
\$CNAME	1		1530	ACCESSORY GEAR BOX		
\$CNAME	1		1551	MIXER		
\$CNAME	1		1552	NOZZLE		
FTCOMP	ENG4	9	AND			
\$CNAME	1	610	1610	FAN ENGINE #4		
\$CNAME	1	630	1630	COMPRESSOR		
\$CNAME	1	650	1650	COMBUSTOR		
\$CNAME	1	670	1670	TURBINE		
\$CNAME	1	690	1690	TURBINE FRAME		
\$CNAME	1	710	1610	AUGMENTOR		
\$CNAME	1	730	1630	ACCESSORY GEAR BOX		
\$CNAME	1	751	1651	MIXER		
\$CNAME	1	752	1652	NOZZLE		
FTCOMP	HYD3SV		OR			
\$CNAME	3	640	3640	RESERVOIR SYST III		
\$CNAME	3	641	3641	MASTER PUMP SYST III		
\$CNAME	3	642	3642	SLAVE PUMP SYST III		
\$CNAME	3	643	3643	FILTER/TRANSDUCER, SYST III		
\$CNAME	3	644	3644	N2 BOTTLE SYST III		

FTCOMP	HEATEX3	1	OR				
\$CNAME	6	723	6723	HEAT EXCHANGER HYD TO FHS LH INTERIOR			
\$COMMEN	T======	=======	========				
\$COMMENT123456781234567812345678123456781234567812345678123456781234567812345678							
FTSUB	ENGRL	5	AND				
FTCOMP	OBPITROL	1	OR				
\$CNAME	3	904	3904	INBOARD PITCH/ROLL SCAS (#3)			
FTCOMP	PITCHSV2	1	OR				
\$CNAME	3	211	3211	SCAS CYLINDER LINK 2			
FTSUB	ENG12	2	OR				
FTCOMP	ENG1	9	AND				
\$CNAME	1	10	1010	FAN ENGINE #1			
\$CNAME	1	30	1030	COMPRESSOR			
\$CNAME	1	50	1050	COMBUSTOR			
\$CNAME	1	70	1070	TURBINE			
\$CNAME	1	90	1090	TURBINE FRAME			
\$CNAME	1	110	1110	AUGMENTOR			
\$CNAME	1	130	1130	ACCESSORY GEAR BOX			
\$CNAME	1	151	1151	MIXER			
\$CNAME	1	152	1152	NOZZLE			
FTCOMP	ENG2	9	AND				
\$CNAME	1	210	1210	FAN ENGINE #2			
\$CNAME	1	230	1230	COMPRESSOR			
\$CNAME	1	250	1250	COMBUSTOR			
\$CNAME	1	270	1270	TURBINE			
\$CNAME	1	290	1290	TURBINE FRAME			
\$CNAME	1	310	1310	AUGMENTOR			
\$CNAME	1	330	1330	ACCESSORY GEAR BOX			
\$CNAME	1	351	1351	MIXER			
\$CNAME	1	352	1352	NOZZLE			
FTCOMP	HYD1SV	5	OR				
\$CNAME	3	436	3436	RESERVOIR SYST I			
\$CNAME	3	437	3437	MASTER PUMP SYST I			
\$CNAME	3	438	3438	SLAVE PUMP SYST I			
\$CNAME	3	439	3439	FILTER/TRANSDUCER, SYST I			
\$CNAME	3	440	3440	N2 BOTTLE SYST I			
FTCOMP	HEATEX1	1	OR				
\$CNAME	6	729	6729	HEAT EXCHANGER HYD TO FHS RH INTERIOR			
\$COMMEN	T=======	=======					
ENDDATA							

Appendix E: Fault Tree Output File Example

ABCDEF01

```
ABCDE0 2/2 <AND>
          ABC0
                  <AND>
                    \mathbf{A0}
                           <OR>
                              0_1 component A0
                                                              , PKNUM = 100, Kill Type = K
                    B<sub>0</sub>
                           <OR>
                              0_2 component B0
                                                              , PKNUM = 100, Kill Type = K
                    C0
                           <OR>
                                                              , PKNUM = 100, Kill Type = K
                              0_3 component C0
          DEF0 2/2 <AND>
                    D0
                           <AND>
                              0 4 component D0
                                                              , PKNUM = 100, Kill Type = K
                    E0
                           <AND>
                                                              , PKNUM = 100, Kill Type = K
                              0_5 component E0
                    F0
                           <AND>
                              0 6 component F0
                                                              , PKNUM = 100, Kill Type = K
ABCDE1 2/2 <AND>
          ABC1
                  <AND>
                    A1
                           <OR>
                               1_1 component A1
                                                              , PKNUM = 100, Kill Type = K
                    B1
                           <OR>
                                                              , PKNUM = 100, Kill Type = K
                               1_2 component B1
                    C1
                           <OR>
                              1_3 component C1
                                                              , PKNUM = 100, Kill Type = K
          DEF1 2/2 <AND>
                    D1
                           <AND>
                                                              , PKNUM = 100, Kill Type = K
                               1_4 component D1
                    E1
                           <AND>
                               1_5 component E1
                                                              , PKNUM = 100, Kill Type = K
                    F1
                           <AND>
                                                              , PKNUM = 100, Kill Type = K
                              1_6 component F1
```

Bibliography

- 1. Vice, John, "Surviving Desert Storm," Aerospace America, 30: 33,62, August 1992
- 2. Ball, R. E., The Fundamentals of Aircraft Combat Survivability Analysis and Design, AIAA, 1985
- 3. "HOOPS Graphics System Tutorial", Ithaca Software, Inc., Mountain View, CA
- 4. "HOOPS Reference Manual", Ithaca Software, Inc., Mountain View, CA
- 5. Dussault, Heather B., "The Evolution and Practical Applications of Failure Modes and Effects Analyses," Rome Air Development Center, Griffis AFB, March 1983.
- 6. Roach, Lisa K., "Fault Tree Analysis and Extensions of the V/L Process Structure," Army Research Laboratory, Aberdeen Proving Ground, MD, June 1993.
- Bass, Lewis, Wynholds, Hans, Porterfield III, William, "Logic Tree Analysis A Fault Tree Graphics Approach," LMSC-D368008 Revision A, Defense Technical Information Center E034-0932, August 1974.
- 8. Buckland, Michael E., Webster, Mark, Tkalcevic, Frank J., "GRAFTED GRAphical Fault Tree EDitor: A Fault Tree Description Program for Target Vulnerability/Survivability Analysis User Manual," DSTO Materials Research Laboratory, Ascot Vale, Victoria, Australia, December 1993
- 9. Deitz, Paul H., Starks, Michael W., Smith, Jill H., Ozolins, Aivars, "Current Simulation Methods in Military Systems Vulnerability Assessment," Ballistic Research Laboratory, Aberdeen Proving Ground, MD, November 1990
- Deitz, Paul H., "Computer-Aided Techniques for Survivability/Lethality Modeling," Ballistic Research Laboratory, Aberdeen Proving Ground, MD, February 1988
- 11. Deitz, Paul H., "Modern Computer-Aided Tools for High-Resolution Weapons System Engineering," Ballistic Research Laboratory, Aberdeen Proving Ground, MD, February 1988
- 12. Starks, Michael W., "Assessing the Accuracy of Vulnerability Models by Comparison with Vulnerability Experiments," Ballistic Research Laboratory, Aberdeen Proving Ground, MD, July 1989
- 13. Barlow, R. E., Lambert, H. E., "Introduction to Fault Tree Analysis," Reliability and Fault Tree Analysis, SIAM, Philadelphia, PA, 1975, pages 7-35

- 14. Young, Jonathan, "Using the Fault Tree Analysis Technique," Reliability and Fault Tree Analysis, SIAM, Philadelphia, PA, 1975, pages 827-847
- 15. Bass, Lewis, Wynholds, Hans W., Porterfield, William R., "Fault Tree Graphics," Reliability and Fault Tree Analysis, SIAM, Philadelphia, PA, 1975, pages 913-927
- 16. Pascal, Andrew M., Foulk, Jeffery W., Vikestad, Walter S., "Integration of Vulnerability Analysis Requirements Into Aircraft Joint Live Fire (JLF) Test Plans," The SURVICE Engineering Company, Aberdeen, MD, December 1990
- 17. Klopcic, J. Terrence, "Survey of Vulnerability Methodological Needs," Ballistic Research Laboratory, Aberdeen Proving Ground, MD, November 1991
- 18. Survivability Evaluation Branch, "F/A-18 Baseline Combat Survivability Evaluation, Appendix E: Fault Trees," Survivability and Lethality Division, Naval Weapons Center, China Lake, CA, May 1982
- 19. Grover, John M., "A Methodology for Determining the Survivability of Fixed-Wing Aircraft Against Small Arms," AFIT/GST/ENS/89M-05, Wright-Patterson AFB, OH, March 1989
- 20. Kavanagh, Kevin John, "MacIntosh Survivability Assessment Program," Naval Postgraduate School, Monterey, CA, September 1991
- 21. Gil, Leopoldo Dolano Jr., "A Comparison of Three Computer Weapon-Target Endgame Simulations for Aircraft," Naval Postgraduate School, Monterey, CA, June 1992
- 22. Bruenning, Leonard E. Jr., Womble, Alyndia S., "High-Explosive Incendiary Vulnerability Assessment Model (HEIVAM)," Volume I: User Manual, Air Force Armament Laboratory, Eglin AFB, FL, September 1986.
- 23. Bruenning, Leonard E. Jr., Womble, Alyndia S., "High-Explosive Incendiary Vulnerability Assessment Model (HEIVAM)," Volume II: Analyst Manual, Book 1, Air Force Armament Laboratory, Eglin AFB, FL, September 1986.
- 24. Bennett, Gerald, Crosthwaite, Kevin R., "A Summary of Aerospace Vehicle Computerized Geometric Descriptions for Vulnerability Analyses," ASD-TR-91-5032, Advanced Systems Analysis Directorate, ASD, Wright-Patterson AFB, OH, May 1992
- 25. "COVART 4.0 User Manual (Draft)," Task Report, KETRON Division of The Bionetics Corporation, Baltimore, MD, ASC/YFEX and ASC/XRESV, Wright-Patterson AFB, OH, April 1994
- 26. Griffis, Hugh, Lentz, Marty, "FASTGEN 4.1 User's Manual," ASC/XRESV and WL/FIVS, Wright-Patterson AFB, OH, April 1994

Vita

Brett F. Grimes was born on February 5, 1965 in St. Marys, Ohio. He graduated

from Memorial High School in St. Marys in 1983 and attended Wright State University in

Dayton, Ohio. He graduated in 1989 with a Bachelor of Science in Computer Engineering.

Upon graduation, he spent some months in St. Louis before taking a position with the

Scientific and Engineering Applications section of the Information Systems Technical

Center at Wright-Patterson AFB, Ohio. His duties included evaluating, installing, and

maintaining software applications, and eventually defining the guidelines for application

management for the organization. He was also responsible for the development of a Unix

workstation demonstration laboratory for the evaluation of hardware and software

products. Later, he went on to assemble the Wright-Patterson Major Shared Resource

Center Visualization Laboratory. Early on however, he became involved with graphics

programming projects that eventually led to his thesis efforts in the School of Engineering

at the Air Force Institute of Technology.

Permanent Address:

7922-C Moulins Dr.

Centerville, OH 45459

174